

SEPOX HD-AW-HS

SEPOX Large Outdoor Padlock Instruction Manual

Model: HD-AW-HS

1. PRODUCT OVERVIEW

The SEPOX Large Outdoor Padlock (Model HD-AW-HS) is a heavy-duty, all-weather keyed padlock designed for enhanced security in various outdoor and indoor applications. It features a robust 50mm (2-inch) solid steel body and a hardened steel shackle, providing resistance against cutting, sawing, and prying. The padlock is equipped with a waterproof blue cover, offering protection against corrosion and harsh weather conditions.



Image 1.1: SEPOX Large Outdoor Padlock with its two keys.

Key Features:

- **Unmatched Security Design:** Robust 2-inch solid steel body and hardened steel shackle for superior protection.
- **Durable Blue Coating:** Enhances resistance to corrosion and harsh weather.
- **Versatile Usage:** Suitable for doors, sheds, lockers, toolboxes, gates, and chains.
- **Easy Installation:** User-friendly design for straightforward application.
- **Ultimate Waterproof Protection:** Crafted with waterproof materials to resist moisture.

2. SETUP AND INITIAL INSPECTION

Upon receiving your SEPOX padlock, perform a brief inspection to ensure all components are present and in good condition.

What's Included:

- 1 x SEPOX Large Outdoor Padlock
- 2 x Keys

Initial Steps:

1. Remove the padlock and keys from their packaging.
2. Inspect the padlock body and shackle for any visible damage.
3. Insert one of the provided keys into the keyway and turn it to ensure smooth operation. The shackle should open and close freely.




Image 2.1: Close-up view of the padlock's keyhole, showing the brass cylinder.

3. OPERATING INSTRUCTIONS

Using your SEPOX padlock is straightforward. Follow these steps to secure and unlock your belongings.

To Lock:

1. Ensure the shackle is in the open position.
2. Position the padlock around the items or through the hasp/chain you wish to secure.
3. Press the shackle firmly into the padlock body until it clicks into place. The padlock is now locked.
4. Remove the key.

To Unlock:

1. Insert the key fully into the keyway.
2. Turn the key clockwise (or counter-clockwise, depending on the lock mechanism) until the shackle springs open.
3. Remove the padlock from the secured items.
4. Remove the key.



Image 3.1: The SEPOX padlock securing a heavy chain, demonstrating typical usage.



Image 3.2: The padlock in use on a metal gate, highlighting its suitability for outdoor security.

4. MAINTENANCE

Proper maintenance will extend the lifespan and ensure the smooth operation of your SEPOX padlock.

General Care:

- **Cleaning:** Wipe the padlock body with a soft, damp cloth to remove dirt and grime. Avoid abrasive cleaners.

- **Moisture:** Although waterproof, if moisture gets into the lock cylinder, wipe it off with a towel to prevent potential long-term issues and extend service life.
- **Lubrication:** Periodically apply a small amount of graphite lubricant or a silicone-based spray into the keyway and around the shackle mechanism. This helps maintain smooth operation, especially in dusty or humid environments. Avoid oil-based lubricants as they can attract dirt.



Image 4.1: The padlock exposed to rain, illustrating its waterproof design.

5. TROUBLESHOOTING

If you encounter issues with your padlock, refer to the following common problems and solutions.

Common Issues:

- **Key is difficult to insert or turn:**
 - Ensure the key is fully inserted and oriented correctly.
 - Apply a small amount of graphite lubricant into the keyway.

- Check for any debris in the keyway and carefully remove it.
- **Shackle is stuck or difficult to open/close:**
 - Apply a silicone-based lubricant to the shackle where it enters the padlock body.
 - Ensure the key is turned completely to the unlock position.
 - Check for any obstructions preventing the shackle from moving freely.
- **Padlock does not lock:**
 - Ensure the shackle is fully depressed into the lock body until you hear a click.
 - Verify that the key is removed after attempting to lock.

6. SPECIFICATIONS

Detailed specifications for the SEPOX Large Outdoor Padlock (Model HD-AW-HS).

Feature	Detail
Brand	SEPOX
Model Number	HD-AW-HS
Lock Type	Pin Tumbler, Brass Cylinder, High Security
Special Features	Anti-Corrosion, Waterproof, Keyed Alike
Material	Anti-rust steel with cover, Solid Brass Cylinder
Color	Blue
Item Dimensions (L x W x H)	1 x 2 x 1.4 inches
Recommended Uses	Outdoor, sports, industrial, gym, school, chain, gate
Included Components	Padlock, 2 Keys



Image 6.1: Dimensional diagram of the SEPOX padlock.

7. WARRANTY AND SUPPORT

SEPOX stands behind the quality of its products.

Manufacturer's Warranty:

This SEPOX padlock is covered by a **5-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

Customer Support:

For warranty claims, technical assistance, or any questions regarding your SEPOX padlock, please contact the manufacturer, SEPOX leading manufacturer of lock, through their official channels or the retailer where the product was purchased.

8. PRODUCT VIDEO

Watch the official SEPOX product video for a visual demonstration of the padlock's features and applications.

Your browser does not support the video tag.

Video 8.1: Official SEPOX video demonstrating the features and durability of their outdoor padlocks.

