#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Yaheetech /
- > Yaheetech Padded Zero Gravity Recliner Instruction Manual

#### Yaheetech cca92dc8-a2af-47bc-bb9a-1be765d93325

# Yaheetech Padded Zero Gravity Recliner Instruction Manual

Model: cca92dc8-a2af-47bc-bb9a-1be765d93325

#### Introduction

Thank you for choosing the Yaheetech Padded Zero Gravity Recliner. This manual provides essential information for the safe and effective use, setup, and maintenance of your new outdoor patio chairs. Designed for optimal relaxation, these foldable, adjustable anti-gravity loungers are perfect for backyard, camping, and various outdoor activities. Please read this manual thoroughly before use and retain it for future reference.



Image: A pair of Yaheetech Padded Zero Gravity Recliners, showcasing their design and padded comfort.

# **Safety Information**

To ensure safe operation and prevent injury or damage, please adhere to the following guidelines:

- MAXIMUM WEIGHT CAPACITY: Do not exceed 299 lb (136 kg). Overloading can cause damage to the chair and lead to injury.
- **ASSEMBLY:** Follow assembly instructions carefully. Ensure all parts are correctly installed and secured before use.
- FOLDING & ADJUSTMENT: Use caution when folding and adjusting the backrest to avoid pinching fingers or other body parts. Ensure the locking mechanism is fully engaged when adjusting the recline position.
- **KEEP AWAY FROM WATER & HEAT SOURCES:** While designed for outdoor use, prolonged exposure to extreme weather conditions, direct flames, or excessive heat can damage the fabric and frame.
- STABILITY: Always use the chair on a flat, stable surface to prevent tipping. Do not stand on the chair.
- CHILDREN AND PETS: Keep children and pets away from the chair during folding and unfolding to prevent accidents.

## **Key Features**

The Yaheetech Padded Zero Gravity Recliner is equipped with several features designed for comfort and convenience:

- Adaptive Reclining System: Effortlessly adjust the backrest to your desired angle and securely lock it in place for optimal relaxation.
- **Robust Construction:** Features a heavy-duty painted steel support frame with high hardness and lightweight design, forming a stable triangle structure when unfolded. Capable of holding up to 136 kg (300 lb).
- **Professional Outdoor Material:** The fabric part is made of 600\*300D Oxford cloth, known for its lightweight, high durability, wear-resistance, and weather resistance, making it ideal for outdoor environments.
- **Unfixed Pillow:** A movable pillow is included, allowing you to position it as a headrest or lumbar support for personalized comfort.
- Buckle & Strap for Carry Out: A simple buckle locks the chair in folded mode, and the included strap allows for easy shoulder carrying.
- **Detachable Tray:** Each chair comes with a removable tray featuring cup holders and slots for phones or books, keeping your essentials within reach.



Image: Close-up view of the padded seat, highlighting the comfortable Oxford fabric.



Image: Detail of the elastic cord fastening system, providing flexible support.



Image: The removable cup holder tray, designed to hold beverages, phones, and other small items.



Image: The adjustable and removable headrest pillow for added comfort.

# **Setup and Assembly**

Your Yaheetech Zero Gravity Recliner comes pre-assembled and ready for use. Follow these simple steps to set up your chair:

#### 1. Unfolding the Chair:

Carefully remove the chair from its packaging. Hold the frame and gently pull the chair open until it fully extends. Ensure all legs are firmly on the ground and the chair is stable before sitting.

#### 2. Attaching the Cup Holder Tray:

Locate the detachable cup holder tray. Align the tray's attachment points with the corresponding slots on the side of the chair's armrest. Press firmly until it clicks securely into place.

#### 3. Adjusting the Pillow:

The movable pillow can be slid along the backrest to your preferred height, whether for head support or lumbar support.

#### 4. Using the Carry Strap:

When folding the chair for transport, secure it with the integrated buckle. Attach one end of the shoulder strap to the cup holder and the other end to the iron pipe on the opposite side for easy carrying.



Image: Step-by-step guide on how to fold the chair, attach the buckle, fix the shoulder strap, and carry it.

#### Your browser does not support the video tag.

Video: Official product video demonstrating the features and setup of the Yaheetech Padded Zero Gravity Chair.

# **Operating Instructions**

The zero gravity recliner offers multiple positions for your comfort:

## 1. Adjusting Recline Position:

To recline, gently push back on the armrests while leaning your body backward. The chair will smoothly glide into various positions. To return to an upright position, push forward on the armrests and lean your body forward.

#### 2. Locking the Position:

Once you find your desired recline angle, locate the locking levers (typically on the underside of the armrests). Push the levers down to engage the lock and secure the chair in position. To unlock, pull the

#### 3. Zero Gravity Position:

The zero gravity position elevates your legs above your heart, distributing your body weight evenly and reducing pressure on your spine. Recline fully and lock the chair to achieve this position.

# TWO APPLICABLE WAYS



Image: Visual representation of the chair's adjustable positions: sitting, rest, and full recline (sleep/zero gravity).



Image: Detailed view of the locking mechanism, showing the 'loose' and 'lock' positions for adjusting the recline.

#### **Care and Maintenance**

Proper care will extend the life of your recliner:

- **Cleaning:** Wipe clean with a damp cloth. For stubborn stains, use a mild soap solution and rinse thoroughly. Do not use harsh chemicals or abrasive cleaners.
- Drying: Allow the chair to air dry completely before folding and storing to prevent mildew.
- **Storage:** When not in use for extended periods, especially during harsh weather, fold the chairs and store them in a dry, protected area to prevent wear and tear.
- **Inspection:** Periodically check all bolts, screws, and elastic cords to ensure they are tight and secure. Tighten as needed.

## **Troubleshooting**

If you encounter any issues with your recliner, refer to the following common problems and solutions:

#### · Chair not reclining smoothly:

Check for any obstructions in the reclining mechanism. Ensure the locking levers are fully disengaged. Lubricate moving parts with a silicone-based spray if necessary.

#### • Chair feels unstable:

Ensure the chair is placed on a flat, level surface. Verify that all frame connections are securely tightened. Do not exceed the maximum weight capacity.

#### • Cup holder tray is loose:

Ensure the tray is properly aligned and firmly clicked into its attachment points. If it continues to be loose, inspect the attachment mechanism for any damage.

### • Fabric appears worn or faded:

This can occur with prolonged exposure to direct sunlight and harsh weather. Store the chair indoors or under cover when not in use to minimize exposure.

For issues not covered here, please contact Yaheetech customer support.

## **Product Specifications**

Attribute	Value
Brand	Yaheetech
Model Name	Zero Gravity Recliner
Item Model Number	cca92dc8-a2af-47bc-bb9a-1be765d93325
Color	Gray/Black
Size	26"
Product Dimensions	33"D x 26"W x 43"H

Item Weight	34.5 pounds
Maximum Weight Recommendation	299 Pounds
Material (Fill)	Cotton
Indoor/Outdoor Usage	Outdoor
Is Foldable	Yes
Included Components	Movable Pillow, Detachable Tray



#### ,

# **Warranty and Support**

For warranty information or technical support, please refer to the product packaging or contact Yaheetech customer

service directly. Keep your purchase receipt as proof of purchase.

**Online Support:** Visit the official Yaheetech website for FAQs, product registration, and contact information.

© 2025 Yaheetech. All rights reserved.

#### Related Documents - cca92dc8-a2af-47bc-bb9a-1be765d93325

