

Oakcastle HIFI100

Oakcastle HIFI100 Compact Home Stereo System User Manual

Model: HIFI100

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Oakcastle HIFI100 Compact Home Stereo System. Please read this manual thoroughly before using the device and retain it for future reference.

2. SAFETY INFORMATION

- **Power Source:** Use only the provided power adapter. Ensure the voltage matches the requirements specified on the adapter.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the unit.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the power outlet before cleaning. Use a dry cloth for cleaning.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **CD Player:** Handle CDs by their edges. Do not touch the playing surface.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1x Oakcastle HIFI100 Stereo System
- 1x Remote Control
- 1x Power Adapter
- 1x User Manual (this document)




Image 3.1: Contents of the Oakcastle HIFI100 package, showing the main unit, remote control, power adapter, and user manual.

4. PRODUCT OVERVIEW

4.1 Main Unit

The Oakcastle HIFI100 features a compact design with integrated speakers, a vertical CD player, and a clear LED display. Control buttons are located on the top panel for easy access.



Image 4.1: Front and top view of the Oakcastle HIFI100 stereo system, alongside its remote control. The main unit displays its digital clock and control buttons.

4.2 Remote Control

The included remote control provides full functionality for the HIFI100, allowing you to manage playback, adjust volume, select sources, and access advanced settings from a distance.

Note: The remote control requires 2x AAA batteries (not included).

5. SETUP

5.1 Power Connection

1. Connect the power adapter to the DC IN port on the back of the HIFI100 unit.
2. Plug the power adapter into a suitable wall outlet.

5.2 FM Antenna Connection

For optimal FM radio reception, connect the supplied FM wire antenna to the FM ANT port on the back of the unit. Extend the antenna fully and position it for the best signal.

5.3 Wall Mounting (Optional)

The HIFI100 can be wall-mounted to save space. Ensure you use appropriate screws and anchors for your wall type (not supplied). Consult a professional if you are unsure about wall mounting procedures.



Image 5.1: The Oakcastle HIFI100 stereo system displayed as wall-mounted, demonstrating its space-saving capability.

5.4 Initial Power On

Press the Power button on the unit or remote control to turn on the system. The LED display will illuminate.

6. OPERATING INSTRUCTIONS

6.1 Basic Controls

- **Power:** Press the **POWER** button to turn the unit on or off.
- **Volume:** Use the **VOLUME +/-** buttons on the unit or remote to adjust the sound level.
- **Source:** Press the **SOURCE** button to cycle through available input modes: CD, Bluetooth, FM, AUX.

6.2 CD Player Operation

1. **Loading a CD:** Gently push the CD door upwards to reveal the CD slot. Carefully insert a CD with the label side facing you. The vertical loading mechanism requires a firm but gentle push until the CD clicks into place.
2. **Unloading a CD:** To remove a CD, gently pull it outwards from the slot. Take care not to bend the disc.
3. **Playback:** After loading, the unit will automatically detect and begin playing the CD. Use the

PLAY/PAUSE, STOP, SKIP FORWARD, and SKIP BACKWARD buttons for control.

4. **Repeat/Random Play:** Use the remote control to select repeat modes (single track, all tracks, folder) or random play.
5. **Program Playback:** The remote control allows you to program a sequence of tracks for playback. Refer to the remote control section for detailed instructions.



Image 6.1: The Oakcastle HIFI100 with its vertical CD player mechanism open, ready to accept a disc.

6.3 Bluetooth Operation

1. **Select Bluetooth Mode:** Press the **SOURCE** button until 'Bluetooth' appears on the display. The unit will enter pairing mode, indicated by a flashing Bluetooth icon.
2. **Pairing:** On your Bluetooth-enabled device (e.g., smartphone, tablet), search for available Bluetooth devices. Select 'Oakcastle HIFI100' from the list.
3. **Connection:** Once paired, the Bluetooth icon on the HIFI100 display will become solid, indicating a successful connection. You can now stream audio from your device.

6.4 FM Radio Operation

1. **Select FM Mode:** Press the **SOURCE** button until 'FM' appears on the display.
2. **Auto Scan:** Press and hold the **SCAN** button (or equivalent on remote) to automatically scan and save available FM stations to presets.

3. **Manual Tuning:** Use the **TUNE +/-** buttons to manually adjust the frequency.
4. **Access Presets:** Use the **PRESET +/-** buttons on the remote to navigate through saved stations. The HIFI100 supports up to 20 FM presets.



Image 6.2: The Oakcastle HIFI100 unit displaying 'FM Radio' on its screen, highlighting its radio functionality.

6.5 AUX Input Operation

Connect an external audio device (e.g., MP3 player) to the AUX IN port on the unit using a 3.5mm audio cable (not supplied). Select 'AUX' mode using the **SOURCE** button. Audio from the connected device will play through the HIFI100 speakers.

6.6 Clock and Alarm Settings

The HIFI100 features a digital clock and an alarm function. All clock and alarm settings are controlled via the remote control. Refer to the remote control section of this manual for specific button functions to set the time and configure alarms. You can set the alarm to wake you with a beep, CD playback, or FM radio.

6.7 Equalizer Settings

The HIFI100 offers preset equalizer options to customize your listening experience. These settings are accessible only via the remote control:

- **Preset EQ:** Cycle through 'Classic', 'Rock', 'Pop', 'Jazz', and 'Flat' modes.
- **X-Bass:** Activate or deactivate the X-Bass function for enhanced low-frequency sound.

7. MAINTENANCE

- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents.
- **CD Care:** Keep CDs clean and free from scratches. Store them in their cases when not in use.
- **Ventilation:** Ensure the ventilation openings are not obstructed by dust or debris.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected; Power outlet faulty	Check power adapter connection; Try a different outlet
CD not playing or skipping	CD dirty or scratched; CD inserted incorrectly; Unsupported CD format	Clean or replace CD; Re-insert CD correctly; Ensure CD format is supported (CD, CD-RW, CD-DA, CD-MP3, CD-WMA)
Bluetooth not connecting	Unit not in pairing mode; Device too far; Device already connected to another unit	Ensure HIFI100 is in Bluetooth pairing mode; Move device closer; Disconnect from other Bluetooth devices
Poor FM radio reception	Antenna not connected or poorly positioned	Connect FM antenna; Adjust antenna position for better signal
No sound	Volume too low; Incorrect source selected; Mute activated	Increase volume; Select correct source; Deactivate mute function

9. SPECIFICATIONS

- **Product Dimensions:** 2.56 x 13.78 x 8.66 inches (L x W x H)
- **Item Weight:** 4.3 pounds
- **Connectivity Technology:** Bluetooth
- **Speaker Type:** Stereo
- **Output Power:** 2 x 5W (Total 40W peak)
- **Bluetooth Version:** 5.0
- **Supported CD Formats:** CD, CD-RW, CD-DA, CD-MP3, CD-WMA
- **Supported MP3 Bitrate:** 32-320 kbps
- **Supported WMA Bitrate:** 64-160 kbps
- **FM Presets:** 20
- **Input:** AUX-in (3.5mm)





10. WARRANTY AND SUPPORT



The Oakcastle HIFI100 comes with a 3-year extended warranty. To activate this warranty, please register your product within 30 days of purchase. For detailed warranty terms and conditions, or for technical support, please visit the official Oakcastle website or contact their customer service.

Website: www.oakcastle.co.uk (Example link, please verify actual support URL)



Email: support@oakcastle.co.uk (Example email, please verify actual support email)

Related Documents - HIFI100

 <p>Instruction Guide Oakcastle HIFI100 Slim Micro Hifi Stereo System</p>	<p>Oakcastle HIFI100 Slim Micro Hifi Stereo System Instruction Guide</p> <p>Detailed instruction manual for the Oakcastle HIFI100 Slim Micro Hifi Stereo System, covering setup, operation of radio, CD, Bluetooth, and auxiliary inputs, as well as specifications and safety information.</p>
 <p>Instruction Guide HIFI100 Slim Hifi CD Music System</p>	<p>Oakcastle HIFI100 Slim Hifi CD Music System Instruction Guide</p> <p>Detailed instruction manual for the Oakcastle HIFI100 Slim Hifi CD Music System. Learn how to set up, operate, and use all features including CD playback, Bluetooth connectivity, FM radio, and alarm functions. Includes safety information and specifications.</p>
 <p>OAKCASTLE MP300 USER MANUAL</p>	<p>Oakcastle MP300 User Manual: Your Guide to Portable Music</p> <p>Comprehensive user manual for the Oakcastle MP300 portable MP3 player. Learn about setup, music transfer, playback, Bluetooth connectivity, settings, and troubleshooting.</p>
 <p>OAKCASTLE CD-10 USER MANUAL</p>	<p>Oakcastle CD-10 Portable CD Player User Manual</p> <p>Comprehensive user manual for the Oakcastle CD-10 portable CD player, covering setup, operation, troubleshooting, specifications, and safety information.</p>

	<p>Oakcastle MP200 MP3 Player User Manual</p> <p>Comprehensive user manual for the Oakcastle MP200 MP3 Player, covering setup, controls, music playback, radio, recording, Bluetooth connectivity, settings, specifications, and safety information.</p>
	<p>Oakcastle CD150 Wall CD Player User Manual</p> <p>Comprehensive user manual for the Oakcastle CD150 Wall CD Player, covering setup, operation, features, troubleshooting, and safety guidelines.</p>

Documents - Oakcastle – HIFI100

	<p>[pdf] User Manual Quick Start Guide Instructions</p> <p>Max Cubitt View Product Instructions HiFi100 Compact HiFi Stereo System Oakcastle HIFI100 Manual Collection DEC 2024 oakcastle.co.uk 12 </p> <p>HIFI100 USER MANUAL EN Contents What s In the Box</p> <p>..... 3 Controls And Functions..... 4 Instruct...</p> <p>lang:en score:66 filesize: 1.53 M page_count: 124 document date: 2024-12-09</p>
	<p>Oakcastle HIFI100 Slim Micro Hifi Stereo System Instruction Guide</p> <p>Detailed instruction manual for the Oakcastle HIFI100 Slim Micro Hifi Stereo System, covering setup, operation of radio, CD, Bluetooth, and auxiliary inputs, as well as specifications and safety information.</p> <p>lang:fr score:63 filesize: 573.59 K page_count: 23 document date: 2023-10-06</p>



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide

Untitled View Product Instructions HiFi100 Compact HiFi Stereo System Oakcastle HIF150 Manual Website Collection oakcastle co uk 2024 10 |||

HIFI150 USER MANUAL EN Contents What s In the Box

..... 3 Controls And
Functions..... 4 Instruct...
lang:en **score:50** filesize: 974.02 K page_count: 84 document date: 2024-10-21



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide

Untitled HIFI150 Oakcastle View Product Instructions Avant de brancher le HIFI 150 sur secteur assurez vous que la TENSION mentionnée bloc d alimentation correspond à celle votre région HiFi100 Compact HiFi Stereo System HIF150 Manual Website Collection 2025 oakcastle co uk 01 |||

HIFI150 USER MANUAL EN Contents What s In the Box

..... 3 Controls And
Functions..... 4 Instruct...
lang:en **score:39** filesize: 988.98 K page_count: 84 document date: 2025-01-16



[\[pdf\]](#) User Manual Instructions

PowerPoint Presentation Max Cubitt International HiFi100 Compact HiFi Stereo System Oakcastle TT100 Manual Collection Nov 2024 oakcastle co uk 11 |||

TT100 Classic Turntable USER MANUAL EN Contents What s In the Box

..... 3 Controls And
Functions.....
lang:en **score:36** filesize: 1.24 M page_count: 66 document date: 2024-11-19



[\[pdf\]](#) Borchure Catalog

Untitled OAKCASTLE 2024 9 set — Oakcastle products are designed with user convenience in mind offering a seamless experience across their range of electronics Brochure August majority co uk 09 |||

OAKCASTLE Product Catalogue. 2024 Contents. An intro to Oakcastle The Oakcastle Promise Speakers D ... Analogue connections, there will be a Oakcastle Music System to suit any audiophile. 17 OAKCASTLE **HIFI100**. RRP 69.95 / 79.95 The compact Hi-Fi Stereo System packs a punch with its 40-watt 2.0 stereo...
lang:en **score:32** filesize: 5.16 M page_count: 27 document date: 2024-09-06




[\[pdf\]](#) User Manual Quick Start Guide Instructions

PowerPoint Presentation Max Cubitt HIFI100 Advertencias de Seguridad para Niños Uso del Producto
Destinado a adultos manténgalo fuera alcance los niños Advertencia sobre Baterías 91Jhlmj1TnL ref dp
product quick view m media amazon images I |||

HIFI100 USER MANUAL EN Contents What s In the Box


..... 3 Controls And
Functions..... 4 Instruct...
lang:en **score:32** filesize: 530.81 K page_count: 28 document date: 2024-11-11



[Oakcastle HIFI100 Slim Hifi CD Music System Instruction Guide](#)

Detailed instruction manual for the Oakcastle HIFI100 Slim Hifi CD Music System. Learn how to set up, operate, and use all features including CD playback, Bluetooth connectivity, FM radio, and alarm functions. Includes safety information and specifications.

lang:es **score:26** filesize: 1.4 M page_count: 23 document date: 2024-01-18



[\[pdf\]](#) User Manual

User Manual Oakcastle CD200 Portable CD Player Boombox I Bluetooth FM Radio USB Aux Playback 2
0 Stereo Sound 15hr Battery Playtime Headphone Jack Simple Controls LED Display Black Amazon co
uk Electronics Photo 81rFQgsqD3L m media amazon images |||

Box Contents 1. 1x HiFi100 2. 1x Remote Control 3. 1x Mains Power Cable

<https://www.majority.co.uk/wp-content/uploads/2022/11/HIFI100-Giftbox-EU.png>

Controls and Functions Top View/Control Buttons <https://www.majority.co.uk/wp-content/uploads/2022/11/Hifi-100-Top.jpg> 1. Volume down - button 2....

lang:en **score:24** filesize: 357.92 K page_count: 11 document date: 2023-01-04