Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- OneBom /
- > ONEBOM Roku Remote Cover User Manual

OneBom Roku Remote Cover (B0CX5DS3MV)

ONEBOM Roku Remote Cover User Manual

Brand: OneBom | Model: Roku Remote Cover (B0CX5DS3MV)

INTRODUCTION

Thank you for choosing the ONEBOM Cat Ears Design Silicone Skin Case for your Roku remote. This manual provides essential information on how to set up, use, and maintain your new remote cover, ensuring optimal protection and enhanced usability for your device. Our covers are designed to offer superior grip, prevent damage from drops, and make your remote easier to find.

PRODUCT FEATURES


- Easy Remote Identification: Available in various colors, including glow-in-the-dark options (Yellow & Pink in this pack), making your remote simple to spot in any lighting condition.
- Fun Cat Ears Design: Adds a unique and playful aesthetic to your remote, appealing to users of all ages.
- Unobstructed Volume Key Design: Features a precise opening for the volume buttons, allowing for
 easy and accurate adjustment without interference.
- Enhanced Grip and Texture: The silicone material and fan-shaped pattern provide a comfortable, non-slip grip, reducing the likelihood of accidental drops.
- Full Access: Custom cutouts ensure full access to all ports, buttons, and functions of your Roku remote.
- Anti-Lost Lanyard: Includes a silicone lanyard that can be worn around the wrist or used to hang the remote, further preventing loss.



The ONEBOM remote covers are designed to glow in the dark, making your remote easy to locate even in low-light conditions. This image shows the yellow and pink covers demonstrating their luminous property.



This cover features a unique fan-shaped pattern for enhanced grip, a clear signal window to ensure uninterrupted remote functionality, and is made from durable, washable silicone.



An intelligent design ensures that all essential buttons, including the volume keys, remain fully accessible and unobstructed when the cover is installed.

COMPATIBILITY

The ONEBOM remote cover is designed for broad compatibility with various Roku remote models. It fits all Roku TV brands such as TCL, Hisense, onn, and Roku, as well as replacement remotes for Roku streaming media players including Roku Express, Roku Streaming Stick, official Roku Voice Remote, Roku Premiere, Roku 2, Roku 3, and Roku 4.

Important Note:

This cover is NOT compatible with Roku Ultra and Roku Pro remotes that feature a headphone jack.

UNIVERSAL COVERS FOR ROKU REMOTE



The ONEBOM remote cover is designed for universal compatibility with a wide range of Roku TV remotes and streaming stick remotes. Please note that it is not compatible with Roku Ultra or Roku Pro remotes that feature a headphone jack.

SETUP (INSTALLATION)

Installing your ONEBOM remote cover is a simple process:

- 1. Ensure your Roku remote is clean and free of dust or debris.
- 2. Gently slide the remote into the silicone cover, starting from the top (cat ears end).
- 3. Adjust the cover to ensure all buttons and the infrared signal window are properly aligned and unobstructed.
- 4. Attach the included silicone lanyard to the designated loop at the bottom of the cover if desired.

Watch this official video from Onebom Supplier to see how easily the remote cover can be installed and how it helps prevent remote loss and damage.

OPERATING THE GLOW FEATURE

The glow-in-the-dark feature of your ONEBOM remote cover requires activation through light exposure:

- 1. Expose the silicone cover to a strong light source, such as direct sunlight or a bright lamp, for approximately 15-20 minutes.
- 2. After exposure, take the remote to a dark environment to observe the fluorescence.

Please note that due to technological limitations of silicone materials, the glow may not be permanent and will slowly fade over time, requiring re-exposure to light for reactivation. The intensity and duration of the glow depend on the light absorption.



WARM TIPS:

They need to absorb light energy, such as sunlight, ultraviolet light, fluorescent lamps, etc., The remote control cover can glow in the dark by absorbing this light energy. The more light energy absorbed, the brighter it becomes in the dark. However, it is worth noting that due to the small cover, the luminous time is also limited.

To activate the glow-in-the-dark feature, expose the silicone cover to strong light, such as sunlight or a lamp, for 15-20 minutes. The cover will then slowly release fluorescence in the dark.

MAINTENANCE

To keep your ONEBOM remote cover clean and in optimal condition:

- The silicone material can be easily washed by hand with mild soap and water.
- · Alternatively, you can wipe the cover with a damp cloth or an alcohol wipe to remove dirt and grime.
- Ensure the cover is completely dry before re-installing it on your remote.

TROUBLESHOOTING

If your remote cover is not glowing as expected:

- Ensure the cover has been exposed to strong light for the recommended 15-20 minutes.
- Test the glow in a completely dark room, as even minimal ambient light can diminish the perceived glow.
- Remember that the glow is not perpetual and requires re-charging with light.

SPECIFICATIONS

Attribute	Detail
Material	Silicone
Color (This Pack)	Glow Yellow & Glow Pink
Form Factor	Cover
Item Weight	1.76 ounces
Package Dimensions	6.81 x 4.57 x 1.02 inches

WARRANTY AND SUPPORT

ONEBOM stands behind the quality of its products. This silicone Roku remote cover comes with **a_ifetime Replacement Warranty**.

If you encounter any issues or have questions regarding your product, please do not hesitate to contact our customer support. We are committed to providing reliable after-sales service and ensuring your satisfaction.

For support, please refer to the contact information provided with your purchase or visit the official OneBom store on Amazon: OneBom Amazon Store