

Garvee EZ06

Garvee Espresso Coffee Machine User Manual

Model: EZ06

1. INTRODUCTION

Thank you for choosing the Garvee Espresso Coffee Machine with Grinder. This semi-automatic espresso maker is designed to provide a professional coffee experience at home, featuring a 20-bar pump, integrated conical burr grinder, and PID temperature control. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new appliance.



Image: The Garvee Espresso Coffee Machine, showcasing its sleek design with integrated grinder and steam wand, alongside a freshly prepared latte.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always connect the appliance to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.

- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot liquids.
- Do not use the appliance for other than intended use.
- Avoid contact with moving parts.
- The steam wand and hot water dispenser can reach high temperatures. Use caution to avoid burns.

3. PRODUCT COMPONENTS

Familiarize yourself with the various parts of your Garvee Espresso Coffee Machine.



Image: Diagram showing the main components of the Garvee Espresso Coffee Machine, including the removable water tank, tamper, milk jug, needle, cleaning brush, single filter cup, and double filter cup.

Included Components:

- 1 x Garvee Coffee Machine
- 1 x Water Tank (2.8L)
- 1 x Tamper
- 1 x Milk Jug
- 1 x Needle (for cleaning)
- 1 x Cleaning Brush
- 2 x Cups (likely referring to filter cups, not drinking cups)

4. INITIAL SETUP

Before first use, follow these steps to prepare your machine.

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.
2. **Placement:** Place the machine on a stable, flat, heat-resistant surface, away from walls and heat sources. Ensure adequate ventilation.
3. **Clean Components:** Wash the water tank, portafilter, filter baskets, and milk jug with warm soapy water. Rinse thoroughly and dry.
4. **Fill Water Tank:** Fill the 2.8L removable water tank with fresh, cold filtered water up to the MAX line. Ensure the tank is properly seated in its position.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.
6. **Initial Rinse Cycle:** Before brewing coffee, perform an initial rinse cycle to prime the pump and clean internal components. Follow the instructions in the 'First Use' section of the operation guide.



Image: The Garvee Espresso Machine highlighting its detachable 2.8L water tank, removable drip tray with water level indicator, and a space-saving toolbox for accessories.

5. OPERATING INSTRUCTIONS

This section guides you through the process of making espresso and frothing milk.

5.1. Grinding Coffee Beans

The integrated conical burr grinder offers 30 adjustable grinding sizes for optimal extraction.

1. **Add Beans:** Pour fresh whole coffee beans into the bean hopper.
2. **Select Grind Size:** Rotate the grind size selector to choose your desired fineness. Finer grinds (lower numbers) are for slower extraction and stronger espresso, while coarser grinds (higher numbers) are for faster extraction. A setting between 8-9 is often recommended for espresso.
3. **Grind:** Place the portafilter under the grinder chute. Press the 'GRIND' button or activate the grinding mechanism (refer to specific model controls). The machine supports hand-free grinding.



Image: Illustration of the 30 optional grinding settings, showing coarse, medium, and fine grinds, and how they relate to extraction speed.

Integrated Precision- Conical Burr Grinder



Conical Burr Grinder



Hand-free Grinding



Anti-Static Grinding

Image: Close-up view of the integrated conical burr grinder, demonstrating the grinding process into the portafilter.

5.2. Brewing Espresso

The machine features a 20-bar professional pump and double PID temperature control for optimal extraction.

1. **Pre-heat:** Turn on the machine. Allow it to pre-heat for at least 30 seconds (ThermoJet technology) until the indicator lights signal readiness. Pre-heating cups on the cup warming tray is recommended.
2. **Dose & Tamp:** Fill the single (0.49-0.56 oz) or double (0.7-0.78 oz) filter cup with freshly ground coffee. Tamp the coffee firmly and evenly to the 'Max' line using the provided tamper. Wipe any excess grounds from the rim.
3. **Insert Portafilter:** Insert the portafilter into the group head and twist firmly to lock it into place.
4. **Place Cup:** Place your espresso cup(s) under the portafilter spouts.
5. **Brew:** Select 'SINGLE' or 'DOUBLE' shot button. The machine will automatically brew the programmed amount of espresso. For manual control, refer to the manual-shot mode (up to 13.5 oz).



1 Add coffee beans into container



2 Pre-heat before every first extraction



3 Set the grind size to 8-9



4 11-13 g for single cup, 16-18 g for double cup



5 Tamp to the Max line for filter



6 Espresso is done



7 Switch the knob to steam



8 Making milk foam

Image: An 8-step visual guide illustrating the espresso making process, from adding beans to frothing milk.

Precise Temperature



Image: Close-up of the machine's control panel, highlighting the Double PID temperature control for precise and consistent brewing temperatures (201.2°F $\pm$ 35.6°F).

58mm Brewing Group Head

professional grade extraction caliber allows you to extract more flavor from your favorite coffee grounds.



Image: Detailed view of the 58mm brewing group head and portafilter, emphasizing its professional-grade extraction capabilities.

5.3. Milk Frothing

The adjustable stainless steel steam wand creates rich microfoam for lattes and cappuccinos.

1. **Prepare Milk:** Fill the milk jug with cold milk (dairy or non-dairy). Do not fill more than halfway.
2. **Activate Steam:** Turn the knob to the steam setting. Wait for the steam indicator light to illuminate, indicating the machine has reached steaming temperature.
3. **Purge Steam Wand:** Briefly open the steam valve to purge any condensed water from the wand. Close the valve.
4. **Froth Milk:** Immerse the tip of the steam wand just below the surface of the milk. Open the steam valve fully. Angle the jug to create a swirling motion. As the milk expands, lower the jug slightly to keep the tip just below the surface.
5. **Stop Steaming:** Once the milk has reached the desired temperature and texture, close the steam valve and remove the jug.
6. **Clean Wand:** Immediately wipe the steam wand with a damp cloth to remove any milk residue. Briefly purge the wand again to clear any internal milk.

Powerful Steam Wand



Image: Hands demonstrating the use of the powerful steam wand to quickly turn milk into silky microfoam, with examples of latte art.

5.4. Cup Warming

The top surface of the machine acts as a cup warming tray, helping to preserve the temperature and aroma of your espresso.

- Place your espresso cups or mugs on the designated warming area on top of the machine.
- Allow cups to warm while the machine pre-heats for optimal results.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your Garvee Espresso Machine.

6.1. Daily Cleaning

- **Drip Tray:** Empty and clean the removable drip tray daily. The tray has a water level indicator that floats up when full.

- **Portafilter & Filter Baskets:** After each use, remove spent coffee grounds and rinse the portafilter and filter baskets under hot water.
- **Steam Wand:** As mentioned in the operation section, wipe the steam wand immediately after each use and purge it to prevent milk residue buildup. The removable frothing nozzle simplifies cleaning.
- **Group Head:** Wipe the group head with a damp cloth to remove any coffee grounds.

6.2. Weekly Cleaning

- **Water Tank:** Empty and clean the water tank with warm soapy water. Rinse thoroughly.
- **Grinder:** Periodically clean the grinder burrs using the provided cleaning brush. Refer to the manual for specific instructions on accessing the burrs if necessary.

6.3. Descaling

Depending on water hardness, descaling should be performed every 2-3 months to prevent mineral buildup. Use a commercial descaling solution designed for coffee machines and follow the product's instructions. Refer to the full product manual for detailed descaling procedures.

7. TROUBLESHOOTING GUIDE

This section addresses common issues you might encounter with your Garvee Espresso Machine.

Problem	Possible Cause	Solution
No coffee dispenses / Machine beeps	Water tank empty or not properly seated; Pump not primed; Clogged portafilter/group head; Machine malfunction.	Ensure water tank is full and correctly inserted. Perform an initial rinse cycle to prime the pump. Clean portafilter and group head. If problem persists, contact customer service.
Coffee brews too slowly or not at all	Coffee grind too fine; Too much coffee in filter basket; Coffee tamped too hard; Clogged filter basket.	Adjust grind size to be coarser. Reduce coffee dose. Tamp with less pressure. Clean filter basket thoroughly.
Coffee brews too quickly / Weak coffee	Coffee grind too coarse; Not enough coffee in filter basket; Coffee tamped too lightly.	Adjust grind size to be finer. Increase coffee dose. Tamp with more pressure.
No steam from wand	Steam wand clogged; Not enough water in tank; Machine not at steaming temperature.	Clean steam wand with needle. Ensure water tank is full. Wait for steam indicator light.
Water leaking from machine	Water tank not seated correctly; Drip tray full; Seal issues.	Ensure water tank is firmly in place. Empty drip tray. If leaking persists, contact customer service.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	Garvee

Feature	Specification
Model Name	EZ06
Color	Grey
Product Dimensions	12.59"D x 12.59"W x 13.5"H
Special Features	Integrated Coffee Grinder, Removable Tank, Cup Warmer, Double PID Control
Coffee Maker Type	Espresso Machine (Semi-Automatic)
Filter Type	Reusable
Specific Uses	Espresso, Mocha, Latte, Cappuccino
Water Tank Capacity	2.8 Liters
Pump Pressure	20 Bar
Grinding Sizes	30 Optional Sizes
Heating System	ThermoJet (under 30 seconds)
Item Weight	25.7 pounds
UPC	198290840946

9. WARRANTY AND SUPPORT

Garvee is committed to providing excellent customer service and support for your product.

- **Warranty:** This product comes with a 2-year warranty.
- **Replacement Policy:** A 90-day free replacement offer is available for eligible issues.
- **Technical Support:** Lifetime technical support is provided.
- **Customer Service:** Access to our professional 24-hour customer service team for any support needed.

For warranty claims, technical assistance, or customer service inquiries, please refer to the contact information provided on the Garvee official website or your purchase documentation.

© 2024 Garvee. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question