

[Manuals.plus](#) /

> [Vornado](#) /

> Vornado Airbar 6 Tower Fan and Horizontal Air Circulator User Manual

Vornado FA1-0213-06

Vornado Airbar 6 Tower Fan and Horizontal Air Circulator User Manual

Brand: Vornado
Model: FA1-0213-06

INTRODUCTION

The Vornado Airbar 6 is a versatile air circulator designed to provide powerful and adaptable airflow for medium to large spaces. Unlike typical tower fans, the Airbar 6 offers both vertical and horizontal operation, allowing you to optimize air circulation based on your specific needs. Its innovative magnetic base system enables easy conversion between modes without the need for tools, ensuring a hassle-free experience. With intuitive touch controls and a convenient omnidirectional remote, you can effortlessly manage its three speed settings to create a comfortable environment.



Image: The Vornado Airbar 6 in its horizontal configuration, showcasing its sleek design and accompanying remote control.

SETUP

The Vornado Airbar 6 features a magnetic base system for easy assembly and conversion between vertical (tower) and horizontal (Airbar) orientations. No tools are required for setup.

Included Components:

- Airbar 6 Unit
- Magnetic Base System
- Remote Control
- Owner's Guide

Assembly Instructions:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Choose Orientation:** Decide whether you will use the Airbar 6 in its vertical (tower) or horizontal (Airbar) position.
3. **Attach Base:** The magnetic base system easily snaps into place. Align the base pieces with the corresponding magnetic points on the Airbar 6 unit and allow them to connect securely. Ensure the unit is stable in your chosen orientation.
4. **Placement:** Place the Airbar 6 on a stable, level surface, away from obstructions.
5. **Power Connection:** Plug the power cord into a standard electrical outlet.

Airbar™ to Tower in a snap.

Vertical / Horizontal
Design

Magnetic
Base

Full 360°
Range Tilt



Image: Demonstrates the magnetic base system allowing easy conversion of the Airbar 6 from a vertical tower fan to a horizontal air circulator.

OPERATING INSTRUCTIONS

The Vornado Airbar 6 offers intuitive touch controls on the unit and an omnidirectional RF remote for convenient operation.

Controls:

- **Power Button:** Press to turn the unit On or Off.
- **Speed Settings:** Cycle through 3 distinct speed settings (Low, Medium, High) using the speed control buttons on the unit or remote.
- **Remote Control:** The omnidirectional RF remote allows control from anywhere in the room. It features a magnetic cradle for convenient storage on the unit.




Image: A hand demonstrating the use of the touch controls on the Airbar 6 unit and the magnetic RF remote control.

Airflow Direction:

The Airbar 6 features full-range tilt, allowing you to direct airflow precisely where needed. In horizontal mode, it provides wide, low-profile comfort, ideal for floor-level circulation. In vertical mode, it functions as a tower fan, circulating air throughout the room.

Whole room circulation.



Image: The Vornado Airbar 6 positioned horizontally, demonstrating its low-profile design for targeted airflow.

Official Product Video:

Video: An introduction to Vornado products, showcasing their design and engineering philosophy. This video provides a general overview of the brand's commitment to comfort and quality.

MAINTENANCE

Regular cleaning of your Vornado Airbar 6 will help maintain its performance and extend its lifespan.

Cleaning Instructions:

1. **Disconnect Power:** Always unplug the unit before cleaning.
2. **Exterior Cleaning:** Use a soft, damp cloth to wipe down the exterior surfaces of the Airbar 6. Do not use harsh chemicals or abrasive cleaners.
3. **Air Inlet/Outlet:** Use a vacuum cleaner with a brush attachment to remove any dust or debris from the air inlet and outlet grilles.
4. **Storage:** If storing the unit for an extended period, cover it to protect from dust and store in a cool, dry place.

TROUBLESHOOTING

If your Vornado Airbar 6 is not operating as expected, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Reduced airflow.	Dust or debris accumulation.	Clean the air inlet and outlet grilles as described in the Maintenance section.
Unusual noise.	Obstruction or loose part.	Unplug the unit and inspect for any foreign objects or loose components. If the noise persists, contact Vornado customer support.
Remote control not working.	Dead batteries or obstruction.	Replace the remote control batteries. Ensure there are no obstructions between the remote and the unit.

If the problem persists after attempting these solutions, please contact Vornado customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions	12.5 x 12.5 x 44.5 inches
Item Weight	9 pounds
Manufacturer	Vornado
ASIN	B0CX6Z2BHT
Country of Origin	China
Item Model Number	FA1-0213-06
Color	Black
Material	Plastic, Metal
Cooling Method	Fan
Speed Settings	3 Speeds
Controls	Touch Control, RF Remote

Feature	Detail
Included Components	Magnetic Base System, Owner's Guide, Remote, Airbar 6
Batteries Required	Yes (for remote)
Assembly Required	Yes
Number of Pieces	4

WARRANTY AND SUPPORT

Warranty Information:

The Vornado Airbar 6 comes with a **5 Year Manufacturer Limited Warranty**. This warranty covers defects in material and workmanship under normal household use. For specific terms and conditions, please refer to the Owner's Guide included with your product.

Customer Support:

For any questions, troubleshooting assistance, or warranty claims, please contact Vornado customer support. Products are designed and supported in Andover, KS.

You can also refer to the official User Manual (PDF) for detailed information:

[Download User Manual
\(PDF\)](#)