

[Manuals.plus](#) /

› [ZURU](#) /

› ZURU MAX-Dino Adventure US-Series 1-Egg Capsule (284 pcs) Instruction Manual

ZURU 83159-V2

ZURU MAX-Dino Adventure US-Series 1-Egg Capsule Instruction Manual

Model: 83159-V2

INTRODUCTION

Welcome to the exciting world of ZURU MAX-Dino Adventure! This 1-Egg Capsule set provides 284 pieces for building an adventurous dinosaur-themed playset, including a T-Rex and a specialized vehicle. This manual will guide you through the assembly process, operation, and care of your new ZURU MAX-Dino Adventure set.



The ZURU MAX-Dino Adventure 1-Egg Capsule set, featuring the large green egg packaging, an assembled green and grey adventure truck, an orange and brown T-Rex figure, and a small grey radar dish accessory.

SAFETY INFORMATION

WARNING: Choking hazard - Small pieces. Not for children under 3 years. Adult supervision is recommended during assembly and play, especially for younger children, to ensure all small parts are handled safely.

WHAT'S IN THE BOX

Your ZURU MAX-Dino Adventure 1-Egg Capsule contains all the necessary components to build your dinosaur adventure scene. Carefully open the egg capsule to reveal:

- Assorted building blocks (284 pieces)
- T-Rex dinosaur figure components
- Vehicle components

- Accessory components (e.g., radar dish)
- Instruction Manual (this document)



ZURU

MAX

DINO
ADVENTURE

T-rex Attack



BRICK BRANDS COMPATIBLE WITH MAJOR BRICK BRANDS

The back of the ZURU MAX-Dino Adventure egg capsule, illustrating the main components of the set: the adventure truck and the T-Rex dinosaur figure.

SETUP AND ASSEMBLY

Follow these steps to assemble your ZURU MAX-Dino Adventure set:

1. **Unpack Components:** Carefully open the egg capsule and remove all plastic bags containing the building blocks. Lay them out on a clean, flat surface.
2. **Sort Pieces:** For easier assembly, sort the blocks by color, size, or type. This will help you locate specific pieces as you follow the instructions.
3. **Follow Instructions:** Refer to the detailed building instructions provided within the capsule. Each step will show which pieces are needed and how they connect.
4. **Assemble the Vehicle:** Begin by constructing the base of the adventure truck, then add the cabin, wheels, and the rear cargo section. Ensure all connections are firm.
5. **Assemble the T-Rex:** Build the T-Rex figure by connecting its body parts, legs, arms, and head as indicated in the instructions.
6. **Assemble Accessories:** Construct any additional accessories, such as the radar dish, and attach them to the vehicle or place them in the play area as desired.
7. **Verify Assembly:** Once all components are assembled, double-check that all pieces are securely attached and that the models are stable.

OPERATING AND PLAY

Once assembled, your ZURU MAX-Dino Adventure set is ready for imaginative play. The vehicle features rolling wheels, allowing it to be moved across surfaces. The T-Rex figure is designed for interactive play, encouraging storytelling and creative scenarios.

- **Vehicle Movement:** Gently push or pull the adventure truck to make it roll. Avoid excessive force to prevent damage to the wheels or connections.
- **Dinosaur Posing:** The T-Rex figure may have articulated parts (e.g., jaw, legs) allowing for various poses. Handle these parts carefully to avoid breakage.
- **Interactive Play:** Use the truck and dinosaur together to create rescue missions, exploration adventures, or any other imaginative scenarios.



A child engaging in play with the assembled ZURU MAX-Dino Adventure truck and T-Rex figure, demonstrating the interactive nature of the set.



Two children collaborating in play with the ZURU MAX-Dino Adventure set, highlighting its suitability for shared imaginative experiences.

MAINTENANCE

To ensure the longevity of your ZURU MAX-Dino Adventure set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the blocks and figures with a soft, dry cloth to remove dust. For stubborn dirt, a slightly damp cloth can be used, but ensure the pieces are thoroughly dried afterward. Do not submerge in water or use harsh chemicals.
- **Storage:** Store the set in a cool, dry place away from direct sunlight and extreme temperatures. The original egg capsule can be used for convenient storage of all pieces.
- **Handling:** Handle the assembled models with care. Avoid dropping them or applying excessive force, which could cause pieces to detach or break.

TROUBLESHOOTING

If you encounter any issues with your ZURU MAX-Dino Adventure set, consider the following:

- **Missing Pieces:** Double-check all packaging and the play area. If a piece is genuinely missing, contact ZURU customer support.
- **Difficulty Connecting Blocks:** Ensure you are using the correct pieces as indicated in the instructions. Apply firm, even pressure when connecting blocks. If a block is unusually difficult to connect, check for any debris in the studs or holes.
- **Models Falling Apart:** This usually indicates that pieces are not fully pressed together. Re-examine the connections and ensure they are secure.

SPECIFICATIONS

Product Name	ZURU MAX-Dino Adventure US-Series 1-Egg Capsule
Model Number	83159-V2
ASIN	B0CX7P9R9D
Number of Pieces	284 pcs
Product Dimensions	9.25 x 7.72 x 12.87 inches
Item Weight	3.2 ounces
Manufacturer Recommended Age	6 years and up
Manufacturer	ZURU
Release Date	January 1, 2024

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ZURU MAX-Dino Adventure set, please contact ZURU customer service. While specific warranty details are not provided in this manual, ZURU is committed to product quality and customer satisfaction. Please retain your proof of purchase for any inquiries. You can find more information and contact details on the official ZURU website or through the retailer where you purchased the product.

© 2024 ZURU. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question