

[Manuals.plus](#) /

› [Gudsunal](#) /

› Gudsunal Induction Hob User Manual

Gudsunal IC3616-EU-2

Gudsunal Induction Hob User Manual

Model: IC3616-EU-2

INTRODUCTION

Thank you for choosing the Gudsunal Induction Hob. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read it thoroughly before use and keep it for future reference.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the appliance is properly grounded.
- Do not immerse the appliance in water or other liquids.
- Keep children away from the hob during operation.
- Use only induction-compatible cookware.
- Do not place metallic objects on the hob surface when not in use.
- Disconnect from power supply before cleaning or maintenance.
- Be aware of residual heat after use.
- Do not operate if the ceramic glass plate is cracked or broken.

Mehrfacher Sicherheitsschutz



Figure 1: Multiple Safety Features. The hob includes a child lock, residual heat indication, automatic safety cut-off, and a pan detector for enhanced user safety.

PRODUCT OVERVIEW

The Gudsunal Induction Hob features two recessed burners, offering efficient and precise cooking. Its sleek design integrates seamlessly into modern kitchens.



Figure 2: Gudsunal Induction Hob. A black ceramic glass surface with two induction zones and integrated touch controls.

Key Features:

- **Dual Burners:** Total 3600W power (1500W and 2100W individual burners).
- **9 Power Levels:** Precise temperature control for various cooking needs.

- **Booster Function:** Rapid heat rise for 5 minutes on both burners.
- **Timer Function:** For controlled cooking duration and automatic shut-off.
- **Low Power Continuous Heating:** Prevents overheating and preserves food texture at lower power levels (1-3).
- **Safety Features:** Child lock, residual heat indication, automatic safety cut-off, pan detector.
- **Durable Surface:** Advanced shatterproof ceramic glass plate.

SETUP AND INSTALLATION

The Gudsunal Induction Hob is designed for drop-in installation. Ensure proper ventilation and electrical connections are made by a qualified professional.

Unpacking and Contents:

Carefully unpack all components and check against the list below. If any items are missing or damaged, contact customer support.

Was ist in der Box



 Kochfeld	 Benutzerhandbuch	 Ausschnittgrößeplatte
	 Sicherheitstipps	 Dichtband
	 Installationskit	 Gummifuß *4

Figure 3: What's in the Box. The package includes the cooktop unit, user manual, cutout size board, safety tips, sealing tape, installation kit, and rubber feet.

- Gudsunal Induction Hob Unit
- User Manual
- Cutout Size Board
- Safety Tips Sheet
- Sealing Tape
- Installation Kit
- Rubber Feet (x4)

Dimensions and Cutout:

Ensure your countertop cutout matches the specified dimensions for a secure fit.

- Product Size: 29 cm (W) x 52 cm (L) x 4.8 cm (H)
- Cutout Size: 27 cm (W) x 49 cm (L)



Figure 4: Product and Cutout Dimensions. Essential measurements for proper installation.

Electrical Connection:

The hob operates on 220-240V and requires a dedicated electrical circuit. Consult a certified electrician for installation to ensure compliance with local electrical codes.

OPERATING INSTRUCTIONS

Familiarize yourself with the touch controls and functions for optimal cooking performance.

Control Panel:



Figure 5: Control Panel. Touch-sensitive controls for power, temperature, timer, and safety features.

Basic Operation:

1. **Power On:** Touch the power button to activate the hob.
2. **Select Burner:** Choose the desired cooking zone.
3. **Adjust Power Level:** Use the '+' and '-' buttons to select one of 9 power levels.
4. **Booster Function:** Touch the 'B' button for a rapid 5-minute power boost.
5. **Timer Setting:** Use the timer controls to set a cooking duration. The hob will automatically shut off when the timer expires.
6. **Child Lock:** Activate the child lock to prevent accidental operation.
7. **Pan Detection:** The hob will only operate when an induction-compatible pan is placed on the cooking zone. If no pan is detected, it will automatically stop.

Low Power Continuous Heating:

This feature automatically activates when power levels 1-3 are selected. It maintains a consistent low temperature, ideal for delicate tasks like melting chocolate or simmering sauces, preventing scorching and preserving food quality.

Kontinuierliche Niedrigleistungsheiztechnologie

Die Textur und der Geschmack der Zutaten besser bewahren, während Energie gespart wird.




Figure 6: Low Power Continuous Heating Technology. Ensures stable, gentle heat for delicate cooking.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your induction hob.

- Always ensure the hob is cool and disconnected from the power supply before cleaning.
- Wipe the ceramic glass surface with a soft cloth and mild detergent. Avoid abrasive cleaners or scouring pads.
- For stubborn stains, use a ceramic hob scraper.
- Clean the control panel gently with a damp cloth.
- Do not use steam cleaners.

TROUBLESHOOTING

If you encounter issues with your hob, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hob does not turn on.	No power supply; Child lock activated.	Check power connection; Deactivate child lock.
No heat from burner.	Non-induction compatible cookware; No pan detected.	Use induction-compatible cookware; Place pan correctly on zone.
Hob makes buzzing noise.	Normal operation with certain cookware; Fan noise.	This is normal for induction hobs and certain types of cookware.
Error code displayed.	Internal fault; Overheating.	Refer to specific error code in full manual (if available) or contact support. Turn off and restart.

SPECIFICATIONS

Attribute	Detail
Brand	Gudsunal
Model Number	IC3616-EU-2
Type	Induction Hob, 2 Burners
Total Wattage	3600 W
Individual Burner Wattage	1500 W, 2100 W
Voltage	220-240 V
Power Levels	9
Product Dimensions (L x W x H)	52 x 29 x 4.8 cm (5.8 cm including base)
Cutout Dimensions (L x W)	49 x 27 cm
Item Weight	4.3 kg
Material	Ceramic Glass
Installation Method	Drop-In
Special Features	Automatic Safety Cutting, Pan Sensor, Child Lock, Continuous Low Power Heating Technology, Residual Heat Indication, Booster Function, Timer

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase documentation or visit the official Gudsunal website. Keep your proof of purchase for warranty claims. Service contact information found on the box:service@gudsunalkitchen.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question