Hatteker ht608

Hatteker Professional Hair Clippers and Trimmer Set

Model: HT-608

User Manual

Safety Information

Please read all instructions carefully before using the product.

- **Caution:** Keep away from eyes.
- Do not ingest or inhale small parts.
- Recommended for use by adults or under adult supervision.
- Do not immerse the charging unit in water.
- Ensure the product is completely dry before charging.
- Keep out of reach of children.

What's Included

Your Hatteker Professional Grooming Kit includes the following components:



Image: The complete Hatteker Professional Hair Clippers and Trimmer Set, showcasing both the large barber clipper and the smaller multi-function trimmer, along with various guide combs, charging cables, and additional accessories.

- 1 x Large Barber Clipper
- 1 x Small Multi-function Hair Trimmer
- 3 x Additional Cutter Heads for Trimmer (Nose/Ear, Body, Detailed Trimmer Head)
- 13 x Guard Combs (4 for hair trimmer: 1/3/5/7mm; 8 for hair clipper: 1/8", 1/4", 3/8", 1/2", 5/8", 3/4", 7/8", 1"; 1 for body trimmer: 3-6-9mm)
- 2 x USB Cables
- 1 x Cleaning Brush
- 1 x Barber Cape
- 1 x Storage Bag
- User Manual

Your browser does not support the video tag.

Video: An overview of the Hatteker Professional Hair Clippers and the various components included in the set, demonstrating its comprehensive nature.

Product Features

- **High-Quality Stainless Steel Blade & Zero Gapped T-Blade:** Adopts stainless steel blade, maintains long-term sharpness without pulling hair, delivering superior performance. Precision detachable blade for precise edges, artistic sculpting, and sideburn trimming.
- **4-in-1 Multi-function Trimmer & Ergonomic Design:** Exquisite and compact for comfortable grip. Combines nose/ear trimmer head, body grooming head, detailed trimmer head, and 4 size guide combs (1/3/5/7mm) for diverse grooming needs.
- **Large Battery Capacity & Long Battery Life:** 1.5 hours for full charge provides up to 150 minutes running time for the hair clipper and 180 minutes for the hair trimmer. Convenient USB charging.
- **Built-in LED Intelligent Display:** Shows battery indicator, Lock-Key function, oil drip reminder, and cleaning reminder for easy monitoring.
- **IPX7 Washable Design:** Allows for easy cleaning under running water. Both the hair clipper body and trimmer can be rinsed. Blades are detachable for brush cleaning.
- **Strong & Powerful Motor:** Ensures stable and efficient cutting for various hair types and lengths.



Image: Detailed view of the multi-function trimmer, showcasing its precision T-blade, interchangeable heads, metal embossed body, clear LCD display, and IPX7 waterproof rating.



Image: Detailed view of the main hair clipper, highlighting its high-quality stainless steel blade, adjustable blade lever, one-button power switch, and LCD display for power and maintenance reminders.

Setup

Charging the Devices

Before first use, fully charge both the hair clipper and the multi-function trimmer. Connect the provided USB cables to the charging ports on the devices and a compatible USB power source (e.g., computer, laptop, USB charger, power bank). The LED display will indicate the charging status.



Image: Visual guide showing the charging process and expected runtimes: 1.5 hours charge for 150 minutes runtime for the clipper, and 1.5 hours charge for 180 minutes runtime for the trimmer.

Attaching Guide Combs

Select the desired guide comb based on the hair length you wish to achieve. Align the comb with the blade and snap it securely into place. Ensure it is firmly attached before use.



Image: An illustration detailing the various guide comb sizes available for both the hair trimmer (1mm, 3mm, 5mm, 7mm) and the hair clipper (3mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm), along with the adjustable taper control for the clipper.

Operating Instructions

Power On/Off

Press the power button located on the front of the device to turn it on or off. The LED display will illuminate when the device is active.

Adjusting Cutting Length

For the large barber clipper, use the adjustable taper lever on the side to fine-tune the cutting length between 0.8mm and 2.0mm. For longer lengths, attach the appropriate guide comb as described in the Setup section.

Using Different Trimmer Heads (Multi-function Trimmer)

The small multi-function trimmer comes with interchangeable heads for various grooming tasks:

- **Nose/Ear Trimmer Head:** Ideal for safely trimming unwanted hair in the nose and ear areas.
- **Body Grooming Head:** Use for general body hair trimming.
- **Detailed Trimmer Head:** Perfect for precise lines, edges, and intricate designs on beards, sideburns, or hairlines.

To change heads, gently twist and pull off the current head, then align and push the desired head onto the trimmer until it clicks into place.



Image: A composite image demonstrating the versatility of the Hatteker grooming kit, showing it being used for a child's haircut, nose hair trimming, body hair grooming, and beard detailing.

Maintenance

Cleaning the Devices

Both the hair clipper and trimmer feature an IPX7 waterproof design, allowing for easy cleaning under running water. After each use:

1. Turn off the device.
2. Remove any attached guide combs or trimmer heads.
3. Rinse the blades and the device body under running water.
4. Use the provided cleaning brush to remove any stubborn hair clippings from the blades.
5. Wipe the device dry with a soft cloth before storing.



Image: Side-by-side comparison showing both the main hair clipper and the multi-function trimmer being rinsed directly under a faucet, illustrating their IPX7 waterproof capability for easy cleaning.

Oiling Blades

The LED display includes an oil drip reminder. When this indicator appears, apply a small drop of lubricating oil (not

included) to the blades to ensure smooth operation and prolong their lifespan. Run the device for a few seconds to distribute the oil evenly.

Troubleshooting

If you encounter any issues with your Hatteker grooming kit, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. If the battery is low, connect it to a power source using the USB cable.
- **Poor cutting performance:** Clean the blades thoroughly to remove any trapped hair. Apply lubricating oil if the oil reminder is active or if the blades feel sluggish. Ensure the correct guide comb is properly attached.
- **Unusual noise:** Clean and oil the blades. If the noise persists, ensure all attachments are securely fastened.

For further assistance, please contact customer support.

Specifications

Feature	Detail
Product Dimensions	3.39 x 7.68 x 8.82 inches; 10.41 ounces
Item Model Number	ht608
Batteries	1 AAA batteries required (included)
Date First Available	March 6, 2024
Manufacturer	YIWU KEHAN ELECTRICAL APPLIANCE CO.LTD
Brand	Hatteker
Model Name	Hatteker Professional
Charging Time	1.5 Hours
Battery Description	Lithium-Ion

Warranty and Support

Hatteker products are designed for durability and performance. For information regarding product warranty, protection plans, or customer support, please refer to the documentation included with your purchase or visit the official Hatteker website. For any operational issues or technical assistance, please contact our dedicated support team.
Online Support: Hatteker Brand Store on Amazon

© 2024 Hatteker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question