Aoxun 10' x 10' Gazebo Single Polycarbonate Roof

Aoxun 10' x 10' Gazebo Single Polycarbonate Roof Instruction Manual

Model: 10' x 10' Gazebo Single Polycarbonate Roof

1. Introduction

Thank you for choosing the Aoxun 10' x 10' Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor structure. Please read these instructions thoroughly before beginning assembly and retain them for future reference. Proper assembly and care will ensure the longevity and optimal performance of your gazebo.


2. Safety Information

Important Safety Warnings:

- Keep all parts and tools out of reach of children during assembly.
- Avoid direct contact with skin and eyes when handling any components that may have protective coatings.
- If any part is ingested, seek medical help immediately.
- The maximum load-bearing capacity of the ceiling hook is 10KG (approximately 22 lbs). Do not hang items exceeding this weight.
- Ensure the gazebo is securely anchored to the ground to prevent wind damage. Refer to the 'Assembly Instructions' for anchoring options.
- Do not assemble or use the gazebo during strong winds, heavy rain, or snowfall. Disassemble or secure the structure if severe weather is anticipated.
- Regularly inspect all connections and components for tightness and wear. Tighten loose bolts and replace damaged parts as needed.
- Keep open flames and heat sources away from the gazebo fabric and polycarbonate roof.

3. Package Contents

Your Aoxun Gazebo is delivered in two boxes, which may arrive on different days. Please ensure you have received both packages before beginning assembly. All parts and hardware are clearly numbered and labeled for easy identification during the assembly process. Refer to the included detailed and illustrated instructions for a complete list of components.




The gazebo is shipped in two separate boxes, which may arrive on different days.

4. Assembly Instructions

Assembly of the Aoxun Gazebo requires careful attention to detail. It is recommended that two or more adults participate in the assembly process. All necessary parts and hardware are included and clearly marked. Follow the step-by-step illustrated instructions provided in the separate assembly guide for best results.

Key Assembly Steps and Features:


- **Frame Construction:** The gazebo features a thick powder-coated aluminum frame designed for durability and resistance to scratching, peeling, corrosion, and rust. The four columns are constructed with a strong tripod structure for stability.
- **Roof Installation:** The single polycarbonate roof panels are designed to block harmful UV rays while allowing natural light to enter. Ensure panels are correctly oriented and sealed to prevent water leakage.
- **Anchoring:** Robust anchoring brackets with pre-drilled holes are provided for secure mounting to various surfaces. Depending on your installation surface (ground, anchoring stakes, or expansion bolts), wind resistance can be significantly enhanced.
- **Curtains and Netting:** Attach the removable polyester curtains and netting using the provided extra Velcro straps. These can be adjusted for privacy, sun protection, or insect prevention.



Detail of the sturdy aluminum frame, Velcro straps, and anchoring system.



The aluminum frame features a durable powder coating for enhanced longevity.



Anchoring methods impact wind resistance: ground (18-24MPH), stakes (24-30MPH), expansion bolts (31-38MPH).

5. Operating Instructions

Your Aoxun Gazebo is designed for versatile outdoor use, offering comfort and protection.

Curtains and Netting:


- The gazebo includes removable polyester curtains and netting. Use the netting to prevent mosquitoes and ensure air ventilation.
- Deploy the curtains for protection from rain, strong sunlight, or to create a private space. The extra Velcro straps help organize and secure the curtains when not in use.

Polycarbonate Roof:

- The single polycarbonate roof is designed to block harmful UV rays, minimizing the risk of sunburn while allowing natural light to filter through.
- The sloped roof and water gutter design facilitate quick drainage of rainwater, preventing accumulation.

Ceiling Hook:

- A ceiling hook is integrated into the center of the gazebo roof. This hook can be used to hang lightweight items such as fans, lights, or decorative elements.
- Ensure that any item hung from the ceiling hook does not exceed the maximum load capacity of 10KG (22 lbs).



The gazebo offers versatile configurations for privacy, ventilation, and mosquito protection.



The central ceiling hook supports hanging fans, lights, or decorations up to 10KG.

6. Maintenance and Care

Regular maintenance will extend the life and appearance of your Aoxun Gazebo.

- **Cleaning the Frame:** Wipe the aluminum frame with a soft cloth and mild soap and water. Rinse thoroughly and dry to prevent water spots. Avoid abrasive cleaners or harsh chemicals that could damage the powder coating.
- **Cleaning the Roof:** The polycarbonate roof can be cleaned with a soft cloth or sponge and mild soapy water. Avoid using stiff brushes or abrasive materials that may scratch the surface.
- **Cleaning Curtains and Netting:** The polyester curtains and netting can be spot cleaned with mild soap and water. For deeper cleaning, they may be removed and hand washed or machine washed on a gentle cycle with cold water. Air dry completely before reattaching.
- **Seasonal Care:** In areas with heavy snowfall, it is recommended to remove snow accumulation from the roof to prevent

structural damage. Consider disassembling and storing the gazebo in a dry, protected area during extreme winter conditions to prolong its lifespan.

- **Fastener Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Re-tighten any loose fasteners to maintain structural integrity.


7. Troubleshooting

This section addresses common issues you might encounter with your gazebo.

- **Gazebo feels unstable:** Ensure all frame connections are securely tightened. Verify that the gazebo is properly anchored to the ground using appropriate methods (stakes or expansion bolts) for your surface. Avoid using the gazebo in high winds.
- **Water pooling on the roof:** The polycarbonate roof has a sloped design for drainage. Check if the gazebo is assembled on a level surface. Ensure all roof panels are correctly installed and sealed according to the assembly instructions. Clear any debris that might be obstructing the water gutters.
- **Curtains/Netting not closing properly:** Check for any obstructions or damage to the fabric. Ensure the Velcro straps are aligned correctly. Clean any dirt or debris from the Velcro to ensure a strong seal.
- **Parts missing or damaged:** If you discover any missing or damaged parts upon unpacking, please contact Aoxun customer support immediately with your product model and a description of the issue.

8. Specifications

Feature	Detail
Brand	Aoxun
Model	10' x 10' Gazebo Single Polycarbonate Roof
Product Dimensions (L x W x H)	118.11"L x 118.11"W x 100.4"H (approx. 9.8' L x 9.8' W x 8.4' H)
Item Weight	133 Pounds
Frame Material	Aluminum (Powder-coated)
Roof Material	Polycarbonate
Curtain/Netting Material	Polyester
Water Resistance Level	Waterproof
Ultraviolet Light Protection	25 (Protects against 99% UV rays)
Assembly Required	Yes
Color	Gray



Detailed dimensions of the Aoxun 10' x 10' Gazebo.

9. Warranty and Support

For warranty information, specific product support, or to order replacement parts, please refer to the contact information provided with your purchase documentation or visit the official Aoxun website. Please have your model number and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question