Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BOWERY HILL BH-4752-2624926

BOWERY HILL Modern Wood Baker Rack with Sliding Door in White Oak

Model: BH-4752-2624926

1. Introduction

This manual provides essential information for the assembly, setup, operation, and maintenance of your BOWERY HILL Modern Wood Baker Rack. Please read these instructions carefully before beginning assembly and retain them for future reference. This baker rack is designed to provide versatile storage and display options in various rooms, featuring a modern farmhouse aesthetic with a white oak finish, a sliding barn-style door, and a drawer.



Image 1.1: Front view of the BOWERY HILL Modern Wood Baker Rack, showcasing the white oak finish, sliding door, and open shelving.

2. Safety Information

- **Weight Capacity:** Do not exceed the maximum weight capacity of 100 lbs (45 kg) for the entire unit. Distribute weight evenly across shelves and the top surface.
- **Anti-Tip Device:** If an anti-tip device is included, it is strongly recommended to install it to prevent accidental tipping, especially in households with children or pets.
- **Stable Surface:** Place the baker rack on a flat, level, and stable surface to prevent wobbling or instability.
- **Assembly:** Assemble the unit according to the provided step-by-step guide. Ensure all fasteners are securely tightened before use.
- **Children:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the unit.

3. Package Contents

Verify that all components are present before beginning assembly. Refer to the separate assembly guide for a detailed list of parts and hardware.

- Baker Rack Frame (MDF, Particle Board)
- Sliding Wooden Door with X-brace design
- Drawer with metal glides
- Interior Shelves (quantity as per design)
- Open Shelves (quantity as per design)
- Gold metal accent hardware for sliding door mechanism
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Assembly Guide

4. Assembly Instructions

Your BOWERY HILL Modern Wood Baker Rack requires assembly. A detailed, step-by-step assembly guide is included in the product packaging. Please follow the instructions in that guide carefully.

1. Unpack all components and verify against the parts list in the assembly guide.
2. Identify all hardware and separate them for easy access.
3. Follow the numbered steps in the assembly guide, ensuring all connections are secure.
4. Do not overtighten screws to avoid damaging the wood material.
5. Ensure the sliding door mechanism and drawer glides are installed correctly for smooth operation.

Tools Required (not included): Typically, a Phillips head screwdriver and a hammer are needed for assembly.

5. Setup

After assembly, follow these steps for proper setup:

- **Placement:** Choose a suitable location on a flat, level surface. Avoid placing the unit in direct sunlight or near heat sources, which can cause material warping or discoloration.
- **Leveling:** Check the stability of the baker rack. If it wobbles, adjust the placement or use shims under the legs to ensure it is level.
- **Anti-Tip Installation:** If an anti-tip kit was provided, securely attach it to the wall and the unit as per the separate instructions to prevent accidental tipping.

6. Operating the Baker Rack Features

This baker rack features a sliding door and a drawer for organized storage.

6.1. Sliding Door

The barn-style door slides horizontally along the gold metal track. To open or close, gently grasp the door and slide it left or right. Ensure the track is clear of obstructions for smooth movement.



Image 6.1: Front view of the baker rack with the sliding door open, revealing interior shelves.

6.2. Drawer

The drawer operates on metal glides for smooth opening and closing. To open, pull the drawer handle. To close, push the drawer firmly until it is fully seated. Avoid overloading the drawer to ensure proper function.



Image 6.2: Front view of the baker rack with the drawer pulled open, showing its storage capacity.

6.3. Shelves

The unit includes both open and interior shelves. These are fixed shelves designed for storing kitchen appliances, pantry items, decor, or other household goods. Distribute items evenly to maintain stability.

7. Maintenance

Proper care will extend the life and appearance of your baker rack.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish. Dry immediately with a clean cloth.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the wood finish.

- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.
- **Sliding Mechanism:** Keep the sliding door track clean and free of debris to ensure smooth operation.

8. Troubleshooting

- **Wobbly Unit:** Ensure the unit is on a level surface. Check all assembly screws and tighten them if loose.
- **Drawer Sticks:** Verify that the drawer glides are installed correctly and are free of obstructions. Ensure the drawer is not overloaded.
- **Sliding Door Not Smooth:** Check the track for debris or misalignment. Ensure the door is properly seated on the track.
- **Missing Parts:** If any parts are missing or damaged upon arrival, contact the retailer or manufacturer for assistance.

9. Specifications

Brand	BOWERY HILL
Model Name	Bowery Hill Modern Wood Baker Rack with Sliding Door in White Oak
Item Model Number	BH-4752-2624926
Product Dimensions (L x W x H)	31.25"L x 15.5"W x 52.75"H (79.38 cm L x 39.37 cm W x 133.99 cm H)
Item Weight	67 lbs (30.39 kg)
Weight Capacity	100 lbs (45 kg)
Materials	MDF, Particle Board
Finish	White Oak
Assembly Required	Yes
Number of Shelves	2 (visible open shelves, plus interior shelves behind door)




Image 9.1: Technical diagram illustrating the dimensions of the BOWERY HILL Modern Wood Baker Rack and its components.

10. Warranty Information

Specific warranty details for the BOWERY HILL Modern Wood Baker Rack are typically provided with your purchase documentation or can be obtained from the retailer where the product was purchased. Please retain your proof of purchase for any warranty claims.

11. Customer Support

For assistance with assembly, missing parts, or any other product-related inquiries, please contact the retailer or the manufacturer, BOWERY HILL, directly. Refer to your purchase receipt or the product packaging for contact information.

Online Resources: You may also find additional support or FAQs on the BOWERY HILL brand website.

© 2024 BOWERY HILL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX92MQC4

More documents and user manuals: **https://manuals.plus/**