

[Manuals.plus](#) /

> [ARREGUI](#) /

> ARREGUI Magna 590090 Furniture Safe User Manual

ARREGUI 590090

ARREGUI Magna 590090 Furniture Safe User Manual

Model: 590090 | Brand: ARREGUI



Figure 1: ARREGUI Magna 590090 Furniture Safe

INTRODUCTION

This manual provides essential instructions for the proper installation, operation, and maintenance of your ARREGUI Magna 590090 Furniture Safe. Please read this manual thoroughly before using the safe to ensure optimal security

and functionality. Keep this manual for future reference.

Safety Information

- Always keep the emergency keys in a secure location away from the safe. Do not store them inside the safe.
- Ensure the safe is securely anchored to a wall or floor to prevent unauthorized removal.
- Do not expose the safe to extreme temperatures or humidity.
- Replace batteries promptly when the low battery indicator appears to avoid lockout.

1. SETUP AND INSTALLATION


1.1 Unpacking and Contents

Carefully unpack the safe and verify all components are present. The package should include:

- ARREGUI Magna 590090 Safe
- Instruction Manual (this document)
- 2 User Keys
- 1 Emergency Key
- Mounting Screws and Anchors
- Removable Shelf

DIMENSIONES Y COMPONENTES

MAGNA
590090



ESTANTE	MANUAL DE INSTRUCCIONES	ALFOMBRILLA	TORNILLERÍA	2 LLAVES DE USUARIO	1 LLAVE DE EMERGENCIA

ARREGUI

Figure 2: Safe Dimensions and Included Components

1.2 Battery Installation

The safe requires 4 AA 1.5V alkaline batteries (not included) for the electronic lock. Locate the battery compartment, usually on the inside of the safe door. Insert the batteries, ensuring correct polarity.

Important: Do not use rechargeable batteries as they may not provide sufficient power.

1.3 Initial Code Setting

Your safe comes with a factory default code or requires you to set an initial code upon first use. Refer to the specific instructions below to set your personal user code and master code.

1. With the safe door open, locate the reset button (often a small button on the inside of the door or battery compartment).
2. Press the reset button. The display should show "PROG" or similar, indicating it's ready for programming.
3. Enter your desired user code (3 to 6 digits) on the keypad, then press the '#' or 'ENTER' button.
4. Repeat the process to set a master code, if applicable, following the specific prompts on the display.
5. Test the new code with the door open before closing it.

Note: The safe supports 1 master code and 1 user code, offering 1 million possible combinations.

1.4 Anchoring the Safe

For maximum security, it is highly recommended to anchor the safe to a wall, floor, or inside a cabinet. The safe features 2 pre-drilled holes in the base and 2 in the rear wall, each 9 mm in diameter. Use the provided mounting screws and anchors.

1. Choose a suitable location for the safe.
2. Mark the drilling points through the pre-drilled holes in the safe.
3. Drill holes in the wall/floor using an appropriate drill bit.
4. Insert the anchors into the drilled holes.
5. Position the safe and secure it firmly with the mounting screws.

2. OPERATING INSTRUCTIONS

2.1 Opening the Safe (Normal Operation)

The ARREGUI Magna 590090 safe features a 2-factor security lock, requiring both a code and a key for opening.


1. Enter your personal user code (or master code) on the electronic keypad. The 6-digit display will show help messages during entry.
2. Once the correct code is entered, the display will indicate successful entry.
3. Insert one of the user keys into the keyhole and turn it to unlock the safe.
4. Pull the door open. The internal LED light will automatically turn on.

MODOS DE APERTURA

MAGNA
ARREGUI


APERTURA HABITUAL

Código personal + llave de usuario



APERTURA DE EMERGENCIA


Llave de emergencia
(sustituye al código personal)



Alimentación externa mediante
pila de 9V (en caso de pilas agotadas)



Servicio de Asistencia Técnica
en toda España



Duplicado
de llaves



Nº de serie
único grabado
en la caja, para
solicitar
duplicados de
llaves en caso
de pérdida.

Figure 3: Opening the Safe with Code and Key

2.2 Closing and Locking the Safe

1. Close the safe door firmly.
2. Turn the key back to the locked position and remove it. The safe will automatically lock with its 3 nickel-plated steel bolts.

2.3 Changing the User/Master Code

To change an existing code:

1. With the safe door open, press the reset button.
2. Enter your new desired code (3 to 6 digits).
3. Press the '#' or 'ENTER' button to confirm.
4. Test the new code with the door open before closing.

2.4 Emergency Opening

In case of forgotten code, empty batteries, or keypad damage, the safe can be opened using one of the following emergency methods:

- **Emergency Key:** Insert the emergency key into the hidden emergency keyhole (usually behind a cover on the keypad panel) and turn it to open the safe.
- **External Power Supply (9V Battery):** If batteries are depleted, connect a 9V battery to the external power contacts on the keypad panel. This will temporarily power the keypad, allowing you to enter your code and open the safe. Replace the internal AA batteries immediately after opening.

3. MAINTENANCE

3.1 Battery Replacement

The display will indicate a low battery level. Replace all 4 AA batteries promptly to ensure continuous operation and prevent lockout. Use only new, high-quality alkaline batteries.

3.2 Cleaning

Clean the safe's exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or electronic components.

3.3 Internal Features

The safe includes a removable shelf for organizing contents and a 10 cm high base with a hidden storage box. The internal LED light activates automatically when the door is opened, providing visibility.

CAPACIDAD

**MAGNA
590090**



Estante extraíble

Válida para archivadores >A4

Capacidad 71 L.

Cajón oculto en el zócalo



JOYAS



DINERO



**DOCUMENTOS
Y CARPETAS**



PASAPORTES



PORTÁTIL (14")

ARREGUI

Figure 4: Interior Capacity with Removable Shelf and Hidden Base Compartment



Figure 5: Automatic Internal LED Light

4. TROUBLESHOOTING

- **Safe does not open after entering code:**
 - Ensure you are turning the key after entering the correct code. Both steps are required.
 - Check if batteries are low. Replace them if necessary.
 - Try using the emergency key.
- **Keypad is unresponsive:**
 - Check battery level. Use a 9V battery for external power if internal batteries are dead.
 - If 3 incorrect codes are entered, the safe will lock for 5 minutes. Wait for the lockout period to expire.
- **Low Battery Indicator:**
 - The display will show a low battery warning. Replace all 4 AA batteries immediately.
- **Lost or forgotten code:**
 - Use the emergency key to open the safe. Once open, you can reset the code.

5. SPECIFICATIONS

Feature	Detail
Model	ARREGUI Magna 590090
External Dimensions (H x W x D)	62 x 35 x 36 cm (24.41" x 13.78" x 14.17")
Internal Dimensions (H x W x D)	51.5 x 34.5 x 30 cm (excluding base height)
Capacity	71 Liters
Weight	25 kg (55.1 lbs)
Material	Alloy Steel (6mm front, 2mm body thickness)
Lock Type	Electronic Combination Lock + Key (2-Factor Security)
Locking Bolts	3 nickel-plated steel bolts, 20 mm diameter
Codes	1 Master Code, 1 User Code (3-6 digits)
Display	6-digit display with help messages and low battery indicator
Power	4 x AA 1.5V alkaline batteries (not included)
Emergency Power	9V battery external connection
Special Features	Removable shelf, 10 cm high base with hidden storage, internal LED light, anti-theft features.
Mounting	2 base and 2 rear wall holes (9mm diameter) for anchoring

CARACTERÍSTICAS

MAGNA
590090

Espesor cuerpo: 2 mm

Espesor frente: 6 mm

Luz interna

Pantalla 6 dígitos

Balda interior extraíble

Llave de emergencia

Cierre mediante
3 bulones de Ø 20 mm



Zócalo de 10 cm
con cajón oculto



PROTECCIÓN ANTI SIERRA

Bulones giratorios y guiados
por soportes macizos.



PROTECCIÓN ANTI FISHING

Protección del botón de reinicio.

ARREGUI

Figure 6: Key Features of the Safe

6. WARRANTY INFORMATION

The ARREGUI Magna 590090 safe comes with a **3-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation provided with your product or contact customer support.

7. CUSTOMER SUPPORT

For technical assistance, spare parts, or any inquiries regarding your ARREGUI safe, please contact ARREGUI customer service. You may find contact information on the official ARREGUI website or through your retailer. When contacting support, please have your model number (590090) and serial number (if available, typically found on a sticker inside the safe or on the packaging) ready.

For service assistance, you can visit the official ARREGUI website: www.arregui.es