

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK Electric Sit-Stand Desk 120x60 cm Maple - Instruction Manual

SANODESK 120x60cm

SANODESK Electric Sit-Stand Desk 120x60 cm Maple - Instruction Manual

Model: 120x60cm Maple

INTRODUCTION

Thank you for choosing the SANODESK Electric Sit-Stand Desk. This manual provides detailed instructions for the assembly, operation, and maintenance of your new adjustable height desk. Please read this manual thoroughly before use to ensure proper function and safety. This desk is designed to offer a versatile and ergonomic workspace, allowing you to easily switch between sitting and standing positions throughout your day.

Design Sans Couture, Artisanat Supérieur

Le Plateau Monobloc Offre Une Surface Parfaitement
Lisse Et Continue, Qui Incarne Elégance Et Précision



Image: The SANODESK Electric Sit-Stand Desk providing a modern and functional workspace.

SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety guidelines:

- The maximum weight capacity for this desk is **60 kg (132 lbs)**. Do not exceed this limit to maintain stability and safety.
- Keep children and pets away from the desk during operation.
- Ensure there are no obstructions in the desk's path when adjusting height.
- Do not sit or stand on the desk.
- Only use the provided power adapter and control panel.
- If any unusual noise or movement occurs, immediately stop operation and unplug the desk.

Concevez Votre Espace Comme Vous Vivez Et Travaillez

Que Vous Travailliez, Créiez Ou Vous Détendiez, Sanodesk Vous Accompagne Pour Trouver Votre Rythme



Image: A user comfortably working at the SANODESK desk, highlighting its adaptability for various activities.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Desk tabletop (Maple, 120x60 cm)
- Electric lifting columns (legs)
- Foot pads
- Control panel with LED display
- Power adapter and cable
- Cable management tray/hooks
- Assembly hardware (screws, bolts, Allen keys)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly typically requires two people. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Desk Frame:** Attach the lifting columns to the crossbar and side brackets using the provided hardware. Ensure all connections are secure.
3. **Attach Feet:** Secure the foot pads to the bottom of the lifting columns.
4. **Mount Tabletop:** Carefully place the tabletop upside down on a soft surface. Position the assembled frame onto the tabletop, aligning the pre-drilled holes. Secure the frame to the tabletop using the provided screws.
5. **Install Control Panel:** Attach the control panel to the underside of the tabletop in a convenient location.
6. **Connect Cables:** Connect the motor cables from the lifting columns to the control box. Connect the control panel cable to the control box. Finally, connect the power adapter to the control box and then to a power outlet.
7. **Cable Management:** Use the included cable management accessories (hooks, tray) to organize and secure all cables.
8. **Initial Power-On:** Once fully assembled and connected, plug the desk into a power source. The LED display should light up.

For detailed visual instructions, refer to the assembly diagrams included in the physical manual.

OPERATING INSTRUCTIONS

The SANODESK features an intuitive control panel for easy height adjustment and memory functions.

Panneau LED Intelligent

4 Emplacements De Mémoire Pour Un Réglage De Hauteur Sans Effort



Affichage LED



Haut/Bas



Fonction De Mémoire



Système Anti-Collision

Image: The intelligent LED control panel for the SANODESK desk, showing height display and function buttons.

Basic Height Adjustment

- Press and hold the **Up** (▲) button to raise the desk.
- Press and hold the **Down** (▼) button to lower the desk.
- Release the button at your desired height. The LED display will show the current height in centimeters.

Memory Presets

The control panel allows you to save up to four preferred height positions.

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **'M'** button (or similar memory set button, often indicated by 'i' or 'SET'). The display may flash 'S'.
3. Within 3 seconds, press one of the numbered memory buttons (**1, 2, 3, or 4**) to save the current height to that position. The display will confirm the setting.
4. To recall a saved height, simply press the corresponding numbered memory button. The desk will automatically move to the saved position.

Child Lock Function

The integrated child lock function prevents accidental height adjustments.

- To activate the child lock, press and hold the 'L' button (or a similar lock icon) for a few seconds until the display indicates 'LOC' or a lock symbol.
- When locked, the desk will not respond to height adjustment or memory button presses.
- To deactivate, press and hold the 'L' button again until the display returns to the current height.

Anti-Collision System

The desk is equipped with an anti-collision system that automatically stops and slightly reverses the desk's movement if it encounters an obstruction during height adjustment. This feature helps prevent damage to the desk or other objects.



Élévation De Précision, Sans Aucun Tremblement

Travaillez En Toute Confiance : Votre Bureau Reste
Parfaitement Stable, Sans Balancement Ni Vibration

Image: A fishbowl on the desk surface, illustrating the desk's stable and precise movement during height adjustments.

Regular maintenance ensures the longevity and optimal performance of your SANODESK.

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cable Management:** Periodically check that all cables are securely routed and not pinched or tangled.
- **Fasteners:** Occasionally check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Motor Care:** The electric motor is designed for maintenance-free operation. Do not attempt to open or lubricate the motor housing.

Travailler En Silence, Se Concentrer Profondément

Profite D'un Levage Doux À Moins De 50 DB De Bruit.



<30 dB

<50 dB

>80 dB

Bourdonnement De Papillon

Nos Produits

Klaxons De Voiture

Image: A cat resting on the desk, demonstrating the quiet operation of the desk's motor, which operates at less than 50 dB.

TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Child lock active; Overload.	Check power connections; Deactivate child lock; Reduce weight on desk.
Desk moves unevenly or makes unusual noise.	Loose connections; Obstruction; Damaged component.	Check all assembly connections; Remove obstructions; Contact customer support if issue persists.
Error code on display.	Specific system error.	Refer to the full manual for specific error code meanings or contact customer support. Often, unplugging and replugging the desk can reset the system.
Memory function not working.	Incorrect setting procedure.	Ensure you press 'M' then the number button within 3 seconds.

If these solutions do not resolve the issue, please contact SANODESK customer support for further assistance.

SPECIFICATIONS

Key technical details for your SANODESK Electric Sit-Stand Desk:

- **Model:** 120x60cm Maple
- **Tabletop Dimensions (L x W):** 120 cm x 60 cm (47.2 x 23.6 inches)
- **Height Adjustment Range:** 73 cm to 118 cm (28.7 to 46.5 inches)
- **Maximum Load Capacity:** 60 kg (132 lbs)
- **Noise Level:** < 50 dB during operation
- **Material:** Wood (tabletop), Metal (frame)
- **Features:** Electric height adjustment, Memory presets (4 positions), Child lock, Anti-collision system

Votre Hauteur Parfaite, À Chaque Fois

Enregistre Jusqu'à 4 Positions Préférées Avec Le
Panneau De Contrôle De Mémoire.



Image: Visual representation of the desk's adjustable height, showing a user sitting at 750mm and standing at 1100mm.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official SANODESK website. Keep your purchase receipt as proof of purchase for any warranty claims. If you have any questions or require assistance, please contact SANODESK customer service directly.