

OLEVS YPF-S-G5529G-JL

OLEVS Men's Chronograph Quartz Watch Instruction Manual

Model: YPF-S-G5529G-JL

1. INTRODUCTION

Thank you for choosing the OLEVS Men's Chronograph Quartz Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.

2. PRODUCT FEATURES

- **Chronograph Function:** Features three multi-function subdials for 60 seconds, 60 minutes, and moon phase tracking.
- **Multi-Calendar Display:** Includes a date window for convenient date reference.
- **Quartz Movement:** Ensures stable and accurate timekeeping.
- **Durable Construction:** Stainless steel case and strap with a butterfly double buckle for comfortable wear.
- **Adjustable Bracelet:** Comes with a free stainless steel strap adjustment tool to customize fit.
- **Luminous Display:** High-definition luminous pointers and markers absorb light energy for readability in dark environments.
- **Water Resistance:** Rated for 30 meters (3 ATM) for daily waterproof needs.

3. SETUP INSTRUCTIONS

3.1 Time and Date Setting

1. **Setting the Time:** Pull the crown (middle knob) out to the second click position. Rotate the crown to set the hour and minute hands to the correct time. Push the crown back in to the normal position.
2. **Setting the Date:** Pull the crown out to the first click position. Rotate the crown clockwise or counter-clockwise (depending on the movement) to set the correct date. Push the crown back in to the normal position. *Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.*

3.2 Bracelet Adjustment

Your watch comes with a strap adjustment tool. To adjust the length of the stainless steel bracelet:

1. Identify the pins on the side of the bracelet links that need to be removed.
2. Place the bracelet in the adjustment tool with the pin facing the tool's pusher.
3. Slowly turn the screw on the tool to push the pin out.
4. Remove the desired number of links.
5. Reassemble the bracelet by inserting the pins back into the links and gently tapping them into place.



Image: OLEVS Men's Chronograph Quartz Watch with blue dial and stainless steel band, accompanied by a band adjustment tool.

4. OPERATING INSTRUCTIONS

4.1 Chronograph Function

The chronograph allows for precise timing of events.

1. **Start/Stop:** Press the upper pusher (button above the crown) to start the chronograph. Press it again to stop.
2. **Reset:** While the chronograph is stopped, press the lower pusher (button below the crown) to reset all chronograph hands to zero.

4.2 Moon Phase Display

The moon phase subdial indicates the current phase of the moon. This is typically set in conjunction with the time and date, and will advance automatically once set correctly.

4.3 Luminous Display

The watch hands and markers are coated with a luminous material. Exposure to light (natural or artificial) will charge this material, allowing the time to be read in low-light conditions. The intensity and duration of the glow depend on the exposure time and light source.

Product Parameters

Product Parameters

Model number OLEVS/3618	Mirror material High hardness coated
Strap material Textured bracelet	Movement Original quartz movement
Case diameter 42mm	Dial thickness 12mm
Strap width 20mm	Wearing length 19cm
Waterproofing 30metres	Weights 115g

Note: Due to manual measurement, there may be slight differences

between the actual size of the product and the data we provide.

Colour Selection



Fernie Blue

Silvery

Glack

Golden

Rose gold

Image: Diagram illustrating the functions of the OLEVS watch's chronograph, moon phase, calendar, and time setting.

High Definition Luminous

HD luminescent coating, absorbs light according to daylight hours
Easy to keep time day and night





Image: Close-up of the OLEVS watch dial showing the luminous hands and markers in the dark.

5. MAINTENANCE

5.1 Water Resistance

This watch is water resistant to 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes or brief immersion in water. **It is not suitable for showering, bathing, swimming, or diving.** Avoid exposing the watch to hot water, as this can compromise the water resistance seals.

Water resistant to **30 metres**

With sealed waterproof ring to enhance anti-fog function
(All watches are not protected against warm and hot water)



Image: OLEVS watch with water splashing around it, illustrating its water resistance.

5.2 Cleaning

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners or abrasive materials.

5.3 Battery Replacement

The watch is powered by a quartz movement, which uses a battery. The battery life typically ranges from 1 to 3 years. When the watch stops or the second hand begins to jump erratically, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.

6. TROUBLESHOOTING

- **Watch not running:** Check if the crown is pushed in completely. If it is, the battery may need replacement.
- **Incorrect time/date:** Refer to the 'Time and Date Setting' section to reset. Ensure the crown is pushed in after setting.
- **Chronograph not resetting to zero:** This may require a specific reset procedure for the chronograph movement, or professional adjustment.
- **Condensation under crystal:** This indicates a loss of water resistance. Avoid further contact with water and seek professional service immediately.

7. SPECIFICATIONS

Feature	Detail
Model Number	YPF-S-G5529G-JL
Movement	Original Quartz Movement
Case Diameter	42mm
Dial Thickness	12mm
Strap Material	Stainless Steel
Strap Width	20mm
Wearing Length	19cm (Adjustable)
Mirror Material	High Hardness Coated Glass
Waterproofing	30 meters (3 ATM)
Weight	115g

8. WARRANTY AND SUPPORT

OLEVS provides a **30-day free return guarantee** for this watch. If you encounter any issues during the use of your OLEVS watch, please contact customer support for assistance. We are committed to providing a satisfactory solution. For further inquiries or support, please refer to the contact information provided with your purchase or visit the official

OLEVS store online.

Note: Protection plans may be available for extended coverage. Please check your purchase details for options.

© 2025 OLEVS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question