

PayLessHere Mannequin Torso Dress Form Mannequin

PayLessHere Male Full Body Retail Mannequin 73 Inch Instruction Manual

Model: Mannequin Torso Dress Form Mannequin

Brand: PayLessHere

INTRODUCTION

Thank you for choosing the PayLessHere Male Full Body Retail Mannequin. This instruction manual provides detailed guidance on assembling, operating, and maintaining your mannequin to ensure optimal performance and longevity. Please read this manual carefully before assembly and use.

SETUP AND ASSEMBLY

The PayLessHere Male Full Body Mannequin is designed for easy assembly without the need for special tools. Follow these steps to set up your mannequin:

- Unpack Components:** Carefully remove all parts from the packaging. Verify that all accessories are included as shown in the diagram below.
- Assemble Legs and Base:** Connect the two leg sections. Insert the metal rod into the designated slot in one leg and secure it to the metal base by tightening the knob.
- Attach Torso:** Align the torso with the assembled legs and twist gently until it locks into place.
- Install Arms:** Attach each arm to the shoulder sockets. The arms are designed to rotate for adjustable posing.
- Place Head:** Secure the head onto the neck post. The head can be rotated 360 degrees for versatile display options.



Image: All components of the mannequin, including head, torso, legs, arms, and metal base, laid out before assembly.



Image: A detailed view highlighting the adjustable posture and detachable design of the mannequin's head and arms for easy dressing and posing.

Video: This video demonstrates the step-by-step assembly process of the male full body mannequin, including connecting the legs, torso, arms, and head, and securing it to the base.

OPERATING AND USAGE

The PayLessHere Mannequin offers versatile usage for various display needs. Its realistic design and adjustable features make it ideal for showcasing clothing and apparel effectively.

- **Realistic Display:** The mannequin boasts a lifelike appearance with adjustable posture, arms, and legs, allowing for dynamic showcasing of clothing designs. The head can be rotated 360 degrees, and it features vivid facial expressions, eyelashes, clear eyes, and blush for a realistic presentation.
- **Perfect Muscle Curve:** Designed to emulate the natural contours of the human body, this mannequin features a perfect muscle curve that enhances the presentation of clothing and apparel, providing a realistic and flattering fit.
- **Versatile Usage:** Ideal for dressmakers, seamstresses, fashion designers, and retail displays, this full-body mannequin is suitable for a wide range of applications, including sewing, dress modeling, and showcasing clothing collections.

Fit all kind of clothes

Suit, tie, hat, shorts, pants



Image: The mannequin is shown wearing different types of clothing, illustrating its ability to fit various garments like suits, ties, hats, shorts, and pants.

Suitable for Various occasions



◀ Suit store



▲ Showcase window



◀ Tailor shop

Image: Examples of the mannequin's use in various settings, such as a suit store, showcase window, and tailor shop, highlighting its suitability for different occasions.

Video: This video demonstrates how to dress a mannequin, showcasing the ease of putting on various garments and adjusting the mannequin's posture for optimal display.

MAINTENANCE

To ensure your mannequin remains in excellent condition, follow these maintenance guidelines:

- **Cleaning:** Wipe the mannequin regularly with a soft, damp cloth to remove dust and dirt. Avoid using abrasive cleaners or solvents, as these can damage the polypropylene (PP) material.
- **Storage:** When not in use, disassemble the mannequin and store its parts in a dry, cool place to prevent damage.
- **Handling:** Handle the mannequin with care during assembly, disassembly, and posing to avoid scratches or breakage.

TROUBLESHOOTING

If you encounter any issues with your mannequin, refer to the following common solutions:

- **Loose Joints:** If any detachable parts feel loose, ensure they are properly aligned and twisted securely into their respective sockets.

- **Stability Issues:** Confirm that the metal base is correctly attached to the leg and the knob is tightened. Ensure the mannequin is placed on a flat, stable surface.
- **Difficulty Posing:** Gently rotate and adjust the arms and head. If resistance is met, check for any obstructions or misalignments in the joints.

SPECIFICATIONS

Feature	Detail
Brand	PayLessHere
Model Number	Mannequin Torso Dress Form Mannequin
Size	73 Inch
Product Dimensions	73"H
Material	Polypropylene (PP)
Item Weight	15 Pounds
Color	Nude
Chest Size	38 Inches
Waist Size	30 Inches
Hip Size	37 Inches

Product Parameter



Image: A visual representation of the mannequin's key dimensions, including chest, waist, hip, and total height.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact PayLessHere customer service directly. Keep your purchase receipt for any warranty claims.