CMF BY NOTHING CMF BY NOTHING Buds

CMF BY NOTHING CMF Buds Wireless Earbuds User Manual

Model: CMF BY NOTHING Buds (Orange)

Introduction

This manual provides essential information for the safe and efficient use of your CMF BY NOTHING CMF Buds wireless earbuds. Please read this manual thoroughly before using the product.





Image: CMF BY NOTHING CMF Buds wireless earbuds and their square charging case in orange.

What's in the Box

- Pair of CMF BY NOTHING CMF Buds (Orange)
- Ear tips in sizes S, M, L
- Charging case
- Safety information
- User Manual (this document)



Image: The complete package contents of the CMF Buds, showing the earbuds, charging case, and various sizes of ear tips.

Setup

1. Initial Charge

Before first use, ensure your CMF Buds and charging case are fully charged. Connect the charging case to a USB-C power source. A full charge provides up to 35.5 hours of total playtime with the case.
For a quick charge, 10 minutes of charging can provide approximately 6.5 hours of playtime.



Image: The CMF Buds charging case with a USB-C cable inserted for charging.

2. Pairing with Your Device

1. Open the charging case.
2. Press and hold the pairing button on the case until the LED indicator flashes.
3. On your device (Android 5.1+ or iOS 13+), go to Bluetooth settings and select "CMF BY NOTHING Buds" from the list of available devices.
4. For Android devices, Google Fast Pair is supported for quick connection. For Windows devices, Microsoft Swift Pair is supported.

The CMF Buds support dual device connection, allowing seamless switching between two paired devices.

Your browser does not support the video tag.

Video: A user demonstrating the pairing process of the CMF Buds with a smartphone, showing the app interface and connection steps.

Operating Instructions

1. Nothing X App

Download the Nothing X application from your device's app store to unlock full customization options for your CMF Buds. The app allows you to:

- Customize equalizer settings (Dirac HD Audio presets or custom).
- Adjust Ultra Bass levels (5 adjustable levels).
- Control Active Noise Cancellation (ANC) and Transparency Mode.
- Enable Low-Latency Mode for gaming.
- Customize touch controls.
- Use the "Find My Earbuds" feature.




Image: Screenshot of the Nothing X app displaying equalizer settings for audio customization.

2. Active Noise Cancellation (ANC) & Transparency Mode

The CMF Buds feature 42dB Active Noise Cancellation with a bandwidth of up to 2900Hz to reduce ambient noise.
Transparency Mode allows you to hear your surroundings while still enjoying audio.
Switch between ANC, Transparency, and Off modes via the Nothing X app or customizable touch controls.



Image: A visual representation of the CMF Buds' 42dB Active Noise Cancellation and Transparency Mode capabilities.

3. Call Quality

Equipped with 4 HD microphones and Clear Voice Technology, the CMF Buds ensure crisp and clear call performance. An optimized channel structure with two holes at the bottom of the stem helps reduce wind interference during calls.




Image: A detailed diagram highlighting the wind noise reduction features integrated into the CMF Buds.

Maintenance

1. Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance. Use a soft, dry cloth for the case. For the earbuds, gently wipe the ear tips and speaker mesh with a slightly damp cloth. Ensure no moisture enters the speaker openings.
The earbuds are IP54 dust and water-resistant, protecting them from sweat and light splashes. However, they are not designed for submersion in water.

Your browser does not support the video tag.

Video: A user demonstrating how to remove and clean the ear tips of the CMF Buds, highlighting the internal mesh filter.

2. Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.

Troubleshooting

1. Earbuds Not Pairing

- Ensure both earbuds are in the charging case and the case has sufficient battery.
- Open the case and press and hold the pairing button until the LED indicator flashes.
- On your device, forget the "CMF BY NOTHING Buds" from your Bluetooth settings and try pairing again.

2. Low Audio Quality

- Check the ear tip fit. Experiment with different sizes (S, M, L) to find the best seal for your ears.
- Clean the ear tips and speaker mesh to remove any debris.
- Adjust the equalizer settings in the Nothing X app.

3. Battery Drain Issues

- Ensure the earbuds are properly seated in the charging case when not in use.
- High volume levels and continuous ANC use can reduce battery life.
- Check for firmware updates via the Nothing X app.

Specifications

Feature	Detail
Model Name	CMF BY NOTHING Buds
Noise Control	Active Noise Cancellation (42dB)
Connectivity	Bluetooth 5.3, Wireless
Audio Driver Size	12.4 mm Dynamic Driver
Battery Life (Earbuds)	Up to 8 hours
Battery Life (with Case)	Up to 35.5 hours
Quick Charge	10 min charge for 6.5 hours playtime
Water Resistance	IP54 (Dust and Water Resistant)
Compatible Devices	Android 5.1 and above, iOS 13 and above
Control Type	Touch control, Voice Assistant, App
Item Weight	3.21 ounces (91 Grams)
Product Dimensions	2.15 x 2.15 x 0.9 inches

Warranty and Support

For warranty information and technical support, please refer to the official CMF BY NOTHING website or contact their customer service. Ensure you retain your proof of purchase for warranty claims.

Each item has a unique code that is verified before shipping, ensuring product authenticity.

© 2024 CMF BY NOTHING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question