

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Smart Watch Band Instruction Manual for VKAROOD KC88, Donerton T50S/T50H, and Uaue T50S

Lamshaw Smart Watch Band

Lamshaw Smart Watch Band Instruction Manual

For VKAROOD KC88, Donerton T50S/T50H, and Uaue T50S Smart Watches

1. INTRODUCTION

This manual provides instructions for the installation, usage, and maintenance of your Lamshaw Soft Silicone Sport Replacement Straps. These bands are designed for compatibility with VKAROOD KC88 1.43" Smart Watch, Donerton T50S T50H 1.85" Smartwatch, and Uaue T50S 1.85" Smart Watch models.




This image displays the three included Lamshaw silicone sport replacement straps in black, gray, and blue colors, showcasing their design and texture.

2. SETUP AND INSTALLATION

Follow these steps to correctly attach the replacement strap to your compatible smartwatch.

2.1 Identifying Band Components


Each replacement strap consists of two separate pieces: a longer piece with multiple adjustment holes and a shorter piece with the buckle and a double secure slot.



The individual components of a blue Lamshaw silicone smart watch band are displayed, showing the two strap pieces before assembly.

2.2 Attaching the Band to Your Smartwatch

1. Locate the quick-release pins on the back of each band piece.
2. Align one end of the quick-release pin with the corresponding lug hole on your smartwatch.
3. Slide the small lever on the quick-release pin inwards to retract the pin.
4. While holding the lever, gently insert the other end of the pin into the opposite lug hole on the smartwatch.
5. Release the lever, ensuring the pin is securely seated in both lug holes. You should hear a slight click or feel it lock into place.
6. Gently tug on the band to confirm it is firmly attached and does not detach easily.
7. Repeat the process for the second band piece.



This image provides a close-up of the band's key features, including the seamless connection mechanism, the double secure slot for a firm fit, the soft and flexible silicone material, and its breathable, comfortable design.

3. OPERATING (USAGE)

Once installed, your Lamshaw smart watch band is ready for use. The silicone material is designed for comfort and flexibility during daily wear and various activities.

3.1 Wearing the Band

1. Place the smartwatch on your wrist.
2. Thread the longer strap through the buckle on the shorter strap.
3. Insert the buckle pin into one of the adjustment holes that provides a comfortable and secure fit. The band should be snug but not too tight, allowing for proper blood circulation and sensor readings.
4. Secure the excess strap through the double secure slot to prevent it from flapping.



A smartwatch with a gray Lamshaw silicone band is shown on a person's wrist, demonstrating comfortable wear during an activity like writing.



A smartwatch with a blue Lamshaw silicone band is shown on a person's wrist, highlighting its casual and comfortable fit.



A smartwatch with a black Lamshaw silicone band is shown on a person's wrist, illustrating its suitability for daily activities such as typing on a laptop.

4. MAINTENANCE

Proper care will extend the life and appearance of your silicone watch band.

4.1 Cleaning Instructions

- Regularly clean your band, especially after exercise or exposure to sweat, dirt, or lotions.
- Wipe the band with a soft, damp cloth. For stubborn dirt, use a mild soap solution.
- Rinse thoroughly with clean water to remove any soap residue.
- Dry the band completely with a soft, lint-free cloth before reattaching it to your smartwatch or wearing it.
- Avoid harsh chemicals, abrasive cleaners, or excessive scrubbing, as these can damage the silicone material.

4.2 Storage

When not in use, store the band in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.

5. TROUBLESHOOTING

If you encounter any issues with your Lamshaw smart watch band, consider the following:

- **Band not attaching securely:** Ensure the quick-release pins are fully retracted and properly aligned with the lug holes. Verify that the pins are seating correctly in both holes before releasing the lever.
- **Discomfort or skin irritation:** Ensure the band is not too tight. Clean the band regularly to remove sweat and debris. If irritation persists, discontinue use and consult a healthcare professional.
- **Band appears dirty or discolored:** Refer to the cleaning instructions in Section 4.1.

6. SPECIFICATIONS

- **Material:** Soft Silicone
- **Clasp Type:** Buckle

- **Metal Type:** No Metal Type
- **Compatibility:** VKAROOD KC88 1.43" Smart Watch, Donerton T50S T50H 1.85" Smartwatch, Uaue T50S 1.85" Smart Watch
- **Department:** Unisex-adult

7. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Lamshaw Smart Watch Band, please contact the seller directly through your purchase platform. Please refer to your purchase documentation for specific warranty details, if applicable.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0CXDK5P2B>

More documents and user manuals: <https://manuals.plus/>