domi outdoor living LGMF1638-DF-US

Domi 12'x16' Cedar Wood Gazebo Instruction Manual

Model: LGMF1638-DF-US

Brand: domi outdoor living

1. Introduction

Thank you for choosing the Domi 12'x16' Cedar Wood Gazebo. This gazebo is designed to provide a durable and elegant outdoor living space, featuring a double-roof steel hardtop, solid cedar wood frame, and included curtains and netting. This manual provides essential information for the safe assembly, operation, and maintenance of your gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: The Domi 12'x16' Cedar Wood Gazebo, showcasing its design and functionality in an outdoor setting.

2. Safety Information

Your safety and the safety of others are very important. Please observe the following safety guidelines:

- Always assemble and anchor the gazebo to a stable and level foundation. Ensure the ground is firm and can support the weight of the structure.
- Do not attempt to move or disassemble the gazebo when it is wet or frozen, as this can cause damage to the structure or lead to injury.
- Inspect the gazebo regularly for any signs of wear, damage, or loose connections. Perform necessary maintenance promptly to ensure its stability and safety.
- Keep the gazebo clear of debris, especially on the roof. Remove any significant snow or ice accumulation to prevent structural damage or collapse.
- Ensure all bolts and fasteners are securely tightened after assembly and checked periodically.

- Keep children and pets away from the assembly area during installation.
- Do not hang heavy objects from the gazebo frame or roof that exceed its load capacity.

3. Components List

Before beginning assembly, carefully unpack all components and verify them against the parts list provided in your physical instruction manual. Ensure all parts are present and undamaged. If any parts are missing or damaged, contact customer support immediately.
Key components typically include:

- Cedar Wood Frame Posts (5.5"x5.5" reinforced aluminum stand poles)
- Steel Hardtop Roof Panels (double-tier design)
- Roof Support Beams and Connectors
- Detachable Curtains
- Detachable Netting (mesh screens)
- Hardware Kit (bolts, nuts, washers, screws, silicone sealant)
- Ground Nails/Anchors

4. Setup and Assembly

Assembly of the Domi Gazebo requires at least two people. While the process is detailed in the included physical manual, here are some general guidelines and important tips:

- **Read the Manual First:** Before starting, thoroughly read the entire assembly manual provided in the packaging. Familiarize yourself with all steps and component identifications.
- **Organize Parts:** Lay out all parts and hardware according to their labels. This will significantly speed up the assembly process.
- **Do Not Fully Tighten Bolts Prematurely:** This is a critical step. For most sections, especially the roof structure, only hand-tighten bolts initially. Fully tighten all bolts only after the entire section or the complete frame is assembled and aligned. This allows for necessary adjustments and prevents misalignment.
- **Use Silicone Sealant:** Apply the provided silicone sealant to all roof panel seams and connection points to ensure waterproof integrity. Check for any gaps where daylight might show through from underneath the roof panels and seal them.
- **Secure Anchoring:** Once assembled, securely anchor the gazebo to the ground using the provided ground nails or other suitable anchoring methods to ensure stability against wind.

DIMENSION




Image 4.1: Gazebo dimensions for planning and assembly.



Image 4.2: Detail of the high-quality cedar wood frame, emphasizing its durability.

5. Operating Instructions

The Domi Gazebo is designed for ease of use and versatility:

- **Curtains and Netting:** The gazebo includes fully enclosed zippered double-layer sidewalls. The outer curtains provide privacy and shade from direct sunlight, while the inner mesh screens keep insects at bay. These can be easily opened, closed, or tied back as needed.
- **Ceiling Hooks:** The gazebo roof features three integrated ceiling hooks. These hooks are designed to support lightweight items such as fans, lights, or decorative elements, enhancing your outdoor living experience. Ensure any hung items do not exceed the specified weight capacity (typically 25 lbs per hook).
- **Ventilation:** The double-tier roof design promotes enhanced airflow, allowing hot air to escape and maintaining a comfortable environment within the gazebo.
- **Drainage:** The slope-top configuration of the roof is engineered to efficiently drain rainwater, preventing

accumulation and ensuring the longevity of the structure.



Image 5.1: Detachable curtains and netting for versatile use.



Image 5.2: Ceiling hooks for accessories.



Image 5.3: Double-tier roof for enhanced ventilation and weather protection.



Image 5.4: Enhanced slope drainage for effective rainwater runoff.

6. Maintenance

Regular maintenance will extend the life and appearance of your gazebo:

- **Cleaning:** Clean the cedar wood frame and steel roof regularly with mild soap and water. Avoid harsh chemicals or abrasive cleaners that could damage the finish. Rinse thoroughly with clean water.
- **Fabric Care:** The curtains and netting can be spot cleaned with mild soap and water. For deeper cleaning, follow care instructions on the fabric tags. Ensure they are completely dry before storing or zipping up for extended periods to prevent mildew.
- **Inspection:** Periodically check all bolts, screws, and connections to ensure they remain tight. Re-tighten any loose fasteners. Inspect the frame for any signs of cracking, warping, or corrosion.
- **Winter Care:** While the hardtop roof is designed to withstand snow, it is recommended to remove heavy snow accumulation to prevent excessive stress on the structure. Consider purchasing a winter cover for added protection

in harsh climates.

- **Anchoring:** Regularly check the ground anchors to ensure they are secure, especially after strong winds or storms.

7. Troubleshooting

If you encounter issues during assembly or use, consider the following:

- **Misaligned Holes During Assembly:** If holes do not align, ensure that all previously installed bolts are only hand-tightened. Loosen them slightly to allow for flexibility, align the current piece, and then gradually tighten all bolts in that section.
- **Missing or Damaged Parts:** Refer to the components list in your physical manual. If parts are missing or damaged upon delivery, contact Domi Outdoor Living customer support immediately with your product model number and a description of the issue.
- **Water Leaks from Roof:** Ensure all roof panels are correctly overlapped and all seams are sealed with the provided silicone sealant. Re-apply sealant if necessary. Check that the slope is clear of debris.
- **Gazebo Instability:** Verify that the gazebo is anchored securely to a level surface. Check all frame connections for tightness. Ensure the ground nails are fully inserted and holding firm.

For issues not covered here, please consult the detailed troubleshooting section in your physical instruction manual or contact Domi Outdoor Living customer support.

8. Specifications

Brand	domi outdoor living
Model Number	LGMF1638-DF-US
Material	Alloy Steel, Cedar Wood
Frame Material	Cedar Wood, Aluminum
Color	Cedar Wood
Product Dimensions	189.6"L x 142.8"W x 120"H (15.8'L x 11.9'W x 10'H)
Item Weight	357 Pounds
Water Resistance Level	Waterproof
Ultraviolet Light Protection	Yes
Assembly Required	Yes

9. Warranty and Support

Domi Outdoor Living is committed to providing high-quality products and customer satisfaction. For specific warranty information regarding your Domi 12'x16' Cedar Wood Gazebo, please refer to the warranty card included with your

product or visit the official Domi Outdoor Living website.

If you require assistance with assembly, have questions about product features, or need to report a missing/damaged part, please contact Domi Outdoor Living customer support. Have your model number (LGMF1638-DF-US) and purchase information ready when contacting support for faster service.

You can find contact information for customer support on the product packaging or the official brand website: Domi Outdoor Living Store

© 2024 Domi Outdoor Living. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question