



Manuals.plus /

› JBL /

› JBL PartyBox On-The-Go Speaker and Vibe Beam Headphones User Manual

JBL JBLPARTYBOXGOBAM, Vibe Beam

JBL PartyBox On-The-Go Speaker and Vibe Beam Headphones User Manual

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your JBL PartyBox On-The-Go portable Bluetooth speaker and JBL Vibe Beam True Wireless Headphones. Please read this manual thoroughly before operating your devices and retain it for future reference.

WHAT'S IN THE BOX

Carefully unpack all items and ensure the following are present:

- JBL PartyBox On-The-Go Speaker
- JBL Wireless Microphone
- Carrying Strap with Bottle Opener
- Power Cable
- JBL Vibe Beam True Wireless Headphones (Left and Right earbuds)
- JBL Vibe Beam Charging Case
- USB-C Charging Cable for Vibe Beam
- Multiple sizes of ear tips for Vibe Beam
- Quick Start Guide and Safety Sheet for both products



Image: JBL PartyBox On-The-Go speaker shown with its included wireless microphone.



Image: JBL Vibe Beam True Wireless Headphones resting inside their charging case.

JBL PARTYBOX ON-THE-GO SETUP

1. Charging the Speaker

Before first use, fully charge the PartyBox On-The-Go. Connect the power cable to the speaker's power input and then to a power outlet. The battery indicator will show charging status. A full charge takes approximately 3.5 hours.

2. Powering On/Off

Press the **Power button** on the top panel to turn the speaker on or off.

3. Bluetooth Pairing

1. Turn on the PartyBox On-The-Go.
2. Press the **Bluetooth button** on the top panel. The Bluetooth indicator will flash, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and select "JBL PartyBox On-The-Go" from the list of available devices.
4. Once connected, the Bluetooth indicator will glow solid blue.

4. Microphone Connection

Insert the wireless microphone's receiver into the microphone input on the speaker. The microphone will automatically connect. Adjust microphone volume and echo using the dedicated knobs on the speaker's top panel.



Image: JBL PartyBox On-The-Go speaker shown with its detachable shoulder strap attached.

JBL PARTYBOX ON-THE-GO OPERATING INSTRUCTIONS

1. Music Playback

- **Bluetooth:** Play music from your paired device. Use the volume controls on the speaker or your device.

- **USB:** Insert a USB drive with audio files into the USB port. The speaker will automatically play music from the drive.
- **AUX:** Connect an audio device using a 3.5mm AUX cable to the AUX input.

2. Light Show Control

Press the **Light Show button** to cycle through different light patterns or turn the light show off. The lights sync to the music.

3. Bass Boost

Press the **Bass Boost button** to enhance the bass output. Press again to turn it off.

4. True Wireless Stereo (TWS) Connection

You can connect two JBL PartyBox On-The-Go speakers together for a stereo sound experience:

1. Ensure both speakers are powered on.
2. On one speaker, press and hold the **TWS button** for 5 seconds. It will emit a pairing tone.
3. Repeat this step on the second speaker.
4. The speakers will connect automatically. The TWS indicator will glow solid on both speakers.

5. Using the Microphone and Instrument Input

Adjust the microphone volume and echo using the dedicated knobs. You can also connect an instrument (e.g., guitar) to the instrument input and adjust its volume independently.



Image: Rear view of the JBL PartyBox On-The-Go speaker, showing input ports and the wireless microphone.

JBL VIBE BEAM HEADPHONES SETUP

1. Charging the Headphones and Case

Place the earbuds into the charging case. Connect the USB-C cable to the case and then to a power source. The LED indicators on the case will show the charging status. The earbuds and case can be charged simultaneously.

2. Initial Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device, enable Bluetooth and select "JBL Vibe Beam" from the list of available devices.
3. Once connected, the earbuds will indicate successful pairing.

3. Wearing the Headphones

Insert the earbuds into your ears and gently twist them to find a comfortable and secure fit. Experiment with the different ear tip sizes to achieve optimal sound quality and comfort.



Image: JBL Vibe Beam True Wireless Headphones in their open charging case, showing the earbuds and charging indicators.

JBL VIBE BEAM HEADPHONES OPERATING INSTRUCTIONS

1. Touch Controls

The Vibe Beam headphones feature touch controls on each earbud:

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap:** Skip forward (right earbud), Skip backward (left earbud), Reject call.
- **Triple Tap:** Activate voice assistant.
- **Tap and Hold:** Volume control (customizable via JBL Headphones App).

2. VoiceAware

During calls, VoiceAware allows you to control how much of your own voice you hear through the earbuds, enhancing call clarity and comfort. This feature can be adjusted via the JBL Headphones App.

3. Single Earbud Use

Either earbud can be used independently. Simply remove one earbud from the case, and it will automatically connect to your device if already paired.



Image: Close-up view of the two JBL Vibe Beam True Wireless Headphones earbuds.

MAINTENANCE

1. Cleaning

- **PartyBox On-The-Go:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or immerse the speaker in water.
- **Vibe Beam Headphones:** Gently clean the earbuds and charging case with a dry, soft, lint-free cloth. Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.

2. Storage

Store both products in a cool, dry place away from direct sunlight and extreme temperatures. For the Vibe Beam headphones, always store them in their charging case when not in use.

3. Battery Care

To prolong battery life, fully charge the devices at least once every 3 months if not used regularly. Avoid completely draining the battery frequently.

4. Water and Dust Resistance

- The JBL PartyBox On-The-Go is IPX4 splash-proof, meaning it can withstand splashes of water but should not be submerged.
- The JBL Vibe Beam earbuds are IP54 certified (dust and splash resistant), and the charging case is IPX2 (drip resistant). Ensure the charging port covers are securely closed before exposure to water or dust.

TROUBLESHOOTING

JBL PartyBox On-The-Go

- **No Power:** Ensure the speaker is charged or connected to a power outlet.
- **No Sound:** Check volume levels on both the speaker and your connected device. Ensure the correct input source is selected.
- **Bluetooth Pairing Issues:** Ensure the speaker is in pairing mode. Turn off and on Bluetooth on your device, then try pairing again. Clear previous pairings from your device's Bluetooth list.
- **Microphone Not Working:** Ensure the microphone receiver is fully inserted and the microphone is powered on (if applicable). Check microphone volume.

JBL Vibe Beam Headphones

- **No Sound from one earbud:** Place both earbuds back in the charging case, close the lid, then reopen and try again. Ensure both earbuds are charged.
- **Pairing Issues:** Ensure the earbuds are in pairing mode (open case). Turn off and on Bluetooth on your device. Forget "JBL Vibe Beam" from your device's Bluetooth list and re-pair.
- **Earbuds not charging:** Ensure the charging contacts on the earbuds and in the case are clean and dry.

SPECIFICATIONS

JBL PartyBox On-The-Go Speaker

- **Brand:** JBL
- **Model Name:** JBLPARTYBOXGOBAM
- **Speaker Maximum Output Power:** 100 Watts
- **Connectivity Technology:** Bluetooth, USB, AUX
- **Audio Output Mode:** Stereo
- **Battery Average Life:** 6 Hours
- **Battery Charge Time:** 3.5 Hours
- **Waterproof Rating:** IPX4 (Splashproof)
- **Built-In Media:** JBL wireless microphone, carrying strap with bottle opener

JBL Vibe Beam True Wireless Headphones

- **Brand:** JBL
- **Audio Driver Type:** Dynamic Driver
- **Driver Size:** 8mm
- **Battery Life (Earbuds + Case):** Up to 32 total hours
- **Water and Dust Resistance (Earbuds):** IP54
- **Water Resistance (Charging Case):** IPX2

- **Features:** JBL Deep Bass Sound, VoiceAware, Hands-free calls

WARRANTY AND SUPPORT

Your JBL PartyBox On-The-Go Speaker and JBL Vibe Beam True Wireless Headphones are covered by a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official JBL website.

For technical support, troubleshooting assistance, or service inquiries, please contact JBL customer support through their official website or the contact information provided in your product documentation.