

Genérico BC-AU-BS-251-BK

User Manual for BICONIC BC-AU-BS-251-BK Portable Bluetooth Speaker

Model: BC-AU-BS-251-BK

1. INTRODUCTION

Thank you for purchasing the BICONIC BC-AU-BS-251-BK Portable Bluetooth Speaker. This manual provides important information regarding the setup, operation, maintenance, and troubleshooting of your new device. Please read this manual thoroughly before using the speaker to ensure proper function and longevity.

2. SAFETY INFORMATION

To prevent fire, electric shock, or product damage, please observe the following safety guidelines:

- Do not expose the speaker to rain or moisture.
- Do not place objects filled with liquids, such as vases, on the speaker.
- Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

3. PRODUCT OVERVIEW

The BICONIC BC-AU-BS-251-BK is a portable Bluetooth speaker designed for high-quality audio playback with dynamic LED lighting. Its tower design makes it suitable for various placements.

Package Contents:

- BICONIC BC-AU-BS-251-BK Portable Bluetooth Speaker
- Charging Cable
- User Manual (this document)

Key Features:

- Portable Bluetooth Speaker

- Rechargeable Battery
- Tower Type Design
- LED Lights that synchronize with music rhythm



Figure 3.1: Front view of the BICONIC BC-AU-BS-251-BK Portable Bluetooth Speaker, showcasing its tower design and vibrant LED lighting.



Figure 3.2: The BICONIC BC-AU-BS-251-BK speaker placed on a table, demonstrating its compact size and how its LED lights vary with music, as indicated by the text "Vary colors with music" in the image.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker's built-in rechargeable battery. Connect the provided charging cable to the speaker's charging port and the other end to a compatible USB power source (e.g., a computer USB port or a USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.

4.2 Powering On/Off

- To power on: Press and hold the Power button for approximately 3 seconds. You will hear an audible prompt.
- To power off: Press and hold the Power button for approximately 3 seconds. You will hear an audible prompt.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The LED lights may flash to indicate pairing mode.
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices. The speaker will appear as "BC-AU-BS-251-BK" or similar.
4. Select the speaker from the list to pair. Once successfully paired, you will hear a confirmation sound, and the LED lights may change their pattern.
5. You can now play audio from your device through the speaker.

5.2 Audio Playback

Once paired, control audio playback (play, pause, skip tracks, volume) directly from your connected Bluetooth device. The speaker's LED lights will dynamically respond to the rhythm of the music.

5.3 LED Light Modes

The speaker features integrated LED lights that react to the music. Specific controls for changing light modes (if available) will be located on the speaker's control panel. Refer to the physical buttons on your device for light mode adjustments.

6. MAINTENANCE

Proper maintenance ensures the longevity of your speaker:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the provided charging cable.
Cannot pair with Bluetooth device.	Bluetooth is not enabled on the device or speaker is not in pairing mode.	Ensure Bluetooth is enabled on your device. Power cycle the speaker to re-enter pairing mode. Move devices closer.
No sound from speaker.	Volume is too low or device is not properly connected.	Increase volume on both the speaker and the connected device. Re-pair the Bluetooth connection.
LED lights not working.	Feature may be disabled or a malfunction.	Check if there's a dedicated button for LED lights. If not, try restarting the speaker.

8. SPECIFICATIONS

Feature	Detail
Model Name	BC-AU-BS-251-BK
Brand	Genérico (BICONIC)
Connectivity Technology	Bluetooth
Power Source	Battery
Speaker Type	Tower
Amplification Type	Active
Mounting Type	Floor, Table Mount
Special Features	Bluetooth, Portable, LED Lights
Included Components	Charging Cable
Product Dimensions (L x W x H)	12cm x 12cm x 25cm

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your purchase receipt as proof of purchase for any warranty claims.

For technical assistance or further inquiries, please contact the manufacturer or authorized service center. Contact details may be available on the product packaging or the manufacturer's official website.



