

[Manuals.plus](#) /

› [AVNICUD](#) /

› AVNICUD Indoor Digital TV Antenna User Manual

AVNICUD TV Antenna Indoor for ALL Tvs

AVNICUD Indoor Digital TV Antenna User Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your AVNICUD Indoor Digital TV Antenna. Please read this guide thoroughly before use to ensure optimal performance and longevity of your device. This antenna is designed to receive free over-the-air (OTA) high-definition television broadcasts.



Image: The AVNICUD Indoor Digital TV Antenna, showing the main antenna panel, amplifier, and coaxial cable.


PRODUCT COMPONENTS

Your AVNICUD Indoor Digital TV Antenna package includes the following items:

- Digital TV Antenna Panel
- Signal Amplifier (with USB power cable)
- 18 ft Coaxial Cable (integrated with antenna)
- USB Power Adapter (for amplifier)

2023 Newest Upgraded

Amplified Signal Booster with Built-in Smart IC
ChipTenfold Range and a stable Operation



Simple & Easy to install and operate



Voltage and current protection

Image: A detailed view of the signal amplifier, highlighting its internal components and smart IC chip for enhanced signal reception.


SETUP INSTRUCTIONS

Follow these steps to connect and set up your digital TV antenna:

1. **Connect the Antenna:** Locate the 'ANT IN' or 'CABLE IN' port on the back of your television or digital converter box. Connect the coaxial cable from the antenna to this port.
2. **Connect the Amplifier:** The signal amplifier should be connected in-line with the coaxial cable, close to the TV. Ensure the amplifier is securely connected to both the antenna's coaxial cable and the TV's 'ANT IN' port.
3. **Power the Amplifier:** Connect the USB power cable from the amplifier to a USB port on your TV or a separate USB power adapter (e.g., a phone charger). The amplifier requires power to function.
4. **Position the Antenna:** Place the antenna in an optimal location. Refer to the 'Optimizing Reception' section for guidance.
5. **Scan for Channels:** Turn on your TV. Access your TV's menu, navigate to 'Channel Scan' or 'Auto Program'. Select 'Antenna' or 'Air' as the input source. Initiate the channel scan. This process may take several minutes.

How to Connect

Connect the antenna to TraditionalTV



Connect the antenna to HDTV




Image: Connection diagrams illustrating how to connect the antenna to both traditional televisions (via a digital terrestrial set-top box) and modern HDTVs.

OPERATING INSTRUCTIONS

Once the setup is complete and channels have been scanned, you can begin watching free over-the-air broadcasts.

- **Channel Selection:** Use your TV remote to browse and select channels as you normally would.
- **Rescanning Channels:** If you experience signal loss, new channels become available, or you move the antenna, perform a channel rescan. This ensures your TV updates its channel list.

OPTIMIZING RECEPTION

The quality of reception can vary based on location, obstacles, and antenna placement. Consider the following to optimize your signal:

- **Antenna Placement:** Experiment with different locations for the antenna. Generally, higher positions and locations closer to windows facing the broadcast towers yield better results. Avoid placing the antenna near large metal

objects or other electronic devices that may cause interference.

- **Common Placement Options:** The antenna can be affixed to a window, mounted on a wall, placed behind the TV, or laid flat on a table.
- **Check Signal Strength:** Some TVs have a signal strength meter in their settings menu. Use this to gauge the effectiveness of different antenna positions.
- **Identify Local Broadcast Towers:** For best results, determine the direction of local broadcast towers. Websites like dtv.gov/maps or antennaweb.org can help you find available channels and tower locations in your area.

Before Purchasing

Find out what channels are available in your area
Please visit: dtv.gov/maps or antennaweb.org.



Smart chip



Signal stability



HD Channels



Quality assurance




Image: Visual guide demonstrating various installation methods for the antenna, including placement on a window, wall, behind the television, or flat on a surface.

Installation Methods



Stick on the window



Stick on the wall



Behind the TV



Lay flat on table

Image: An informational graphic encouraging users to verify channel availability in their specific location by visiting dtv.gov/maps or antennaweb.org prior to antenna purchase.

TROUBLESHOOTING

If you encounter issues with your antenna, try the following solutions:

- **No Channels Found:**

- Ensure all connections are secure, especially the coaxial cable to the TV and the amplifier.
- Verify the amplifier is powered via its USB connection.
- Perform a channel scan again.
- Try repositioning the antenna to a different location, preferably higher or closer to a window.
- Check dtv.gov/maps or antennaweb.org to confirm if digital broadcasts are available in your specific area.

- **Poor Picture Quality/Pixelation:**

- Adjust the antenna's position slightly. Even small movements can significantly impact signal quality.

- Ensure the antenna is not obstructed by large metal objects, appliances, or thick walls.
 - Rescan for channels after adjusting the antenna.
 - Check for potential sources of interference, such as other electronic devices, and move them away from the antenna if possible.
- **Amplifier Not Working:**
 - Confirm the USB power cable is securely connected to both the amplifier and a working USB power source.
 - Try a different USB port or power adapter.

MAINTENANCE

The AVNICUD Indoor Digital TV Antenna requires minimal maintenance:

- **Cleaning:** Wipe the antenna panel with a soft, dry cloth to remove dust. Do not use liquid cleaners or abrasive materials.
- **Storage:** If storing the antenna, ensure it is kept in a dry, cool place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid kinking or sharply bending the coaxial cable to prevent damage and signal loss.

SPECIFICATIONS

Feature	Specification
Model Number	TV Antenna Indoor for ALL Tvs
Brand	AVNICUD
Antenna Type	Indoor Digital TV Antenna
Coaxial Cable Length	18 feet
Amplifier	Included, USB powered
Package Dimensions	8.78 x 6.77 x 1.18 inches
Item Weight	5.7 ounces

WARRANTY AND CUSTOMER SERVICE

Your AVNICUD Indoor Digital TV Antenna comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use. For any questions, concerns, or warranty claims, please contact AVNICUD customer service. Our professional support team is available to assist you. Please retain your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question