



[Manuals.plus](#) /

> [Hohuqeri](#) /

> Hohuqeri Extra Large Metal Chicken Coop (B0CXHS6CLK) Instruction Manual

Hohuqeri Metal Chicken Coop

Hohuqeri Extra Large Metal Chicken Coop Instruction Manual

Model: Metal Chicken Coop (ASIN: B0CXHS6CLK)

INTRODUCTION

Thank you for choosing the Hohuqeri Extra Large Metal Chicken Coop. This manual provides essential information for the safe assembly, operation, and maintenance of your new poultry enclosure. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

SAFETY INSTRUCTIONS

- **Adult Assembly Required:** This product requires assembly by adults. Keep children and pets away during assembly.
- **Wear Protective Gear:** Always wear gloves and eye protection during assembly to prevent injury.
- **Secure Installation:** Ensure the coop is installed on a level surface and securely anchored to the ground to prevent tipping or collapse, especially in windy conditions.
- **Check for Sharp Edges:** Inspect all components for sharp edges or burrs before and after assembly. File down any sharp points to ensure the safety of your animals and yourself.
- **Proper Mesh Installation:** Ensure the PVC coated hexagonal wire mesh is securely attached to prevent animals from escaping and to protect them from predators.
- **Regular Inspection:** Periodically check all connections, bolts, and mesh for tightness and damage. Replace any worn or damaged parts immediately.
- **Ventilation:** Ensure adequate ventilation within the coop, especially during hot weather, to prevent overheating.
- **Waterproof Cover:** Properly secure the waterproof and UV-resistant cover to provide protection from sun, rain, and snow. Ensure the roof slope allows for proper water runoff.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Galvanized Steel Pipe Frame Components
- PVC Coated Hexagonal Wire Mesh
- Waterproof and UV Protection Cover
- Zip Ties for Mesh Attachment
- Ground Anchors/Reinforcement Nails
- Assembly Hardware (bolts, nuts, washers)
- Instruction Manual

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Hohuqeri Metal Chicken Coop. It is recommended to have at least two people for assembly.

Step 1: Prepare the Base Frame

Lay out the base frame components on a flat, level surface. Connect the horizontal pipes using the provided connectors and secure them with bolts. Ensure all connections are tight.



Figure 1: Base frame components and initial assembly.

Step 2: Install Vertical Supports and Roof Structure

Attach the vertical support pipes to the base frame. Then, assemble the roof structure by connecting the angled pipes. Carefully lift and secure the roof structure to the vertical supports. The frame is constructed from high-quality galvanized steel pipes for durability.

Dimensions

Oxford Coat:
11'×6.1'×2pcs





Figure 2: Assembled frame with key dimensions. The coop measures approximately 26 feet long, 10 feet wide, and 6.56 feet high.

Step 3: Attach Wire Mesh

Unroll the PVC coated hexagonal wire mesh and attach it to the frame using the provided zip ties. Start from one end and work your way around, ensuring the mesh is taut and securely fastened to all frame components. The small gaps in the mesh enhance safety against predators.




Figure 3: Detail of the secure mesh attachment and durable steel pipe construction.

Step 4: Install Waterproof Cover

Drape the waterproof and UV protection cover over the designated roof sections. Secure the cover using the integrated straps or bungee cords to the frame. Ensure the cover is stretched tightly and the roof slope allows for effective water and snow runoff.



Figure 4: The waterproof and UV-proof cover provides protection from various weather conditions.

Step 5: Secure the Coop to the Ground

Use the provided ground anchors or reinforcement nails to firmly secure the base of the coop to the ground. This step is crucial for stability and to prevent the coop from being moved by strong winds or animals.

WATER & ULTRAVIOLET RESISTANT




Figure 5: The coop is designed to be water-resistant, anti-ultraviolet, snow-proof, and heat regulative.

Step 6: Install Door

Install the lockable steel door according to the instructions. Ensure it swings open and shut smoothly and can be securely latched to protect your poultry.

OPERATING INSTRUCTIONS

- **Placement:** Position the coop in a suitable outdoor area, ideally with some natural shade and good drainage.
- **Animal Capacity:** This extra-large coop is designed to comfortably house 25-30 chickens, or other small animals such as ducks, rabbits, or geese.
- **Access:** The walk-in design and tall door allow for easy access for feeding, watering, and egg collection.
- **Security:** Always ensure the door is securely locked when animals are inside to prevent predator access.
- **Environmental Protection:** The waterproof and UV protection cover shields animals from harsh weather conditions, including intense sun, heavy rain, and snow.

Large Metal Chicken Coop

Provide a secure shelter for the poultry



Chicken



Dog



Duck



Rabbit



Goose



Figure 6: The multi-functional design accommodates various small farm animals.

MAINTENANCE

- **Regular Cleaning:** Clean the coop regularly to maintain a hygienic environment for your animals.
- **Frame Inspection:** Periodically check the galvanized steel frame for any signs of rust or damage. Although designed to be anti-rust, extreme conditions or prolonged exposure can affect it.
- **Mesh Integrity:** Inspect the PVC coated wire mesh for tears or loose sections. Repair or reinforce as needed to maintain security.
- **Cover Condition:** Check the waterproof cover for rips or wear. Ensure it remains securely fastened and provides adequate protection.
- **Ground Anchors:** Verify that ground anchors remain firmly in place, especially after heavy rains or strong winds.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coop feels unstable or wobbly.	Loose connections or insufficient ground anchoring.	Tighten all bolts and ensure ground anchors are fully inserted and secure. Consider adding additional anchors in soft soil.
Water pooling on the roof cover.	Cover not taut or improperly installed.	Re-adjust and tighten the cover straps to ensure proper tension and slope for water runoff.
Animals attempting to escape or predators gaining access.	Gaps in mesh or unsecured door.	Inspect all mesh connections and repair any gaps with additional zip ties or wire. Ensure the door is fully closed and locked.

SPECIFICATIONS

- **Model Name:** Metal Chicken Coop
- **ASIN:** B0CXHS6CLK
- **Brand:** Huhuqeri
- **Dimensions (LxWxH):** 312 x 120 x 78.72 inches (26'L x 10'W x 6.56'H)
- **Material:** Galvanized Steel Frame, PVC Coated Hexagonal Wire Mesh, Polyester Waterproof Cover
- **Color:** Silver (Frame), White/Grey (Cover)
- **Special Feature:** Durable, Waterproof, UV-Resistant
- **Recommended Breed Size:** Large
- **Capacity:** Approximately 25-30 Chickens
- **Specific Uses:** Outdoor Poultry Care, Animal Habitat

WARRANTY INFORMATION

The product specifications state "Warranty Description: No". Please refer to your purchase receipt or contact the seller directly for any specific return or replacement policies that may apply.

CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly, please contact Huhuqeri customer support through the retailer's platform where the product was purchased. Please have your ASIN (B0CXHS6CLK) and purchase date available when contacting support.