



[Manuals.plus](#) /

› [Reemix](#) /

› Reemix Masticating Juicer SG-120W-2021 User Manual

Reemix SG-120W-2021

Reemix Masticating Juicer User Manual

Model: SG-120W-2021

INTRODUCTION

Thank you for choosing the Reemix Masticating Juicer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new juicer. Please read it thoroughly before first use and retain it for future reference.



The Reemix Masticating Juicer, designed for efficient juice extraction, shown here with fresh juice and pulp, surrounded by various fruits and vegetables.

PRODUCT OVERVIEW

The Reemix Masticating Juicer is a compact cold press juicer designed to extract nutrient and vitamin-dense juice with minimal oxidation and low noise. It features a 120W copper motor for efficient operation.

Included Components

INCLUDES:

- Compact Slow Juicer
- Pulp Collection Cup
- Juice Cup
- Food Pusher
- Extra Auger



An illustration of all components included with your Reemix Masticating Juicer: the main compact slow juicer unit, a pulp collection cup, a juice cup, a food pusher, and an extra auger for enhanced juicing efficiency.

- Compact Slow Juicer Unit
- Pulp Collection Cup
- Juice Cup

- Food Pusher
- Extra Auger

SETUP AND ASSEMBLY

Before first use, ensure all parts are clean. Follow these steps to assemble your Reemix Masticating Juicer:



A visual guide demonstrating the four steps required to assemble the Reemix Masticating Juicer for operation.

1. **Step 1:** Place the juice container onto the motor unit.
2. **Step 2:** Place the auger on the center pin of the bowl. Turn and press down until it locks into place.
3. **Step 3:** Insert the filter and press down.
4. **Step 4:** Put the lid onto the juice bowl. Turn the lid clockwise to lock it. You will hear a "click".

Ensure the juicer is placed on a stable, flat surface before connecting to power.

OPERATING INSTRUCTIONS

Preparing Ingredients

- Wash all fruits and vegetables thoroughly.
- Cut ingredients into pieces small enough to fit into the feeding chute.
- Remove hard pits from fruits like peaches, plums, and cherries.
- For fibrous vegetables like celery, cut into short pieces to prevent clogging.
- The juicer is recommended for citrus fruits, fruits, vegetables, nuts, and seeds.

Juicing Process

1. Ensure the juice cup and pulp collection cup are in place.
2. Plug the power cord into a 127 Volt electrical outlet.
3. Turn the power switch to the "ON" position. The switch is located on the back of the motor unit.




The power switch, marked 'O' for Off and 'I' for On, located on the rear of the juicer's motor unit.

4. Slowly feed the prepared ingredients into the feeding chute. Use the food pusher only if necessary to guide ingredients down. Do not force ingredients.
5. The juicer will separate juice from pulp, dispensing them into their respective cups.
6. For continuous operation, ensure the pulp and juice cups do not overflow. The juicer has a capacity of 0.6 liters for juice.
7. After juicing, turn the power switch to the "OFF" position and unplug the appliance.

Reverse Function

If ingredients become jammed, switch the power to the "R" (Reverse) position for a few seconds to clear the blockage. Then switch back to "ON" to resume juicing. Always turn off and unplug the juicer before attempting to clear any blockages manually.



A diagram illustrating the rotational movement of the juicer's auger, indicating both the forward juicing direction and the reverse function for clearing blockages.

CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your juicer and ensure optimal performance.

Cleaning

1. **Unplug the Juicer:** Always unplug the juicer from the power outlet before cleaning.
2. **Disassemble:** Disassemble all removable parts (lid, auger, filter, juice bowl, cups).
3. **Rinse Immediately:** Rinse all removable parts under running water immediately after use to prevent pulp from drying and sticking.



A person demonstrating the hand washing process for the removable components of the juicer under running water.

4. **Hand Wash Only:** All accessories are removable and should be hand washed with warm, soapy water. *Do not place any parts in a dishwasher*, as this can damage the BPA-Free Tritan material.
5. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or any other liquid.
6. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing.

Storage

Store the assembled juicer in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Reemix Masticating Juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; power switch off; improper assembly.	Ensure power cord is securely plugged in. Turn power switch to 'ON'. Disassemble and reassemble correctly, ensuring all parts click into place.
Motor stops during operation or jams.	Overloaded with ingredients; hard ingredients; blockage.	Turn off the juicer. Use the 'R' (Reverse) function for a few seconds to clear blockage. If persistent, disassemble and clean out any lodged food. Cut ingredients into smaller pieces.
Low juice yield or excessive pulp in juice.	Filter clogged; ingredients not suitable for juicing; feeding too fast.	Clean the filter thoroughly. Ensure ingredients are appropriate for masticating juicers. Feed ingredients slowly and steadily.

Problem	Possible Cause	Solution
Loud noise or vibration.	Improper assembly; hard ingredients; unstable surface.	Check that all parts are assembled correctly and securely locked. Ensure ingredients are cut appropriately. Place juicer on a stable, flat surface.

If the problem persists after trying these solutions, please contact Reemix customer support.

SPECIFICATIONS

Feature	Detail
Brand	Reemix
Model Name	SG-120W-2021
Color	Black
Product Dimensions	5.71"D x 17.17"W x 6.77"H
Item Weight	4.05 pounds
Capacity	0.6 Liters (Juice Cup)
Maximum Power	120 Watts
Voltage	127 Volts
Power Source	Corded Electric
Blade Material	BPA-Free Tritan
Product Care	Hand Wash Only (Not Dishwasher Safe)
Recommended Uses	Citrus Fruits, Fruits, Vegetables, Nuts, Seeds
UPC	795057711664

PERSONAL JUICER

This is a compact juicer suitable for 2-3 people use



The Reemix Masticating Juicer, illustrating its compact dimensions of approximately 10cm (3.9in) width and 38.5cm (15in) height, suitable for personal use.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Reemix Masticating Juicer, please contact our customer service team.

If you receive a defective item or are not satisfied with your product, please reach out to us for the best solution. You can typically find seller contact information through your purchase platform:

- Navigate to **Your Account**.
- Select **Your Orders**.
- Find the relevant order and click on **Order Issue** or **Contact Seller**.

We are committed to providing you with a safe and healthy juicing experience.