

[manuals.plus](#) /

› [Microsoft](#) /

› Microsoft Surface Pro 2-in-1 Laptop/Tablet (2024) User Manual - Model ZIB-00001

Microsoft ZIB-00001

Microsoft Surface Pro 2-in-1 Laptop/Tablet (2024) User Manual

Model: ZIB-00001

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Microsoft Surface Pro 2-in-1 Laptop/Tablet (2024). Please read this guide thoroughly to ensure optimal performance and longevity of your device.

2. PRODUCT OVERVIEW

2.1 Design and Versatility

The Microsoft Surface Pro (2024) is engineered for adaptability, functioning as both a high-performance laptop and a portable tablet. Its sleek design incorporates a built-in kickstand for flexible viewing angles and a detachable keyboard (sold separately) for seamless transitions between modes.

Your everyday apps supercharged




Figure 1: Side view of the Microsoft Surface Pro, highlighting its thin profile and USB-C ports.

OLED Specifications

PROCESSOR	MEMORY	STORAGE ²
Snapdragon® X Plus Snapdragon® X Elite	16GB or 32GB ¹ LPDDR5x RAM	Removable SSD drive 256GB, 512GB or 1TB ¹
GRAPHICS	NPU	DISPLAY
Qualcomm® Adreno™ GPU	Qualcomm® Hexagon™ (45 TOPs)	13" Touchscreen PixelSense™ Flow OLED display ³

¹ 32GB memory and 1TB storage option available for Pro with Wi-Fi only. ² See Surface.com/Storage for more details. ³ Surface Pro display has rounded corners within a standard rectangle. When measured as a standard rectangular shape the screen is 13" diagonally (actual viewable area is less).

Figure 2: Rear view of the Surface Pro with its integrated kickstand extended, providing stable support for various orientations.

2.2 Key Features

- Copilot+ PC:** This device is a Copilot+ PC, offering enhanced performance and AI capabilities designed to boost productivity.
- 13" OLED Touchscreen Display:** Experience vibrant visuals with a 13-inch OLED touchscreen, featuring a 1M:1 contrast ratio for a wider range of colors and deep blacks.
- Outstanding Performance:** Powered by Snapdragon X Elite (12 Core) or Plus (10 Core) processors with a powerful Neural Processing Unit (NPU), ensuring efficient multitasking and AI-accelerated tasks.
- All-Day Battery Life:** Enjoy up to 14 hours of battery life, with fast charging supported via Surface Connect or USB-C.
- Massive 1TB SSD Storage:** Store a large volume of photos, videos, and files with the expansive 1TB SSD.
- AI-Enhanced Studio Camera:** Equipped with HD front and rear cameras that include AI-enhanced features for optimized lighting and clear audio during video calls.
- Sustainable Design:** Constructed with recycled aluminum and featuring more replaceable components, making it a sustainable 2-in-1 device.



Figure 3: The Microsoft Surface Pro showcasing the Copilot+ PC interface on its display.

Stunning 13" OLED Screen



Figure 4: The vibrant 13-inch OLED touchscreen display of the Surface Pro.

Powered by Snapdragon X Series processors




Figure 5: The Snapdragon X Elite processor, featuring its integrated NPU for AI acceleration.

All-day battery life



Figure 6: The Surface Pro in use, emphasizing its extended battery life.

3. SETUP

3.1 What's in the Box

- Microsoft Surface Pro Device

Note: Accessories such as the Surface Pro Flex Keyboard, Surface Slim Pen, and power supply may be sold separately depending on your purchase configuration.

3.2 Initial Power On and Configuration

1. **Charge the Device:** Connect the Surface Pro to a power source using the appropriate charger. Allow it to charge for at least 30 minutes before first use.
2. **Power On:** Press and hold the power button until the Microsoft logo appears on the screen.
3. **Follow On-Screen Prompts:** Windows 11 will guide you through the initial setup process, including language selection, network connection, account setup, and privacy settings.
4. **Install Updates:** After initial setup, connect to the internet and check for system updates to ensure your device has the latest features and security enhancements.

4. OPERATING INSTRUCTIONS

4.1 Switching Between Laptop and Tablet Modes

The Surface Pro is designed for seamless transitions:

- **Laptop Mode:** Attach the Surface Pro Flex Keyboard (sold separately) to the magnetic connector at the bottom edge of the screen. Adjust the integrated kickstand to your desired viewing angle.
- **Tablet Mode:** Detach the keyboard. The device will automatically switch to tablet mode, optimizing the interface for touch and pen input.

Video 1: A brief overview of the Microsoft Surface Pro's design and functionality, demonstrating its adaptability.

4.2 Using the Touchscreen and Surface Slim Pen

- **Touch Navigation:** Use familiar touch gestures for navigation, app interaction, and content manipulation on the 13-inch OLED display.
- **Surface Slim Pen (sold separately):** For precise input, drawing, and note-taking, use the Surface Slim Pen. It offers a natural writing experience on the touchscreen.

Video 2: Demonstration of using the Surface Pro for artistic creation, highlighting the precision of the Surface Slim Pen.

4.3 Copilot+ PC Features

Leverage the integrated AI capabilities of your Copilot+ PC:

- **AI Acceleration:** Benefit from faster performance in AI-driven applications and tasks.
- **Enhanced Productivity:** Utilize AI tools for content creation, data analysis, and streamlined workflows.

AI accelerated power for ultimate multitasking



Figure 7: The Surface Pro displaying multiple applications, illustrating its AI-accelerated multitasking capabilities.

5. MAINTENANCE

5.1 General Care

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and exterior. Avoid harsh chemicals or abrasive materials.
- **Protection:** Consider using a protective case or sleeve when transporting your device to prevent scratches and damage.
- **Software Updates:** Regularly check for and install Windows updates to ensure optimal performance, security, and access to new features.

5.2 Battery Optimization

- **Charging Habits:** Avoid consistently draining the battery to 0% or keeping it at 100% for extended periods. Optimal battery health is maintained by keeping the charge between 20% and 80%.
- **Power Settings:** Adjust power settings in Windows to optimize battery life based on your usage patterns.

6. TROUBLESHOOTING

If you encounter issues with your Surface Pro, consider the following basic troubleshooting steps:

- Restart the Device:** A simple restart can often resolve minor software glitches.
- Check Connections:** Ensure all cables (power, accessories) are securely connected.
- Update Drivers and Software:** Outdated drivers or software can cause performance issues. Check Windows Update and device manager for any pending updates.
- Consult Online Support:** For more complex issues, refer to the official Microsoft Surface support website or community forums.

7. SPECIFICATIONS

Feature	Specification
Model Number	ZIB-00001
Operating System	Windows 11, Copilot+ PC
Display	13 Inches OLED Touchscreen, 1920 x 1080 pixels
Processor	Snapdragon X Elite (12 Core)
RAM	16GB DDR5 RAM
Storage	1TB NVMe M.2 SSD
Graphics Coprocessor	Adreno 6xx series
Wireless Type	802.11ax
Average Battery Life	14 Hours
Item Weight	3.68 pounds
Rear Webcam Resolution	13 MP
Color	Platinum

8. WARRANTY AND SUPPORT

For detailed warranty information, technical support, and service options, please visit the official Microsoft Support website or contact Microsoft customer service. Keep your proof of purchase for warranty claims.

Online Resources:

- [Microsoft Surface Support](#)
- [Copilot+ PC Information](#)