DOOGEE DK10

DOOGEE DK10 5G Rugged Mobile Phone User Manual

Model: DK10 | Brand: DOOGEE

Introduction

This manual provides essential information for the safe and efficient operation of your DOOGEE DK10 5G Rugged Mobile Phone. Please read this manual thoroughly before using your device to ensure proper functionality and to prevent damage.

Safety Information

Always handle your device with care. Avoid exposing it to extreme temperatures, direct sunlight for prolonged periods, or corrosive chemicals. Do not attempt to disassemble or modify the device, as this will void the warranty and may cause harm. Use only approved accessories and chargers.

What's in the Box

- DOOGEE DK10 5G Rugged Mobile Phone
- Screen Protector
- SIM Tray Ejector
- USB Cable
- USB OTG Adapter

Product Overview

The DOOGEE DK10 is a robust 5G smartphone designed for durability and high performance. It features a powerful processor, advanced camera system, and a rugged build.



Front and rear view of the DOOGEE DK10 5G Rugged Mobile Phone, highlighting its robust design and quad-camera setup.

Display



The 6.67-inch FHD+ AMOLED display with a 120Hz refresh rate provides vibrant colors and smooth visuals, protected by Gorilla Glass 5.

Processor and Memory



Powered by the Dimensity 8020 chip, the DK10 offers 32GB RAM (12GB base + 20GB virtual) and 512GB ROM, expandable up to 2TB.

Camera System



Equipped with a 50MP main camera, 50MP macro/ultra-wide, 64MP night vision, and 16MP telephoto lens, alongside a 50MP front camera for versatile photography.

Your browser does not support the video tag.

Official video demonstrating the DOOGEE DK10's Morpho Quad Camera capabilities, including night mode and anti-shake video stabilization.

Battery and Charging



The 5150mAh battery supports 120W flash charging, reaching 100% in approximately 20 minutes, and 50W wireless charging.

Durability



Constructed with Kevlar aviation material, the DK10 is IP68/IP69K and MIL-STD-810H certified for water, dust, and drop resistance.

Setup

Inserting SIM/TF Card

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM tray ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano SIM card(s) and/or TF card into the designated slots on the tray. Ensure proper orientation.
4. Carefully push the tray back into the device until it is flush with the side.

Initial Power On

Press and hold the power button (located on the side) until the DOOGEE logo appears on the screen. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

Charging the Device

Connect the USB cable to the charging port on your phone and the other end to the 120W fast charger. For wireless charging, place the device on a compatible 50W wireless charging pad. Ensure the device is centered on the pad for optimal charging.

Operating Instructions

Basic Navigation

- **Power Button:** Press and hold to power on/off or restart. Short press to lock/unlock the screen.
- **Volume Buttons:** Adjust media volume during playback or ringtone volume.
- **Touchscreen Gestures:** Swipe up for app drawer, swipe down for notification panel, pinch to zoom, etc.

Camera Usage

Open the Camera app from your home screen or app drawer. Select different modes such as Photo, Video, Portrait, Macro, Ultra-Wide, Night Vision, and Telephoto. Tap the shutter button to capture images or start/stop video recording. Utilize the Morpho AI features for enhanced image quality and stabilization.

Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth to pair with other Bluetooth devices.
- **NFC:** Enable NFC in Settings > Connected devices > Connection preferences > NFC for contactless payments and data transfer.

Side Fingerprint Sensor

Register your fingerprint(s) in Settings > Security & privacy > Device unlock > Fingerprint. The side-mounted sensor allows for quick and secure unlocking of your device.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Water and Dust Resistance:** While the device is rugged, ensure all port covers are securely closed before exposing it to water or dust to maintain its IP68/IP69K rating.
- **Software Updates:** Regularly check for system updates in Settings > System > System update to ensure optimal performance and security.

Troubleshooting

Problem	Possible Solution
Device won't turn on	Ensure the battery is charged. Press and hold the power button for at least 10 seconds to force a restart.
Apps are crashing or freezing	Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the device.
Poor battery life	Reduce screen brightness, close unused apps, disable unnecessary features like GPS or Bluetooth when not in use.
Cannot connect to Wi-Fi	Restart your router. Forget the network on your phone and reconnect. Ensure Wi-Fi is enabled.

Specifications

Feature	Detail
Brand	DOOGEE
Model Name	DK10
Operating System	Android
Screen Size	6.67 Inches
Resolution	1080 x 2400
Refresh Rate	120 Hz
RAM Memory Installed Size	32 GB
Memory Storage Capacity	512 GB
Battery Capacity	5150 Milliamp Hours
Fast Charging	120W
Wireless Charging	50W
Rear Camera	50MP Main, 50MP Macro/Ultra-wide, 64MP Night Vision, 16MP Telephoto
Front Camera	50MP
Dimensions	3.27 x 0.5 x 7.15 inches
Item Weight	10.7 ounces
Water/Dust Resistance	IP68/IP69K, MIL-STD-810H
Connectivity Technologies	Bluetooth, NFC, USB, Wi-Fi

Warranty and Support

DOOGEE offers a 2-year limited warranty for the DK10. For technical support or warranty claims, please refer to the official DOOGEE website or contact their customer service. They provide 24/7 online support.
For more information, visit the DOOGEE Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question