

[Manuals.plus](#) /

› [enya](#) /

› Enya NEXG SE Smart Guitarra User Manual

enya NEXG SE

Enya NEXG SE Smart Guitarra User Manual

Model: NEXG SE | Brand: Enya

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Enya NEXG SE Smart Guitarra. The NEXG SE is an acoustic-electric carbon fiber travel guitar featuring an integrated speaker, DSP chip, and connectivity with the ENYA MUSIC App, designed for versatile musical expression anywhere.





Image 1.1: Overview of the Enya NEXG SE Smart Guitarra and its included accessories, including the protective case, wireless headset microphone, and magnetic strap components.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Enya NEXG SE Smart Guitarra
- Protective Carrying Case
- Wireless Headset Microphone
- Magnetic Guitar Strap (MS1)
- Charging Cable (USB-C)
- User Manual (this document)

3. INITIAL SETUP

3.1 Charging the Guitar

Before first use, ensure the guitar's internal battery is fully charged. Connect the provided USB-C cable to the guitar's charging port and to a compatible USB power adapter (not included). The charging indicator will provide status.

3.2 Attaching the Magnetic Strap

The MS1 magnetic strap offers a quick and secure attachment. Follow these steps:

1. Identify the male buckle of the strap. This part connects to the guitar's strap button.
2. Securely attach the male buckle to the strap button located at the base of the guitar.



Image 3.1: Attaching the male buckle of the MS1 magnetic strap to the guitar's strap button.

3. Bring the female buckle of the strap close to the male buckle. They will automatically click, attach, and lock together using powerful magnets.



Image 3.2: The magnetic connection mechanism of the MS1 strap, showing the female buckle engaging with the male buckle attached to the guitar.

4. To detach, manually pull the buckles apart. The design ensures secure attachment during use and easy detachment when needed.



Image 3.3: The MS1 magnetic strap fully attached to the Enya NEXG SE guitar, ready for playing.

3.3 Connecting the Wireless Headset Microphone

The NEXG SE comes with a wireless headset microphone for vocal performance. Power on the microphone and ensure it is paired with the guitar. Refer to the microphone's specific instructions for pairing details. Once connected, your vocals will be processed through the guitar's onboard speaker.



NEXG SE

Sing & Play Anywhere

NEXG SE comes with a wireless headset mic. Combined with the onboard speaker, you've basically got a Karaoke machine. The Vocal Removal is built in for sing-alongs. Sing it out. Play it out, anytime, anywhere.



Image 3.4: The wireless headset microphone included with the Enya NEXG SE, designed for vocal input during performance.

3.4 ENYA MUSIC App Installation

For full functionality and customization, download the ENYA MUSIC App from your device's app store. The app allows you to control DSP settings, store presets, and access advanced features.

4. OPERATING INSTRUCTIONS

4.1 Onboard Speaker System

The NEXG SE features an integrated speaker system, allowing for amplified sound without external equipment. This system is designed to produce a rich and dynamic sound experience directly from the guitar.



Guitar With A Speaker

The FEATURE of the entire NEXG line is the onboard speaker. NEXG SE is no exception to that. We deeply believe that a speaker inside can make it sound way better than normal acoustic guitars. The singing & playing experience is second to none.



Image 4.1: An exploded view illustrating the internal speaker components of the Enya NEXG SE guitar, highlighting its integrated sound system.



The Onboard Speaker

The speaker is thoroughly developed to deliver better sonic performance: louder volume, wider dynamic range, and prominent frequency response.



Image 4.2: A detailed view of the Enya NEXG SE's onboard speaker, emphasizing its design for enhanced sonic performance.


4.2 Digital Signal Processor (DSP)

The guitar includes a DSP chip that allows for various sound effects and tone shaping. You can store up to 4 onboard presets directly on the guitar. Further customization and expansion of presets are available through the ENYA MUSIC

App.

4.3 Color Display Screen

Navigate through presets and functionalities using the intuitive color display screen. This screen provides visual feedback on your current settings and selections.



NEXG SE

Color Display Screen

A color display screen makes navigating through the presets and functionalities intuitive. All the presets are expandable through ENYA MUSIC App.



Image 4.3: The color display screen of the Enya NEXG SE, showing various preset options like "Acous," "Rock," and "Fusion Lab."

4.4 ENYA MUSIC App Features

The ENYA MUSIC App unlocks the full potential of your NEXG SE. Key features include:

- **EQ and Reverb Settings:** Adjust equalization and reverb effects for both the guitar and the wireless microphone.
- **Preset Management:** Create, save, and load an unlimited number of custom presets.
- **Profiling Feature:** Copy the tone from other acoustic guitars onto your NEXG SE, offering extensive sound versatility.
- **Vocal Removal:** Utilize the vocal removal feature for sing-alongs, effectively turning any song into a karaoke track.



Your Own Sound

We've developed an App for you to further customize your own sound. The Profiling feature allows you to copy the tone from any other acoustic guitar onto NEXG SE. The versatility is incredible.



Image 4.4: A visual representation of the ENYA MUSIC App interface, showcasing its effects and sound profiling capabilities for customizing the guitar's tone.

5. MAINTENANCE

5.1 Cleaning

The carbon fiber body of your NEXG SE is durable and easy to clean. Use a soft, dry, lint-free cloth to wipe down the guitar after each use. For stubborn smudges, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or solvents.

5.2 String Replacement

Regularly inspect your guitar strings for wear and tear. Replace strings as needed to maintain optimal tone and playability. Refer to standard guitar string replacement procedures.

5.3 Storage

When not in use, store your NEXG SE in its protective carrying case to shield it from dust, impacts, and extreme temperature fluctuations. Avoid prolonged exposure to direct sunlight or high humidity.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from onboard speaker.	Guitar is off or battery is low. Volume is turned down. Speaker is muted.	Ensure guitar is powered on and charged. Increase volume. Check if speaker is accidentally muted via controls or app.
Wireless microphone not working.	Microphone is off or not paired. Microphone battery is low.	Ensure microphone is powered on and correctly paired with the guitar. Charge the microphone.
ENYA MUSIC App not connecting.	Bluetooth is off on device or guitar. App requires update.	Ensure Bluetooth is enabled on both your device and the guitar. Restart the app and guitar. Check for app updates.
Magnetic strap detaches unexpectedly.	Improper attachment. Excessive force applied.	Ensure both male and female buckles are fully engaged and clicked into place. Avoid sudden, strong tugs on the strap.

7. SPECIFICATIONS

Feature	Detail
Model	NEXG SE
Body Material	Carbon Fiber
Top Material	Carbon Fiber
Back Material	Carbon Fiber
Neck Material Type	Carbon Fiber
Number of Strings	6
Guitar Bridge System	Adjustable
Onboard Features	Integrated Speaker, DSP Chip, Color Display Screen

Feature	Detail
Connectivity	Bluetooth (for ENYA MUSIC App)
Included Accessories	Protective Case, Wireless Headset Mic, Magnetic Strap

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Enya website or contact Enya customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.
Official Enya Store: [Visit the Enya Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question