

YOUULAR Xiaomi Redmi Pad 10.61 inch

YOUULAR Tablet Case Instruction Manual

For Xiaomi Redmi Pad 10.61 inches (Model: 22081283G)

1. INTRODUCTION

Thank you for choosing the YOUULAR Tablet Case. This heavy-duty, multi-functional case is designed to provide comprehensive protection for your Xiaomi Redmi Pad 10.61 inches, safeguarding it against accidental drops, scratches, and bumps. It features a 360° rotating kickstand, an adjustable wrist strap, and a removable shoulder strap for enhanced portability and usability. This manual will guide you through the installation, operation, and maintenance of your new tablet case.

2. PRODUCT FEATURES

- **Multi-Layer Protection:** Constructed with a hard plastic shell, a hard PC inner shell, and a soft silicone skin to absorb impact and provide robust defense.
- **360° Rotating Kickstand:** Built-in sturdy kickstand allows for multiple viewing angles in both portrait and landscape orientations.
- **Adjustable Wrist Strap:** Ergonomic hand strap for secure and comfortable one-handed holding, ideal for presentations or on-the-go use.
- **Removable & Adjustable Shoulder Strap:** Convenient for carrying your tablet like a bag, perfect for travel, work, or for children.
- **Shock Absorbent Design:** Features reinforced rubber corners for excellent drop protection.
- **Precise Cutouts:** Ensures full access to all ports, buttons, and camera without removing the case.



Image: Front and back view of the YOULAR tablet case, highlighting its robust design and integrated stand.



SHOCK ABSORBENT

4 reinforced rubber corners provide excellent shockproof drop protection.

Image: Close-up showing the reinforced rubber corners designed for shock absorption.

3. PACKAGE CONTENTS

- 1 x Heavy Duty Anti-Fall Tablet Case (Red Rose+Pink)

4. COMPATIBILITY

This tablet case is specifically designed for the **Xiaomi Redmi Pad 10.61 inches**, model number **22081283G** (dimensions: 250.5 x 158.1 x 7.1 mm / 9.86 x 6.22 x 0.28 in).

Important: Before installation, please verify your tablet model by navigating to *Settings > General > About > Tablet name* on your device. Ensure the model number matches to guarantee a perfect fit.

5. SETUP AND INSTALLATION

Follow these steps to properly install your tablet into the YOUULAR case:

1. **Disassemble the Case:** Carefully separate the three layers of the case: the soft silicone outer skin, the hard PC inner shell, and the hard plastic front frame. The hard plastic front frame is typically snapped into the hard PC inner shell.

2. **Insert Tablet:** Place your Xiaomi Redmi Pad 10.61 inches into the hard plastic front frame, ensuring all edges are securely seated.
3. **Reassemble Inner Shell:** Snap the hard PC inner shell onto the front frame with the tablet inside. Make sure all clips align and click into place around the tablet.
4. **Apply Silicone Skin:** Gently stretch and fit the soft silicone outer skin over the assembled hard PC inner shell and front frame. Ensure all corners and edges are fully covered and the ports are aligned with the case cutouts.

3 Layers Multi-Functional Case

Shock Proof / Built-in Kickstand / Shoulder & Hand Strap



Image: Exploded view illustrating the three layers of the case and how they fit together with the tablet.

6. OPERATING INSTRUCTIONS

6.1 Using the 360° Rotating Kickstand

The built-in kickstand is located on the back of the case. To use it, simply pull out the kickstand from its recessed position. It can rotate 360 degrees, allowing you to position your tablet in various viewing angles for typing, watching videos, or video calls, in both landscape and portrait orientations. Push it back into place when not in use.



360 Degree Rotation Kickstand

Comfortable grip your ipad steady with one handed



360° Rotatable



Hand Strap

Image: Demonstrates the 360-degree rotation of the kickstand and the use of the hand strap.

360° Rotatable Kickstand

It turns into a convenient stand
Frees your hands and gives you a best viewing angle



Image: Shows the tablet case with the kickstand in various viewing positions, used by children.

6.2 Using the Adjustable Wrist Strap

The adjustable wrist strap is integrated into the rotating mechanism on the back of the case. Slide your hand through the strap to securely hold your tablet with one hand. Adjust the strap's tightness for a comfortable and secure grip, which helps prevent accidental drops and reduces hand fatigue during extended use.

6.3 Attaching and Adjusting the Shoulder Strap

The removable shoulder strap can be attached to the designated loops on the corners of the tablet case. Simply clip the strap's hooks onto these loops. Adjust the length of the strap using the buckle to suit your preference, whether you want to carry it over your shoulder or across your body. This feature is ideal for hands-free carrying, especially when traveling or for children.

ULTRA-PORTABLE SHOULDER STRAP

Detachable & Adjustable Design



Image: Shows the detachable and adjustable shoulder strap, and the tablet case being used with the strap.



Image: Various scenarios of people using the tablet case, demonstrating the shoulder strap and hand strap functionality.

7. MAINTENANCE AND CARE

To ensure the longevity and appearance of your YOUULAR tablet case, follow these simple care instructions:

- **Cleaning:** Wipe the case regularly with a soft, slightly damp cloth. For stubborn dirt, a mild soap solution can be used, but ensure no liquid enters the tablet's ports.
- **Avoid Harsh Chemicals:** Do not use strong detergents, abrasive cleaners, or solvents, as these can damage the case materials.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use for extended periods.
- **Inspection:** Periodically check the case for any signs of wear or damage, especially around the kickstand, straps, and corners, to ensure continued protection.

8. TROUBLESHOOTING

- **Case Does Not Fit:** Double-check your tablet's model number (*Settings > General > About > Tablet name*). This case is specifically for Xiaomi Redmi Pad 10.61 inches (Model: 22081283G). If your model differs, the case will not fit correctly.
- **Kickstand/Strap Issues:** Ensure the kickstand is fully extended or retracted. For straps, ensure they are

securely clipped and adjusted. If any part feels loose or damaged, inspect for proper assembly or contact customer support.

- **Buttons/Ports Not Accessible:** Verify that the tablet is correctly seated within the case and that the silicone skin is properly aligned with all cutouts.

9. SPECIFICATIONS

Feature	Detail
Product Dimensions	9.86 x 6.22 x 0.28 inches
Item Weight	13.3 ounces
Compatible Devices	Xiaomi Redmi Pad 10.61 inch (Model: 22081283G)
Materials	Hard plastic shell, Hard PC inner shell, Soft silicone skin
Color	Red Rose+Pink
Special Features	Travel, Heavy Duty Protection, Universal, Strap, Shockproof

10. WARRANTY AND SUPPORT

YOUULAR is committed to providing high-quality products and customer satisfaction. If you encounter any problems or are not satisfied with your tablet case, please do not hesitate to contact our customer service team. We aim to provide a satisfactory resolution within 24 hours and ensure you do not suffer any loss. For support, please refer to the contact information provided with your purchase or visit the official YOUULAR website.