

Manuals.plus /

› Symphony /

› Symphony Buddy Mini Portable Tabletop Air Cooler User Manual

Symphony ACOPE468

Symphony Buddy Mini Portable Tabletop Air Cooler User Manual

Model: ACOPE468

INTRODUCTION

The Symphony Buddy Mini is a compact and portable tabletop air cooler designed for personal use in various settings such as homes, offices, and small workspaces. It features a whisper-quiet operation, touch controls, and three-speed settings for customized cooling. This manual provides essential information for the safe and efficient use, setup, maintenance, and troubleshooting of your air cooler.



Image: The Symphony Buddy Mini Air Cooler, demonstrating its compact size suitable for a desk environment. Dimensions are shown as 23 cm height and 15 cm width.

PRODUCT COMPONENTS

Familiarize yourself with the main components of your Symphony Buddy Mini air cooler:

- **Air Outlet:** Where the cooled air is expelled.
- **Fan:** Circulates air through the unit.
- **Motor:** Powers the fan.
- **Water Inlet Door:** Used for filling water into the tank.
- **Touch Control Panel:** For operating the cooler's functions.
- **Type-C Port:** For power connection.
- **Water Level Indicator:** Shows the current water level in the tank.
- **Honeycomb Cooling Pad:** Absorbs water to facilitate evaporative cooling.



Image: An exploded diagram illustrating the internal and external components of the Symphony Buddy Mini air cooler, including the fan, motor, honeycomb cooling pad, water inlet door, air outlet, touch control panel, and Type-C port.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the air cooler and all accessories from the packaging. Ensure all components listed in the package inclusion (1 unit air cooler, 1 C Type USB cable, User Manual) are present.
2. **Placement:** Place the air cooler on a stable, flat surface. Ensure there is adequate space around the unit for proper airflow.
3. **Fill Water:** Open the water inlet door located at the top of the unit. Pour clean water into the tank. You may also add ice through the same inlet for enhanced cooling. Do not overfill; observe the water level indicator.



Images: Left: Demonstrates filling water into the cooler's tank. Right: Shows the water level indicator, marked 'F' for Full and 'E' for Empty.

4. **Power Connection:** Connect the provided C Type USB cable to the cooler's Type-C port. Connect the other end of the USB cable to a power source such as a power bank, laptop, or a USB adapter (5 Volts DC).



Image: The Symphony Buddy Mini Air Cooler powered by a Type-C USB cable, illustrating connectivity options with a power bank, laptop, and USB adapter.

OPERATING INSTRUCTIONS

The Symphony Buddy Mini features intuitive touch controls for easy operation.

1. **Power On/Off:** Gently touch the power icon on the control panel to turn the unit on or off.
2. **Adjust Fan Speed:** The cooler offers three-speed modes: Low, Medium, and High. Touch the fan speed indicator on the control panel to cycle through these settings. Each touch will advance the speed level.



Images: Left: Detailed view of the touch control panel with indicators for Low, Medium, and High fan speeds. Right: A finger interacting with the touch control panel to change the fan speed.

- 3. **Quiet Performance:** The cooler is designed for quiet operation, allowing you to work or relax without significant noise disturbance.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your air cooler.

- **Cleaning the Cooling Pad:** The honeycomb cooling pad is easily removable for cleaning. Periodically remove the cooling pad and rinse it with clean water to prevent mineral buildup and maintain efficiency. Ensure it is dry before reinserting.



Image: A hand demonstrating the removal of the honeycomb cooling pad for cleaning purposes.

- **Draining Water:** To drain the water tank, locate the drain plug at the bottom of the unit. Remove the plug to empty the water. This is recommended when storing the unit or if the water has been stagnant for an extended period.




Image: A hand removing the drain plug from the base of the cooler to empty the water tank.

- **Exterior Cleaning:** Wipe the exterior of the cooler with a soft, damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cooler does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely connected to both the cooler and a working power source (power bank, laptop, or USB adapter). Verify the power source is active.
Weak airflow.	Fan speed set to low; cooling pad clogged or dry.	Increase fan speed using the touch control panel. Check if the water tank is filled and the cooling pad is moist. Clean the cooling pad if necessary.
No cooling effect.	Water tank empty; cooling pad dry or dirty.	Fill the water tank. Ensure the cooling pad is saturated with water. Clean the cooling pad if there is mineral buildup. Adding ice to the water tank can enhance cooling.
Unusual noise during operation.	Obstruction in fan; unit not on a stable surface.	Turn off the unit and check for any obstructions near the fan blades. Ensure the cooler is placed on a flat, stable surface to prevent vibrations.

SPECIFICATIONS

Brand	Symphony
Model Name	BUDDY (Yellow)
Item Model Number	ACOPE468
Mounting Type	Freestanding
Special Feature	Lightweight, Portable
Colour	Yellow
Air Flow Capacity	150 Cubic Feet Per Minute
Controls Type	Touch
Recommended Uses	Personal use in homes, offices, outdoor events; gyms and makeup studios
Included Components	1N-COOLER, 1N - C Type USB cable
Product Dimensions	15D x 16W x 23H Centimeters
Voltage	5 Volts (DC)
Operation Mode	Manual
Material	Plastic
Item Weight	700 Grams

WARRANTY INFORMATION

The Symphony Buddy air cooler is protected by a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects only. Please retain your purchase receipt for warranty claims.

For warranty service, please contact Symphony customer support with your product details and proof of purchase.

CUSTOMER SUPPORT

For any queries, assistance, or service requests regarding your Symphony Buddy Mini Portable Tabletop Air Cooler, please contact Symphony Limited.

- **Manufacturer:** Symphony Limited
- **Address:** Symphony House, FP12-TP50 Bodakdev, Ahmedabad 380059
- **Phone:** +91 79 6621 1111
- **Website:** www.symphonylimited.com (Please refer to the official website for the most current contact information and support resources.)