

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [vidaXL](#) /

› [vidaXL Anthracite Gray Pine Bookcase with Drawers \(Model 374946\) Instruction Manual](#)

vidaXL 374946

vidaXL Anthracite Gray Pine Bookcase with Drawers

Model: 374946

Instruction Manual

1. INTRODUCTION

Thank you for purchasing the vidaXL Anthracite Gray Pine Bookcase with Drawers, Model 374946. This manual provides detailed instructions for the assembly, safe operation, and maintenance of your new furniture. Please read this manual thoroughly before assembly and retain it for future reference.

This vidaXL bookcase features a robust construction primarily from solid pine wood, complemented by engineered wood components and plastic handles, all finished in an anthracite gray.



Image 1.1: Front view of the assembled vidaXL Anthracite Gray Pine Bookcase with Drawers.

2. SAFETY INFORMATION

WARNING: Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over, it must be permanently fixed to the wall using the provided wall attachment device. Always use the wall attachment device supplied with the product.

- Ensure all components are present and undamaged before beginning assembly.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overtighten screws, as this may damage the material.
- Keep small parts out of reach of children during assembly.
- Periodically check all connections to ensure they remain tight.
- Do not stand or climb on the unit.
- Distribute weight evenly across shelves and drawers.



Image 2.1: Rear view of the bookcase, highlighting the wall attachment points for anti-tip safety.

3. PACKAGE CONTENTS

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Solid pine wood and engineered wood panels (various sizes for frame, shelves, and drawers)
- Plastic handles (4 pieces)
- Assembly hardware (screws, dowels, cam locks, etc.)
- Wall attachment device (straps, screws, wall plugs)

- Assembly instructions leaflet (this document)

4. SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the steps carefully. It is recommended to have two people for assembly.

Tools Required (Not Included):

- Phillips head screwdriver
- Hammer (for dowels)
- Drill (for wall attachment)
- Pencil
- Measuring tape

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Refer to the parts list to identify each piece.
2. **Assemble the Main Frame:** Connect the side panels to the top and bottom panels using the provided hardware (e.g., cam locks and dowels). Ensure all connections are secure.
3. **Install Shelves:** Insert the fixed shelf into the designated slots or attach with hardware.
4. **Assemble Drawers:** Construct the two drawers by attaching the side, front, and back panels. Install the drawer bottoms.
5. **Attach Drawer Handles:** Secure the plastic handles to the front of each drawer.
6. **Insert Drawers:** Slide the assembled drawers into their respective compartments.
7. **Attach Back Panel:** Secure the back panel to the rear of the bookcase using small nails or screws.
8. **Install Legs:** Attach the four legs to the bottom of the bookcase.
9. **Wall Attachment:** This is a critical safety step.
 - Position the bookcase in its desired location.
 - Mark the wall where the wall attachment device will be secured, ensuring it aligns with the pre-drilled holes on the back of the bookcase.
 - Drill appropriate holes in the wall (if necessary, depending on wall material) and insert wall plugs.
 - Secure the wall attachment straps to the bookcase and then to the wall using the provided screws. Ensure the bookcase is stable and cannot tip forward.




Image 4.1: Dimensional diagram of the bookcase, useful for assembly and placement planning.



Image 4.2: Close-up of a drawer handle, illustrating the design.

5. OPERATING AND USAGE

This vidaXL bookcase is designed for storing books, decorative items, multimedia devices, and other household goods. It features one open compartment and two drawers.

- **Open Compartment:** Ideal for displaying larger books, decorative objects, or frequently accessed items.
- **Drawers:** Use the two drawers for organized storage of smaller items, keeping them out of sight and protected from dust. The plastic handles facilitate easy opening and closing.
- **Weight Distribution:** Always distribute weight evenly across the shelves and within the drawers to maintain stability and prevent damage to the unit. Place heavier items on lower shelves.
- **Placement:** Ensure the bookcase is placed on a level surface. If the floor is uneven, use shims under the legs to

stabilize the unit.



Image 5.1: Bookcase with drawers open, demonstrating storage capacity.

6. MAINTENANCE

Proper care will extend the life and appearance of your bookcase.

- **Cleaning:** Wipe the surface with a dry cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the engineered wood finish.
- **Dusting:** Regularly dust the unit to prevent buildup.
- **Hardware Check:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary to maintain stability.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.
- **Moisture:** Protect the unit from excessive moisture and humidity.

7. TROUBLESHOOTING

If you encounter any issues with your bookcase, refer to the following common solutions:

- **Wobbling/Instability:**
 - Ensure the bookcase is on a level surface.
 - Check all assembly hardware (screws, cam locks) and tighten any loose connections.
 - Verify the wall attachment device is securely installed.
- **Drawers Not Sliding Smoothly:**
 - Check for any obstructions in the drawer glides.
 - Ensure the drawer assembly is correct and not warped.
 - Verify the bookcase frame is square.
- **Scratches/Minor Damage:**
 - For minor scratches, touch-up pens or furniture markers matching the anthracite gray color may be used.

If problems persist, please contact vidaXL customer support.

8. SPECIFICATIONS

Model Number	374946
Brand	vidaXL
Color	Anthracite Gray
Material	Solid Pine Wood, Engineered Wood, Plastic (handles)
Overall Dimensions (W x D x H)	31.5" x 15.7" x 35.4" (80 cm x 40 cm x 90 cm)
Drawer Outer Size (W x H)	29.7" x 8.7" (75.5 cm x 22 cm)
Compartment Dimensions (W x D x H)	29.9" x 15.4" x 12.4" (76 cm x 39 cm x 31.5 cm)
Number of Drawers	2
Number of Open Compartments	1
Assembly Required	Yes
Special Feature	Wall attachment device included

9. WARRANTY INFORMATION

vidaXL products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official vidaXL website. Keep your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact vidaXL customer support through their official website or the retailer where you purchased the product. Please have your model number (374946) and proof of purchase ready when contacting support.

You can visit the vidaXL store online: [vidaXL Store](#)