

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gabba Goods](#) /
- › [Gabba Goods Kids Cat Karaoke Speaker and Microphone Instruction Manual](#)

## Gabba Goods Kids Cat Karaoke Speaker and Mic

# Gabba Goods Kids Cat Karaoke Speaker and Microphone Instruction Manual

Model: Kids Cat Karaoke Speaker and Mic

## INTRODUCTION

---

This manual provides comprehensive instructions for the Gabba Goods Kids Cat Karaoke Speaker and Microphone. Please read this manual carefully before using the product to ensure proper operation and to maximize your experience. This device is designed to provide an interactive audio experience for children, featuring a speaker and a detachable microphone.

## PRODUCT FEATURES

---

- **Playful Cat Design:** Features a cat-themed design.
- **High-Quality Sound:** Provides clear and amplified audio output.
- **Wireless Connectivity:** Supports Bluetooth for device connection.
- **Easy Operation:** Designed for user-friendly control.
- **Compact and Portable:** Lightweight for easy transport.
- **Rechargeable Battery:** Offers extended playtime on a single charge.
- **Detachable Microphone:** Included for vocal performances.
- **Color Changing LED Lights:** Integrated lighting effects.
- **Micro SD and USB Drive Support:** Allows playback from external storage.



This image displays the Gabba Goods Kids Cat Karaoke Speaker and Microphone. The speaker unit is white with a pink cat-face grille, and the detachable microphone is pink with a silver head. Both are designed for child use.

## PACKAGE CONTENTS

Please verify that all items are present in the package:

- Gabba Goods Kids Cat Karaoke Speaker
- Detachable Microphone
- Charging Cable (USB)



The front of the product packaging for the Gabba Goods Kids Cat Karaoke Party speaker and microphone. It highlights features such as a detachable microphone, LED lights, HD quality sound, and up to 8 hours of playtime.

## SETUP

### 1. Charging the Speaker:

- Connect the provided USB charging cable to the speaker's charging port.
- Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.

- The charging indicator light will illuminate during charging and turn off or change color when fully charged. Allow approximately 2-3 hours for a full charge.

## 2. Connecting the Microphone:

- Locate the microphone input port on the speaker unit.
- Insert the microphone cable securely into the input port.

## 3. Powering On:

- Press and hold the Power button on the speaker until the indicator light turns on and you hear an audible prompt.

# OPERATING INSTRUCTIONS

---

## 1. Bluetooth Pairing:

- With the speaker powered on, it will automatically enter Bluetooth pairing mode (indicated by a flashing light or audible prompt).
- On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
- Select "Gabba Goods Karaoke" (or similar name) from the list to connect.
- Once connected, you will hear a confirmation sound, and the indicator light will become solid.

## 2. Playing Music:

- **Via Bluetooth:** After pairing, play music from your connected device. The speaker will output the audio.
- **Via Micro SD Card:** Insert a Micro SD card (with music files) into the designated slot. The speaker will automatically switch to SD card mode and begin playback.
- **Via USB Drive:** Insert a USB flash drive (with music files) into the USB port. The speaker will automatically switch to USB mode and begin playback.

## 3. Microphone Usage:

- Ensure the microphone is connected and its power switch (if applicable) is in the 'ON' position.
- Speak or sing into the microphone. Your voice will be amplified through the speaker.

## 4. Volume Control:

- Use the volume buttons on the speaker (usually '+' and '-') to adjust the overall sound level.
- You can also adjust the volume from your connected Bluetooth device.

## 5. LED Lights:

- The speaker features color-changing LED lights. Refer to the specific button on the speaker (if labeled) to cycle through light modes or turn them off.

## 6. Powering Off:

- Press and hold the Power button until the indicator light turns off and you hear an audible prompt.

# MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the speaker and microphone. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the device regularly, even if not in frequent use. Avoid fully depleting the battery for extended periods.

## TROUBLESHOOTING

Problem	Possible Solution
No power	Ensure the speaker is fully charged. Connect to a power source and allow it to charge for at least 30 minutes before attempting to power on again.
No sound from speaker	Check the volume level on both the speaker and the connected device. Ensure the device is properly paired via Bluetooth or that the Micro SD/USB is correctly inserted.
Microphone not working	Ensure the microphone is securely plugged into the speaker's input port. Check if the microphone has an 'ON/OFF' switch and that it is in the 'ON' position.
Bluetooth connection issues	Ensure the speaker is in pairing mode. Turn off and on Bluetooth on your device, then try pairing again. Move the speaker closer to your device to reduce interference.

## SPECIFICATIONS

Feature	Detail
Brand	Gabba Goods
Model	Kids Cat Karaoke Speaker and Mic
Power Source	Battery Powered
Speaker Count	1
Connectivity	Bluetooth, Micro SD, USB
Item Weight	1.74 pounds
Package Dimensions	9.41 x 8.98 x 4.8 inches

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Gabba Goods website. Keep your proof of purchase for any warranty claims.