

[Manuals.plus](#) /

› [Piskyet](#) /

› Piskyet Wooden Dog Crate Furniture with Rotatable Bowls and Removable Tray Instruction Manual

Piskyet DKM-02

Piskyet Wooden Dog Crate Furniture with Rotatable Bowls and Removable Tray Instruction Manual

Model: DKM-02

INTRODUCTION

Thank you for choosing the Piskyet Wooden Dog Crate Furniture. This product is designed to provide a comfortable and secure space for your dog while also serving as a functional piece of furniture in your home. Please read this manual carefully before assembly and use to ensure proper installation and safe operation. Keep this manual for future reference.

Important Safety Information

- This product is intended for crate-trained dogs only. It is not suitable for heavy chewers or escape artists.
- Ensure all parts are securely fastened before allowing your pet to use the crate.
- Do not allow children to play inside or on the crate.
- Regularly inspect the crate for any damage or loose parts. Discontinue use if damage is found.
- Place the crate on a flat, stable surface.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Wooden panels (top, bottom, sides, doors)
- Metal grates for doors
- Hardware kit (screws, bolts, hinges, door latches)
- Removable ABS+PP thickened tray
- 360° rotatable dog bowl holder with two 304 food-grade stainless steel bowls
- Double 'S' hooks for side panel
- Assembly tools (usually an Allen wrench)

SETUP AND ASSEMBLY INSTRUCTIONS


Assembly typically requires two people. Follow the step-by-step instructions provided in the included assembly guide. Ensure all connections are tight and secure.

Key Assembly Points:

1. **Frame Assembly:** Connect the side panels to the bottom and top panels using the provided hardware. Ensure the panels are aligned correctly.
2. **Door Installation:** Attach the double doors to the front frame using the hinges. The side door can be installed on either the left or right side, depending on your preference. Secure the spring-loaded locks on the doors.
3. **Tray Insertion:** Slide the removable ABS+PP thickened tray into the designated slot at the bottom of the crate. Ensure the bone-shaped lock is engaged to prevent the tray from slipping out.
4. **Bowl Holder Attachment:** Install the 360° rotatable dog bowl holder on the side panel. Ensure it can rotate smoothly for both internal and external use.
5. **Accessory Hooks:** Attach the double 'S' hooks to the side panel for hanging leashes or toys.

Sturdy And Noiseless Structural Design

- Two built-in spring-loaded locks on the top and bottom of the door lock tightly without slipping or shaking, greatly enhancing the stability of the kennel door.
- The dog bone can increase the firmness of the small door and reduce noise.



Side doors can be placed on the left or right side


Figure 1: Structural design with door locks and accessory hooks.

Perfect for Medium Dogs


When the dog bowl stand is used **outside crate**, this crate inside space is **30*20*23.5 inches**.

When the dog bowl stand is used **inside crate**, the interior space is **23.5*20*23.5 inches**.

Note: This product is not suitable for dogs with severe chewing habits!



304 Stainless Bowl Capacity: 14 oz



Swivel Locking Dog Bowl Holder

Figure 2: Overall dimensions and internal layout of the dog crate.

Video 1: Demonstrates the assembly process, including opening the doors and rotating the food bowls. This video provides a visual guide to the crate's features and functionality.

OPERATING INSTRUCTIONS

Using the Double Doors:

The front of the crate features two doors equipped with spring-loaded locks. To open, simply disengage the top and bottom bolt locks and pull the handles. To secure, close the doors and engage both locks. The design ensures the doors remain stable and do not rattle when closed.

360° Rotatable Dog Bowls:

The dog crate includes a unique 360° rotatable feeder with two 304 food-grade stainless steel bowls. This feature allows you to position the bowls either inside or outside the crate. To rotate, unlock the mechanism on the side panel and gently pivot the bowl holder to the desired position. Lock it in place once positioned.

DETACHABLE 360° SWIVEL DOG BOWLS

The dog bowl can be used inside/outside the crate



Figure 3: Detachable 360° swivel dog bowls for flexible feeding options.

Video 2: Demonstrates the functionality of the rotatable dog bowls, showing how they can be moved from inside to outside the crate.

Removable Tray:

The crate is equipped with a durable, odor-resistant ABS+PP thickened tray. This tray can be easily pulled out for cleaning. To remove, disengage the bone-shaped lock at the front and slide the tray out. After cleaning, slide it back in

and re-engage the lock to secure it.

Why Choose Tray?

The inside of the crate needs to be kept dry and regularly sprayed with a disinfectant to avoid the growth of bacteria that can affect the dog's health, which cannot be done with wood.



Easy to use and clean
Simply slide out easily to sanitize and decontaminate the interior and dispose of hair and dirt inside the crate.



There are 5 felt pads underneath the tray, so you don't have to worry about scratching your floor when you move it.



Bone lock ensures tray won't slip out of crate

Figure 4: Removable tray for easy cleaning and maintenance.

Side Door Access:

In addition to the front doors, the crate features a side door for alternative access. This door also has a lock mechanism. Open the side door to allow your dog to enter or exit from the side, or to access the interior for cleaning or placing bedding.

MAINTENANCE

Cleaning the Tray:

The removable tray should be cleaned regularly to maintain hygiene. Simply slide it out, dispose of any waste, and wash with mild soap and water. Rinse thoroughly and dry before returning it to the crate.

Crate Surface Cleaning:

Wipe down the wooden surfaces with a damp cloth. Avoid harsh chemicals that could damage the finish. For deeper cleaning, use a wood-safe cleaner. Ensure the crate is completely dry after cleaning.

Bowl Cleaning:

The stainless steel bowls are dishwasher safe. Wash them regularly to prevent bacterial growth.

Hardware Inspection:

Periodically check all screws, bolts, and latches to ensure they are tight. Tighten any loose hardware to maintain the crate's structural integrity.

TROUBLESHOOTING

Dog Not Adapting to Crate:

If your dog is hesitant to enter or stay in the crate, ensure it is a positive and comfortable space. Place familiar bedding, toys, and treats inside. Never use the crate as punishment. Consult a professional dog trainer for persistent issues.

Crate Instability:

If the crate feels wobbly, re-check all assembly connections and tighten any loose screws or bolts. Ensure the crate is placed on a level surface.

Tray Not Sliding Smoothly:


Check for any debris or obstructions in the tray's runners. Ensure the bone-shaped lock is fully disengaged when attempting to slide the tray. Lubricate runners if necessary with a pet-safe lubricant.

SPECIFICATIONS

Feature	Detail
Model Number	DKM-02
Material	High-density MDF Wood, Metal Grates, ABS+PP Tray, 304 Stainless Steel Bowls
Product Dimensions (Overall)	80.8L x 56.1W x 61.2H Centimetres (31.8"L x 22.1"W x 24.1"H)
Crate's Inner Size (M)	30"L x 20.1"W x 23.7"H (for dogs up to 35 lbs)

Feature	Detail
Crate's Inner Size (L)	35.9"L x 23.1"W x 25.7"H (for dogs up to 60 lbs)
Crate's Inner Size (XL)	41.4"L x 26.6"W x 29.8"H (for dogs up to 90 lbs)
Special Features	360° Rotatable Removable Dog Bowls, Removable Tray, Double Doors, Side Door Access, Accessory Hooks
Weight Capacity (Top)	Up to 200 lbs (static weight)
Intended Use	Indoor

Please measure your dog to ensure the best fit.



How to choose the right crate for your dog?

Length: Measure the length from tail to nose of dog standing up.

Height: Measure the height from the bottom of the dog sitting down to the top of the head.

*Measured length and height +3-4inch to ensure sufficient room for movement

Crate	Crate size	Dog Weight	Dog Breeds
M 	Whole size 31.8" L x 22.1" W x 24.1" H Crate's inner size 30" L x 20.1" W x 23.7" H	Up to 45 lb	French Bulldog Basenji Dachshund Bull
L 	Whole size 37.7" L x 25.1" W x 26.1" H Crate's inner size 35.9" L x 23.1" W x 25.7" H	Up to 60 lb	Welsh Corgi Harrier Bulldog
XL 	Whole size 43.2" L x 28.6" W x 30.3" H Crate's inner size 41.4" L x 26.6" W x 29.8" H	Up to 80 lb	Airedale Terrier Golden Retriever Bearded Collie

Figure 5: Size guide to help select the appropriate crate size for your dog.

WARRANTY INFORMATION

Piskyet products are manufactured with quality and durability in mind. This product comes with a limited warranty against manufacturing defects. Please retain your proof of purchase. For specific warranty terms and conditions, refer to the product packaging or contact customer support.

SUPPORT

If you have any questions, concerns, or require assistance with your Piskyet Wooden Dog Crate Furniture, please do not hesitate to contact our customer support team. You can typically find contact information on the order page where you purchased the product or on the manufacturer's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CXPQ1H6L>

More documents and user manuals: <https://manuals.plus/>