

## LEMBERI 58TVS

# LEMBERI 58-Inch Fireplace TV Stand with 18-inch Electric Fireplace and LED Lighting User Manual

Model: 58TVS

## 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your LEMBERI 58-inch Fireplace TV Stand, Model 58TVS. This entertainment center is designed to accommodate TVs up to 65 inches and features an integrated 18-inch electric fireplace and customizable LED lighting. Please read this manual thoroughly before assembly and use to ensure safe and correct operation.



Image 1.1: The LEMBERI 58-inch Fireplace TV Stand in a living room setting, showcasing its integrated electric fireplace and blue LED accent lighting.

## 2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all components are present and undamaged before assembly. Do not use damaged parts.
- Assembly should ideally be performed by two adults.
- Keep small parts and packaging materials away from children.
- Do not overload the TV stand. The tabletop supports up to 300 lbs, and each adjustable shelf supports up to 22 lbs.
- Place the TV stand on a flat, stable surface to prevent tipping.
- For the electric fireplace, ensure it is connected to a grounded outlet. Do not run the power cord under carpets or in high-traffic areas.
- Do not block the air intake or exhaust vents of the electric fireplace. Maintain clear space around the unit.

- Do not touch the fireplace heating element when in operation, as it can become hot.
- Unplug the fireplace from the power outlet before cleaning or performing any maintenance.

### 3. PACKAGE CONTENTS

Verify that all items listed below are included in your package. The cabinet is shipped in two separate boxes.

- TV Stand components (MDF panels, hardware)
- 18-inch Electric Fireplace insert
- Electric Fireplace Remote Control
- LED Light strip with remote control
- Power outlet (integrated into the stand for the fireplace)
- Adjustable Tempered Glass Shelves (4 pieces)
- Assembly Instruction Manual



## 4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the step-by-step instructions provided in the separate assembly manual included in your package. It is recommended that two people assemble the unit.

### 4.1 Tools Required

- Phillips head screwdriver
- Drill (recommended for fireplace installation)

### 4.2 Key Assembly Steps

1. Unpack all components and verify against the parts list.
2. Assemble the main frame of the TV stand according to the diagrams.
3. Install the adjustable tempered glass shelves into the side compartments. These shelves can be repositioned to suit your storage needs.
4. Carefully insert the 18-inch electric fireplace into the central opening. Note: There are no pre-drilled holes for attaching the fireplace to the furniture. Use a drill to create pilot holes and secure the fireplace with the provided screws.
5. Install the LED light strips along the designated areas.
6. Utilize the cable management holes at the back of the TV stand to organize wires and cables for electronic devices.

# STORAGE

The built-in adjustable shelves make it easy to customize the space according to your needs.



Adjustable & Removable  
Tempered Glass Shelves



One Tier



Two Tier



Three Tier

Image 4.1: Adjustable and removable tempered glass shelves for customizable storage.

## 5. OPERATING INSTRUCTIONS

### 5.1 Electric Fireplace Operation

The electric fireplace can be operated using the control panel on the unit or the included remote control.

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** Select from 5 temperature settings ranging from 65°F to 95°F. The fireplace can heat rooms up to 350 sq. ft.
- **Flame Effect:** The 3D realistic flame effect can be operated independently with or without heat. The flame color cannot be changed, but its brightness can be adjusted from L1 to L5 levels.
- **Timer:** Set an automatic shut-off timer for 1 to 8 hours.
- **Digital LED Display:** Shows current settings for temperature, timer, and flame brightness.



Image 5.1: Electric fireplace remote control functions.

## 5.2 LED Lighting Operation

The integrated LED lights offer 16 color options to enhance your room's ambiance.

- Use the dedicated remote control for the LED lights to change colors.
- Cycle through the 16 available colors to match your mood or decor.



Image 5.2: The 16 color options for the integrated LED lighting.

## 6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your TV stand.

- **Cleaning the TV Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. The upgraded board material is scratch-resistant, waterproof, and easy to clean.
- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft cloth to wipe the exterior. Do not spray liquids directly onto the unit.
- **Glass Shelves:** Clean glass shelves with a standard glass cleaner.
- **Cord Management:** Periodically check that all cables are neatly organized through the cable holes and are not pinched or damaged.

# Newly Upgraded Board



Scratch-resistant



Waterproof



Easy to clean



Long-time Usage

Image 6.1: Features of the newly upgraded board material.

## 7. TROUBLESHOOTING

- **Fireplace not turning on:** Check if the power cord is securely plugged into a grounded outlet. Ensure the power button on the unit or remote is pressed.
- **Fireplace not heating:** Verify that the heat setting is activated and the temperature is set above the current room temperature. Ensure air vents are not obstructed.
- **Flame effect not working:** Check power connection. If the flame brightness is set to L1, try increasing it.
- **LED lights not changing color:** Ensure the LED remote control has working batteries and is pointed directly at the receiver.
- **Assembly difficulties:** Refer to the detailed assembly manual. Ensure all parts are correctly oriented. If screws are difficult to insert for the fireplace, using a drill to create pilot holes is recommended.

## 8. SPECIFICATIONS

Feature	Detail
Brand	LEMBERI
Model Name	58TVS
Product Dimensions	58"W x 15.75"D x 24.06"H (approximate)
Material	Tempered Glass, Wood (MDF with laminate/veneer finish)
Power Source	Corded Electric
Heat Output	750 Watts
Heating Coverage	Up to 350 sq ft
Special Features	Flame Effect, Timer, LED Lighting (16 colors), Adjustable Glass Shelves, Cable Management
Color	Black
Item Weight	80 Pounds
TV Size Compatibility	Up to 65 Inches

---

## 9. WARRANTY

This LEMBERI product comes with a Limited Warranty. For specific details regarding coverage, duration, and terms, please refer to the warranty information provided with your purchase or contact LEMBERI customer support directly.

---

## 10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter issues not covered in this manual, please contact LEMBERI customer support. Refer to your purchase documentation for contact information or visit the official LEMBERI website.