Zilan ZLN9334

Zilan ONYX Multifunction Food Processor with Wi-Fi (Model ZLN9334) - User Manual

Model: ZLN9334

1. Introduction

Thank you for choosing the Zilan ONYX Multifunction Food Processor. This appliance is designed to simplify your cooking experience with its versatile functions and smart connectivity. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Image 1.1: The Zilan ONYX Multifunction Food Processor, showcasing its main unit, control panel, and a smartphone displaying the companion app interface.

2. Important Safety Instructions

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Ensure all parts are correctly assembled and locked in place before operating the appliance.
- Do not operate the appliance with a damaged cord or plug. Contact customer service for repair.
- This appliance is for household use only. Do not use outdoors.
- Exercise caution when handling sharp blades and hot liquids.
- Keep the appliance out of reach of children.

3. Product Components

The Zilan ONYX Food Processor comes with several components designed for various cooking tasks. Familiarize yourself with each part before use.



Image 3.1: Overview of the Zilan ONYX Food Processor, highlighting key features such as Wi-Fi connectivity, 1700W power, digital LED display, timer, turbo function, and integrated scale.



Image 3.2: Detailed view of all included accessories: Steamer Lid, Steamer Rack, Steamer Body, Jar Lid, 3.3 Liter Stainless Steel Jar, Kneading Blade, Mixing Blade, Butterfly Whisk, Spatula, and Filter Basket. All accessories are dishwasher-safe.

- **Main Unit:** Contains the motor, control panel, and digital LED display.
- **Stainless Steel Jar (3.3L Max):** Used for blending, heating, and mixing. Capacity is 2L for blending and 2.3L for heating.
- **Jar Lid:** Secures the jar during operation.
- **Kneading Blade:** For dough preparation.
- **Mixing Blade:** For general chopping and mixing.
- **Butterfly Whisk:** For whipping and emulsifying.
- **Spatula:** For scraping and stirring.
- **Filter Basket:** For steaming or straining.
- **Steamer Set:** Includes Steamer Body, Steamer Rack, and Steamer Lid for multi-level steaming.

4. Setup and First Use

4.1 Unpacking and Cleaning

1. Carefully remove all components from the packaging.
2. Wash the stainless steel jar, lid, blades, whisk, spatula, filter basket, and steamer parts with warm soapy water. Rinse thoroughly and dry.
3. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.

4.2 Assembly

1. Place the main unit on a stable, flat, and dry surface. Ensure the suction feet are securely attached to the countertop.
2. Insert the desired blade (kneading or mixing) into the bottom of the stainless steel jar.
3. Place the jar onto the main unit, ensuring it is properly seated and locked into position.
4. Add ingredients to the jar.
5. Secure the jar lid onto the jar.



Image 4.1: Front view of the Zilan ONYX Food Processor, showing the main unit and the stainless steel jar assembled.

5. Operating Instructions

5.1 Control Panel Overview

The Zilan ONYX features a digital LED display and a rotary indicator for easy control.



Image 5.1: Side view of the Zilan ONYX Food Processor, highlighting the digital LED control panel and rotary dial.

- **Digital LED Display:** Shows time, temperature, speed, and Wi-Fi status.
- **Rotary Indicator:** Used to adjust settings such as time, temperature, and speed.
- **Integrated Scale:** Allows for precise weighing of ingredients directly in the jar.

5.2 Basic Operation

1. Plug the appliance into a 230V/50Hz power outlet.
2. Use the rotary indicator to select the desired function (e.g., blending, heating, kneading).
3. Adjust parameters such as speed (10 levels, 60-7000 rpm), temperature (37°C-120°C in 1°C increments), and timer (1 second to 12 hours).
4. Press the start button to begin operation.
5. Use the **Turbo Function** for short bursts of high-speed processing.
6. The **Pause Function** allows you to temporarily stop operation without losing current settings.

5.3 Wi-Fi Connectivity and App Control

The Zilan ONYX can be controlled via a smartphone application, providing access to online recipes and remote operation.



Image 5.2: The Zilan ONYX Food Processor demonstrating its app control feature, showing the appliance next to a smartphone displaying the Tuya Smart app.

1. Download the "Tuya Smart" app from the App Store (iOS) or Google Play Store (Android). You can find the app at https://smartapp.tuya.com/tuyasmart.
2. Register or log in to your Tuya Smart account.
3. Ensure your Zilan ONYX is powered on and in pairing mode (refer to the appliance display for Wi-Fi indicator status).
4. In the app, follow the instructions to add a new device. Select "Small Home Appliances" or "Food Processor" if available.
5. Connect the appliance to your home Wi-Fi network (2.4GHz only).
6. Once connected, you can access online recipes, control functions, and receive notifications from the app.



Image 5.3: The Zilan ONYX Food Processor's cloud recipe feature, showing a smartphone displaying various recipe categories and a "Step by Step Guide Cooking" icon.

5.4 Multi-Level Cooking

The Zilan ONYX supports preparing up to four different dishes simultaneously using its multi-level steaming function.



Image 5.4: An example of multi-level cooking with the Zilan ONYX, showing a main dish, side dishes, and a drink prepared concurrently.

1. Fill the main jar with water or a liquid base for steaming.
2. Place ingredients in the filter basket and/or the steamer body and rack.
3. Assemble the steamer components on top of the jar.
4. Select the steaming function and set the desired time and temperature.

6. Care and Maintenance

6.1 Cleaning

- Always unplug the appliance before cleaning.
- The stainless steel jar, blades, whisk, spatula, filter basket, and steamer parts are**dishwasher-safe**.
- For manual cleaning, wash these parts with warm soapy water and a non-abrasive sponge. Rinse thoroughly and dry.

- Wipe the main unit and control panel with a soft, damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- Ensure all parts are completely dry before storing or reassembling.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; appliance not assembled correctly.	Ensure the power cord is securely plugged in. Check the power outlet with another device. Verify the jar is correctly seated and locked on the main unit.
Wi-Fi connection fails.	Incorrect Wi-Fi password; 5GHz network used; appliance too far from router; app pairing issue.	• Double-check your Wi-Fi password. • Ensure you are connecting to a 2.4GHz Wi-Fi network. The appliance does not support 5GHz. • Move the appliance closer to your Wi-Fi router. • Restart the appliance and your router, then try pairing again through the Tuya Smart app.
Blades are not rotating.	Jar lid not secured; too much food; food is too hard.	Ensure the jar lid is properly closed. Reduce the amount of food. Cut hard ingredients into smaller pieces.
Appliance stops during operation.	Overload protection activated; overheating.	Unplug the appliance and let it cool down for at least 30 minutes. Reduce the load before restarting.

8. Technical Specifications

Feature	Specification
Model Number	ZLN9334
Brand	Zilan
Functions	30 (including weighing, blending, heating, kneading, steaming, chopping, grinding, pureeing, slicing)
Power Supply	230 V / 50 Hz
Total Power	1700 W
Motor Power	700 W
Motor Speed	60 - 7000 rpm (10 levels)
Heating Power	1000 W
Temperature Range	37°C - 120°C (1°C increments)
Jar Capacity	3.3 L (Max), 2 L (Blending), 2.3 L (Heating)
Jar Material	SUS304 Stainless Steel

Feature	Specification
Timer	1 second - 12 hours
Connectivity	Wi-Fi (2.4GHz)
Dimensions (L x W x H)	30 x 46 x 44 cm
Weight	7 kg
Dishwasher Safe Parts	Jar, blades, whisk, spatula, filter basket, steamer parts

9. Customer Support

For further assistance, technical support, or warranty inquiries, please contact Zilan customer service. Refer to your purchase documentation for specific contact details.

Note: Information regarding spare parts availability is not provided in the product specifications.

© 2025 Zilan. All rights reserved.