**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Red by Kiss SV-PT

# RED by Kiss Cordless Mini Shaver SV-PT Instruction Manual

Model: SV-PT

## Introduction

Thank you for choosing the RED by Kiss Cordless Mini Shaver. This compact, high-precision shaver is designed for efficient and convenient grooming, especially for travel. Please read this manual thoroughly before first use to ensure safe operation and optimal performance of your device. Keep this manual for future reference.




Image: The RED by Kiss Cordless Mini Shaver in black, showcasing its compact design.

## Important Safety Information

To reduce the risk of electric shock, injury, or damage to the shaver, always follow these basic safety precautions:

- Always hold the shaver with a firm grip to prevent accidental slips during use.
- Avoid using the shaver near water or while charging to prevent electrical hazards.
- If you experience skin irritation, discontinue use and consult a healthcare professional.
- Always clean and maintain the shaver according to the manufacturer's instructions to prevent bacterial growth and ensure optimal performance.
- Keep the shaver out of reach of children.
- Do not disassemble or attempt to repair the shaver yourself. Contact customer support for assistance.

## Product Features

- **Travel-Optimized Design:** Pocket-sized and lightweight for grooming on-the-go.
- **Powerful Motor:** Equipped with a robust motor for quick, efficient shaves.
- **Extended Battery Life:** Long-lasting lithium-ion battery provides up to 2 hours of run time.
- **Non-Slip Grip:** Ergonomic design with a no-slip grip for control, even with wet hands.
- **Titanium-Coated Foil:** Ensures a close, smooth shave while protecting skin and providing durability.
- **USB-C Charging:** Convenient and universal charging.
- **Safety Lock Feature:** Prevents accidental activation during travel.




Image: A diagram pointing out key features of the shaver, including the titanium-coated foil, non-slip grip, safety lock, and worldwide dual voltage charging port.

## Setup

### Charging the Shaver

1. Ensure the shaver is turned off before charging.

2. Locate the USB-C charging port on the shaver.
3. Connect the provided USB-C charging cable to the shaver and plug the other end into a compatible USB power source (e.g., wall adapter, computer USB port).
4. The charging indicator light will illuminate (typically red) to show that the shaver is charging.
5. Once fully charged, the indicator light will change (typically green or turn off). A full charge provides up to 2 hours of run time.



Image: A close-up view of the shaver's USB-C charging port with a cable inserted.

## Operating Instructions

### Turning On/Off

1. To turn on the shaver, slide the power switch upwards. If the safety lock is engaged, first slide the safety lock mechanism to unlock, then slide the power switch.
2. To turn off the shaver, slide the power switch downwards.
3. To engage the safety lock, slide the safety lock mechanism into the locked position after turning off the shaver. This prevents accidental activation, especially during travel.



Image: A close-up of the shaver's side, showing the power switch and safety lock feature.

### Shaving Technique

1. Ensure your skin is clean and dry before shaving.
2. Hold the shaver at a right angle (90 degrees) to your skin.
3. Gently stretch your skin with your free hand to make the hairs stand upright.
4. Move the shaver in short, circular motions or straight strokes against the direction of hair growth.
5. Apply light pressure; excessive pressure is not necessary and can cause irritation.
6. The titanium-coated foil is designed to provide a close shave while protecting your skin.
7. The non-slip grip ensures secure handling, even if your hands are slightly damp.




Image: A man demonstrating the use of the RED by Kiss Mini Shaver for facial grooming.

## Maintenance

### Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

1. Turn off and unplug the shaver before cleaning.
2. Carefully remove the foil head.
3. Use the provided cleaning brush to remove any accumulated hair from the foil and the cutting blades.
4. Do not use water directly on the cutting blades or motor unit unless specified as waterproof (this model is not explicitly stated as wet/dry).
5. Reattach the foil head securely after cleaning.




Image: A detailed view of the shaver's titanium-coated foil blade, which should be cleaned regularly.

### Blade Replacement

Over time, the foil and cutting blades may wear down, affecting shaving performance. While the manufacturer recommends replacing the blade if necessary, specific replacement parts may need to be sourced directly from the manufacturer or authorized retailers. Refer to the official Red by Kiss website for availability of replacement parts.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Shaver does not turn on. | Battery is depleted; Safety lock is engaged. | Charge the shaver fully; Disengage the safety lock. |
| Poor shaving performance / pulling hairs. | Foil or blades are dull/damaged; Shaver is dirty with hair clippings. | Clean the shaver thoroughly; Consider replacing the foil/blades if worn. |
| Shaver stops during use. | Battery is low. | Recharge the shaver. |
| Skin irritation after shaving. | Incorrect shaving technique; Dull blades; Sensitive skin. | Ensure proper technique (light pressure, against grain); Clean/replace blades; Use pre-shave preparation for sensitive skin. |

## Specifications

| Feature | Detail |
|---|---|
| Model Name | RED Mini Shaver |
| Model Number | SV-PT |
| Power Source | Battery Powered |
| Battery Type | Lithium-ion |
| Battery Life | Up to 2 hours |
| Charging Port | USB-C |
| Head Type | Foil |
| Blade Material | Titanium |

| Feature | Detail |
|---|---|
| Number of Blades | 1 |
| Color | Black (as per current product) |
| Dimensions (Package) | 5.25 x 4 x 1.25 inches |
| Weight (Package) | 6.4 ounces |
| Additional Features | Hypoallergenic, Lightweight |

## Official Product Video

Your browser does not support the video tag.

Video: An official product video showcasing the RED by Kiss Cordless Mini Shaver, highlighting its compact size, long-lasting battery, lightweight design, and powerful motor. The video demonstrates its travel-friendly nature and ease of use.

## Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please visit the official Red by Kiss website or contact their customer service directly. Keep your purchase receipt as proof of purchase.
Manufacturer: Red Beauty, Inc.
For further assistance, please refer to the Red by Kiss Store.

© 2024 Red Beauty, Inc. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0CXQ5CX7Y**

More documents and user manuals: **https://manuals.plus/**