

[Manuals.plus](#) /

› [BoxWave](#) /

› BoxWave Wall Charger Direct (15W) Instruction Manual

BoxWave KA18F-0503000US

BoxWave Wall Charger Direct (15W) Instruction Manual

Model: KA18F-0503000US

1. INTRODUCTION

The BoxWave Wall Charger Direct (15W) is a compact and efficient power adapter designed to provide rapid charging for compatible devices. It features a built-in 3-foot Micro USB cable for convenient and reliable power delivery. This manual provides essential information for the safe and effective use of your charger.



Image 1.1: The BoxWave Wall Charger Direct (15W) with its integrated Micro USB cable.

2. SAFETY INFORMATION

- Do not expose the charger to liquids or extreme temperatures.
- Do not disassemble or attempt to repair the charger.
- Ensure the wall outlet voltage is compatible with the charger's input specifications (100-240V).
- Keep out of reach of children.
- Unplug the charger from the wall outlet when not in use.

3. SETUP

Setting up your BoxWave Wall Charger Direct is a simple plug-and-play process.

1. **Identify the Micro USB Port:** Locate the Micro USB charging port on your device. The charger's cable has a Micro USB connector.
2. **Connect to Device:** Carefully insert the Micro USB connector of the charger's cable into your device's Micro USB port. Ensure a secure connection.
3. **Plug into Wall Outlet:** Insert the charger's AC prongs into a standard wall power outlet.



Simple Plug & Play Functionality

Wall Charger Direct's simplicity reduces frustration and fussing with plugging in additional cables to a separate AC adapter

Image 3.1: The charger connected to a device and plugged into a wall outlet, demonstrating simple plug-and-play functionality.

4. OPERATING INSTRUCTIONS

Once connected, the charger will automatically begin charging your device. Most devices will display a charging indicator

(e.g., a battery icon with a lightning bolt or a percentage increase).

- The charger delivers up to 15W of power for rapid charging.
- Charging time may vary depending on your device's battery capacity and current charge level.
- Disconnect the charger from your device once it is fully charged to conserve energy.



Image 4.1: A device screen indicating 95% charge and fast charging status.

5. MAINTENANCE

To ensure the longevity and optimal performance of your BoxWave Wall Charger Direct, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the charger. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger in a cool, dry place when not in use. Avoid wrapping the cable too tightly to prevent damage.
- **Cable Care:** The built-in cable features reinforced strain relief. Avoid sharp bends or excessive pulling on the cable,

especially near the connectors, to prevent wear and tear.



Reinforced Strain Relief

Rubberized connector supports keep Wall Charger Direct from kinking and tearing.



Image 5.1: Detail of the reinforced strain relief on the charger's Micro USB connector, designed for durability.

6. TROUBLESHOOTING

If you encounter issues with your charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging.	Loose connection, faulty outlet, incompatible device.	◦ Ensure the Micro USB cable is securely connected to both the charger and the device. ◦ Try plugging the charger into a different wall outlet. ◦ Verify your device uses a Micro USB port for charging.

Problem	Possible Cause	Solution
Slow charging.	Device drawing less power, background apps, cable issue.	◦ Close unnecessary applications on your device. ◦ Ensure the cable is not damaged. ◦ The charger provides 15W; some devices may have higher charging capabilities not supported by this charger.
Charger feels warm.	Normal operation during charging.	A slight warmth is normal during operation. If it becomes excessively hot or emits smoke/odor, unplug immediately and discontinue use.

7. SPECIFICATIONS

- **Model:** KA18F-0503000US
- **Input:** 100-240V ~ 50/60Hz 0.55A Max
- **Output:** 5V === 3000mA (15W)
- **Cable Length:** 3 feet (built-in)
- **Connector Type:** Micro USB
- **Item Weight:** 2.3 ounces
- **Manufacturer:** BoxWave



Image 7.1: The charger's label displaying detailed electrical specifications.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official BoxWave website or contact their customer service directly. Keep your purchase receipt for warranty claims.

BoxWave Official Website: www.boxwave.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question