Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wurkkos TS26S-US

Wurkkos TS26S Rechargeable Flashlight User Manual

Model: TS26S-US | Brand: Wurkkos

Introduction

The Wurkkos TS26S is a high-performance rechargeable LED flashlight designed for various applications, from daily use to outdoor adventures and emergency situations. It features an impressive 3100 lumens output, high Color Rendering Index (CRI) LEDs for accurate color perception, a magnetic tail cap for hands-free operation, and USB-C charging with reverse charging capability. Its robust IP68 waterproof rating ensures durability in challenging environments.



The Wurkkos TS26S flashlight provides powerful illumination with 3100 lumens output, capable of lighting up vast areas.

What's in the Box

Upon opening your Wurkkos TS26S package, please verify that all the following components are included:

- Wurkkos TS26S Flashlight
- Rechargeable Battery (pre-installed)
- Magnetic Tail Cap
- USB-C Charging Cable
- Pocket Clip
- Spare O-rings

- Lanyard
- User Manual (this document)



Image showing the Wurkkos TS26S flashlight and its included accessories: USB-C cable, spare O-rings, lanyard, and user manual.

Setup

Battery Preparation

Before first use, ensure the battery is properly installed and any protective stickers are removed. The Wurkkos TS26S uses a 21700 Lithium Ion battery.

1. Unscrew the tail cap of the flashlight.
2. Remove the insulating sticker from the positive end of the battery (if present).
3. Insert the battery with the positive (+) end facing towards the head of the flashlight.
4. Screw the tail cap back on securely.




Illustration demonstrating the removal of the battery insulating sticker before initial use.

Charging the Flashlight

The TS26S features a convenient USB-C charging port for direct recharging. It also supports reverse charging to power other devices.

- Locate the USB-C port on the flashlight body.
- Connect the provided USB-C cable to the flashlight and a compatible USB power source (e.g., wall adapter, computer USB port).
- The indicator light on the side switch will show charging status.
- For reverse charging, connect your device to the flashlight's USB-C port using an appropriate cable.



The TS26S flashlight can charge other electronic devices, serving as a portable power bank.

Operating Instructions

The Wurkkos TS26S is operated via a single side switch, offering intuitive control over its various modes.



The side switch provides easy control for turning the flashlight on/off and cycling through modes.

Basic Operation

- **Turn On/Off:** Single click the side switch to turn the flashlight on or off.
- **Change Brightness Modes:** When the flashlight is on, press and hold the side switch to cycle through the brightness levels: Eco, Low, Medium, High, Ultra-bright. Release the switch at your desired brightness.
- **Turbo Mode:** From any state (on or off), double-click the side switch to instantly activate Turbo mode. Double-click again to return to the previous mode.
- **Strobe/SOS/Beacon:** Triple-click the side switch to activate Strobe mode. Double-click again to cycle through SOS

and Beacon modes. Single click to turn off.

- **Moonlight Mode:** From off, press and hold the side switch for approximately 1 second to activate Moonlight mode.
- **Lockout Mode:** From off, quadruple-click the side switch to activate lockout mode. The flashlight will flash once to confirm. To unlock, quadruple-click again. This prevents accidental activation.

Battery Indicator

The indicator light on the side switch provides real-time battery status:

- **Green light always on:** Battery capacity is 75% or higher.
- **Green light flashing:** Battery capacity is between 50% and 75%.
- **Red light flashing:** Battery capacity is between 0% and 25%. Recharge immediately.



The side switch indicator provides clear battery level feedback.

Features

- **Super Bright Illumination:** Equipped with powerful LEDs, the TS26S delivers an astounding 3100 lumens, providing exceptional brightness for various tasks.



The TS26S utilizes four 519A LEDs for high-quality light output.

- **High Color Rendering Index (CRI):** Featuring 95CRI LEDs, the flashlight ensures superior color accuracy and clarity, allowing you to see objects in their true colors.



High CRI LEDs provide better recognition of object contours and a more accurate visual experience.

- **Boost Constant Current Driver:** This advanced driver ensures consistent and stable light output across various battery levels, providing reliable performance.
- **Magnetic Tail Cap:** The integrated magnetic tail cap allows for convenient hands-free operation, attaching the flashlight to metal surfaces.



The magnetic tail cap allows for versatile hands-free lighting.

- **USB-C Rechargeable & Reverse Charging:** Fast and convenient recharging via USB-C. The flashlight can also act as a power bank to charge other devices.
- **IP68 Waterproof Rating:** Designed to withstand harsh conditions, the TS26S is fully waterproof and can be submerged up to 2 meters for 30 minutes.



The TS26S is built to endure, with IP68 waterproofing and drop resistance up to 1 meter.


- **Durable Construction:** Made from aerospace-grade aluminum with an anti-slip texture and toughened ultra-clear glass lens with anti-reflective coating.



The flashlight features an anti-slip texture for a secure grip.

Specifications

Detailed technical specifications for the Wurkkos TS26S flashlight:



Comprehensive specifications table for the Wurkkos TS26S.

General Specifications

Feature	Detail
Model	TS26S-US
Brand	Wurkkos
Light Source Type	LED (4x 519A LEDs)
Max Luminous Flux	3100 Lumens
Max Light Path Distance	191 Meters
Color Temperature	5000K
Color Rendering Index (CRI)	95
Power Source	Battery Powered (1x Lithium Ion 21700, included)
Voltage	3.7 Volts
Max Runtime	325 hours (Eco mode)
Material	Aluminum
Product Dimensions	1.1"D x 1.1"W x 4.8"H
Item Weight	10.6 ounces
Water Resistance Level	IP68 (2 meters for 30 minutes)
Impact Resistance	Up to 1 Meter

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Wurkkos TS26S flashlight.

- **Cleaning:** Wipe the flashlight body with a clean, soft cloth. For stubborn dirt, use a slightly damp cloth. Do not use harsh chemicals or abrasives.
- **Threads and O-rings:** Periodically lubricate the threads and O-rings with silicone grease to maintain waterproof integrity and smooth operation. Replace O-rings if they appear damaged or worn.
- **Battery Care:** If the flashlight will not be used for an extended period, remove the battery to prevent potential leakage. Store the battery in a cool, dry place.
- **Lens Cleaning:** Gently clean the lens with a lens cleaning cloth or cotton swab. Avoid touching the lens surface directly with fingers.

Troubleshooting

If you encounter issues with your Wurkkos TS26S, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery not installed correctly. Battery is depleted. Flashlight is in lockout mode. Tail cap is loose.	Ensure battery is inserted with positive end towards the head. Recharge the battery using the USB-C port. Quadruple-click the side switch to exit lockout mode. Tighten the tail cap securely.
Light output is dim or flickers.	Low battery level. Poor contact between battery and contacts. Dirty threads or contacts.	Recharge the battery. Ensure battery is fully seated. Clean threads and contacts with a clean cloth.
Flashlight gets hot quickly.	Operating in Turbo or High mode for extended periods. High ambient temperature.	This is normal for high-output flashlights. The flashlight has thermal regulation to prevent overheating. Reduce brightness to a lower mode.
Cannot charge other devices (reverse charging).	Flashlight battery is too low. Incompatible charging cable or device.	Ensure flashlight battery is sufficiently charged. Try a different USB-C cable or device.

Warranty and Support

Wurkkos provides a one-year warranty for the TS26S flashlight. We are committed to ensuring your satisfaction with our products.

- **Warranty Period:** One-year from the date of purchase.
- **Contact Support:** If you have any questions, concerns, or require assistance with your Wurkkos TS26S flashlight, please do not hesitate to contact our customer service team. We aim to respond and resolve issues within 24 hours.
- **Online Resources:** For additional information and updates, visit the official Wurkkos store on Amazon:Wurkkos Amazon Store.

© 2024 Wurkkos. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CXSB32FJ

More documents and user manuals: **https://manuals.plus/**