

SogesHome 101-2WT-PRO

SogesHome 31.5-inch Mobile Standing Desk (Model 101-2WT-PRO) User Manual

Brand: SogesHome | Model: 101-2WT-PRO

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your SogesHome 31.5-inch Mobile Standing Desk. Please read this manual thoroughly before use to ensure proper function and longevity of your product.

SAFETY INFORMATION

- Always assemble the desk according to the provided instructions.
- Ensure the desk is placed on a stable, level surface.
- Do not overload the desk beyond its recommended weight capacity.
- Exercise caution when using the lockable casters to prevent accidental movement.
- Keep the desk away from direct heat sources and liquids to prevent damage to materials.

SETUP AND ASSEMBLY

Your SogesHome Mobile Standing Desk requires assembly. All necessary tools and hardware are included in the package. Follow the steps below for quick and easy setup.

Assembly Diagram




Figure 1: Detailed assembly diagram with labeled parts and overall dimensions (L31.5 x W23.6 x H26.4 - 45.3 inches).

1. Unpack all components and verify against the parts list (not provided in this manual, refer to packaging).
2. Attach the base supports to the main frame using the provided screws and tools.
3. Install the lockable universal casters onto the base supports. Ensure they are securely tightened.
4. Mount the two desktop panels to the adjustable support bars. Note that the panels can be positioned independently.
5. Attach the cup holder and headphone holder to the designated slots on the desk frame.
6. Ensure all connections are tight and the desk is stable before use.

OPERATING INSTRUCTIONS

The SogesHome Mobile Standing Desk offers versatile adjustments for optimal comfort and functionality.

Height Adjustment

The desk's overall height can be adjusted from 26.4 inches to 45.3 inches. This allows for comfortable use while sitting or

standing.

Adjust height

Height Can Be Adjusted Freely According To Needs



Figure 2: Height adjustment mechanism. Loosen the knobs on the vertical supports, adjust to desired height, and re-tighten securely.

Multifunctional Lift Table

Adjustable desktop height for use in two modes




Figure 3: The desk can be used in both standing and sitting modes, adapting to various user preferences.

Desktop Panel Adjustment

The desk features two independent desktop panels. The main panel (31.5 x 23.6 inches) and a smaller side panel (approximately 11.8 x 20 cm, based on diagram). Both can be adjusted for tilt and height independently.

- **Tilt Function:** The main desktop panel and the smaller side panel can be tilted to various angles. Loosen the adjustment knobs located underneath each panel, set to your desired angle, and re-tighten.
- **Anti-Slip Ledges:** Ledges are provided on the main panel to prevent items like laptops or tablets from sliding off when tilted.
- **Orientation:** The smaller side panel can be attached to either the left or right side of the main panel, accommodating both left-handed and right-handed users.



Figure 4: Main desktop panel tilted for ergonomic use, ideal for reading or drawing.

Integrated Features

- **Cup Holder:** A dedicated cup holder is located on the side of the desk for convenient access to beverages.
- **Headphone Holder:** An iron hook is provided for organizing your headset or backpack, keeping your workspace tidy.
- **Lockable Casters:** The desk is equipped with universal casters, allowing for easy movement. Lock the casters to secure the desk in place.
- **Table Slot:** A slot is integrated into the main desktop for holding tablets or smartphones upright.



Cup Holder



Table Slot



Lockable Wheels



Headphone Hook

Figure 5: Key features of the desk: cup holder, table slot, lockable wheels, and headphone hook.



Figure 6: The desk in use, demonstrating its functionality as a portable workstation.

MAINTENANCE

To ensure the longevity and appearance of your SogesHome Mobile Standing Desk, follow these maintenance guidelines:

- **Cleaning:** The desk is made of particle wood with a high glossy finish, making it easy to clean. Use a soft, damp cloth and mild detergent for cleaning. Avoid abrasive cleaners or harsh chemicals.
- **Protection:** Keep the desk away from prolonged exposure to direct sunlight, extreme temperatures, and high humidity.
- **Fasteners:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary to maintain stability.

TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose fasteners or uneven surface.	Ensure all assembly screws are securely tightened. Place the desk on a flat, level surface. Adjust leg levelers if present (not explicitly mentioned but common).
Desktop panels are leaning or not holding position.	Adjustment knobs are not sufficiently tightened.	Re-tighten the adjustment knobs located underneath the desktop panels until they are firm.
Casters do not roll smoothly or lock properly.	Debris in casters or faulty locking mechanism.	Clean any debris from the caster wheels. Ensure the locking mechanism is fully engaged or disengaged.
Difficulty adjusting height.	Adjustment knobs are too tight or mechanism is stiff.	Loosen height adjustment knobs completely before attempting to adjust. Apply a small amount of silicone lubricant to the sliding parts if necessary.

SPECIFICATIONS

Brand: SogesHome

Model Number: 101-2WT-PRO

Overall Dimensions (L x W x H): 31.5" x 23.66" x 26.4" - 45.3"

Main Desktop Dimensions: Approximately 31.5" x 23.6" (based on diagram)

Side Desktop Dimensions: Approximately 11.8" x 20 cm (based on diagram)

Material: Particle wood with high glossy finish (Top), Heavy-duty powder-coated metal (Frame)

Color: Upgrade White

Item Weight: 22.8 Pounds

Special Features: Adjustable height, Tilttable desktop panels, Cup holder, Headphone holder, Lockable universal casters, Tablet slot.

Assembly Required: Yes

WARRANTY INFORMATION

This SogesHome product comes with a Limited Warranty. For specific terms and conditions, please refer to the warranty card included with your product packaging or contact customer support.

CUSTOMER SUPPORT

Should you have any questions, concerns, or require assistance with your SogesHome Mobile Standing Desk, please do not hesitate to contact our customer service team. Contact information can typically be found on the product packaging or on the official SogesHome website.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CXSB3YH3>

More documents and user manuals: <https://manuals.plus/>