Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KENES KE-9050-5-P

KENES KE-9050-5-P Polished Chrome Widespread Bathroom Faucet User Manual

Model: KE-9050-5-P

Introduction

This manual provides instructions for the installation, operation, and maintenance of your KENES KE-9050-5-P Polished Chrome Widespread Bathroom Faucet. Please read thoroughly before installation and use to ensure proper function and longevity of the product.

Product Overview

The KENES KE-9050-5-P is a modern, two-handle widespread bathroom faucet designed for 3-hole, 8-inch installations. It features a polished chrome finish, durable stainless steel construction, and a lead-free design, ensuring safety and a sleek appearance in your bathroom.



Main view of the KENES KE-9050-5-P Polished Chrome Widespread Bathroom Faucet, showcasing its modern design and polished finish.




The KENES Polished Chrome Widespread Bathroom Faucet installed on a bathroom sink, highlighting its aesthetic appeal.

Package Contents

Verify that all components are present and undamaged before beginning installation.

- Widespread Faucet Body
- Two Handle Levers
- Pop-up Drain Assembly

- Hot and Cold Water Supply Lines (PEX certified inner tube, 304 stainless steel outer layer)
- Installation Hardware



All components included with the KENES KE-9050-5-P faucet: faucet body, handles, pop-up drain, supply lines, and installation hardware.

Setup and Installation

This faucet is designed for straightforward installation. A Phillips head screwdriver and a wrench are typically the only tools required.

Pre-Installation Checks

- Ensure your sink has three holes, 8 inches apart.
- Confirm maximum deck thickness is 2.25 inches and minimum clearance to backsplash is 1.25 inches.
- Hole size should be between 1 and 1.5 inches.



Diagram illustrating the required sink hole configuration and dimensions for installing the widespread faucet.

Installation Steps

1. Turn off the main water supply to the bathroom.
2. Remove any existing faucet and thoroughly clean the sink area.
3. Install the faucet body and two handle levers into the corresponding sink holes. Secure them from underneath the counter using the provided nuts and washers.
4. Connect the hot and cold water supply lines to the faucet's inlets and then to your hot and cold water supply valves. Ensure all connections are hand-tightened, then use a wrench for a final quarter-turn to prevent leaks.
5. Install the pop-up drain assembly into the sink drain hole. Apply silicone sealant (not included) around the drain flange for a watertight seal before tightening the retaining nut from below.
6. Once all components are securely installed, slowly turn on the main water supply and check all connections for any leaks.



View from underneath the sink showing the secured faucet components and connected supply lines during installation.

Operating Instructions

The faucet features a two-handle design for precise control over water flow and temperature.

- To turn on the cold water, lift the right handle.
- To turn on the hot water, lift the left handle.
- Adjust both handles to achieve the desired water temperature and flow.
- The integrated aerator provides a steady and splash-free stream, suitable for daily tasks such as hand washing and teeth brushing.



Illustration of the two-handle operation, demonstrating how to control hot and cold water flow and temperature.



Close-up of the faucet's aerated water flow, designed for a steady and splash-free experience.

Maintenance

Cleaning

To maintain the polished chrome finish, clean regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish and compromise the fingerprint-resistant properties. The finish is designed to resist corrosion and fingerprints.



Image highlighting the anti-fingerprint and mirror-like finish of the faucet, indicating ease of cleaning.

Aerator Maintenance

If water flow decreases over time, the aerator at the end of the spout may be clogged with mineral buildup or debris. To clean, carefully unscrew the aerator from the spout, rinse away any obstructions, and reattach it securely.



Fast Drainage

·User-friendly design Pop up drain with just one touch will quickly spilled water

·10% faster than traditional effluent

Close-up view of the faucet spout, where the aerator is located, useful for maintenance.

Troubleshooting

Low Water Flow

- Check if the hot and cold water supply valves under the sink are fully open.
- Clean the aerator for any mineral buildup or debris (refer to Aerator Maintenance section).
- Inspect the supply lines for kinks or obstructions that might restrict water flow.

Leaks

- Ensure all connections, especially those for the supply lines and the faucet body, are tightened properly. Do not overtighten, as this can cause damage.
- Check the pop-up drain assembly for proper sealing and ensure the retaining nut is secure.
- If leaks persist after checking connections, contact customer support.

Specifications

Feature	Detail
Brand	KENES
Model Name	Widespread Bathroom Faucet
Model Number	KE-9050-5-P
Material	Stainless Steel
Finish Type	Polished Chrome
Number of Handles	2
Mounting Type	Deck Mount
Hole Count	3
Flow Rate	1.2 Gallons Per Minute (4.5L/min at 410 kPa)
Special Feature	Lead Free
Included Components	Drain, Installation Hardware
Spout Height	4.4 Inches
Spout Reach	6.3 Inches
Handle Type	Lever
Handle Lever Placement	Left, Right
UPC	734914731766

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact KENES customer service directly. Contact details can typically be found on the manufacturer's website or included documentation.

Official Product Video

Your browser does not support the video tag.

This video provides an overview of the KENES Widespread Bathroom Faucet, showcasing its design and features.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CXSGW91R

More documents and user manuals: **https://manuals.plus/**