

[Manuals.plus](#) /

› [IVOXEX](#) /

› IVOXEX Laser Tag Guns Set with Digital LED Score Display Vests, Model B0CXSLJPXG Instruction Manual

IVOXEX B0CXSLJPXG

IVOXEX Laser Tag Guns Set Instruction Manual

Model: B0CXSLJPXG

PRODUCT OVERVIEW

The IVOXEX Laser Tag Guns Set provides an engaging and interactive gaming experience for multiple players. This set includes laser guns and digital LED score display vests, designed for both indoor and outdoor play, promoting teamwork and active engagement.

SAFETY INFORMATION

For external use only. The laser guns utilize child-safe infrared emission and do not emit actual laser beams, ensuring no damage to the eyes. Adult supervision is recommended for younger players.

PACKAGE CONTENTS


- 4 x Laser Tag Guns
- 4 x Digital LED Score Display Vests
- 1 x Screwdriver
- 4 x Screws
- 1 x Instruction Manual



Packaging Box



Breastplate x4



Manual



Screwdriver



Screw x4



Laser Gun x4

Image: The package includes four laser guns, four breastplates, a manual, a screwdriver, and screws.

SETUP

Battery Installation

- Each laser gun requires 3 x 1.5V AAA batteries.
- Each vest requires 3 x 1.5V AAA batteries.
- A total of 24 AAA batteries are required (batteries are not included).
- Use the provided screwdriver to open the battery compartments on both the guns and vests. Insert batteries according to the polarity markings and secure the covers.

LASER GUN INTRODUCTION



Image: Detailed view of the laser gun, highlighting the battery compartment located at the bottom of the handle, requiring 3 AAA batteries.

BREASTPLATE INTRODUCTION

Press The Left Button
For 3 Seconds (Switch)

Four Color Lighting Teams



Team Selection
Button

Led Lights Shows
Remaining Lives

Infrared Receiver

Adjustable Straps

Breastplate Switch
(Press and hold for three seconds)

Adjustable Straps

Uses 3 1.5v "AAA"
Batteries

Image: Detailed view of the breastplate, showing the battery compartment on the back, also requiring 3 AAA batteries.

Powering On

- Locate the power switch on each laser gun and slide it to the 'ON' position.
- For the vests, press and hold the left button for 3 seconds to power them on.

OPERATING INSTRUCTIONS

Team Selection

- The set supports up to 4 teams, indicated by Red, Purple, Green, and Blue/White colors.
- On the laser gun, use the 'Team Select' button to cycle through the available team colors.
- On the vest, use the 'Team Selection Button' to match your team color.

BREASTPLATE INTRODUCTION

Press The Left Button
For 3 Seconds (Switch)

Four Color Lighting Teams



Team Selection
Button

Led Lights Shows
Remaining Lives

Infrared Receiver

Adjustable Straps

Breastplate Switch
(Press and hold for three seconds)

Adjustable Straps

Uses 3 1.5v "AAA"
Batteries

Image: The breastplate features a team selection button and displays four color lighting options for teams: Blue, Red, Green, and White.

Weapon Modes

- Choose from four distinct weapon modes: Pistol, Laser Gun, Machine Gun, and Plasma Gun.
- Each weapon mode has different bullet capacities and impacts on opponent's lives.

Weapon Select Overview

Weapon Type	Number of Bullets	Life Taken Per Shot
Pistol	9	1
Laser Gun	6	2
Machine Gun	6	2
Plasma Gun	1	3

4 BLASTER MODES TO CHOOSE FROM

WEAPON SELECT

 Single Shot	Number of Bullets : 10 Life Taken Per Shot : 1
 Machine Gun	Number of Bullets : 5 Life Taken Per Shot : 2
 Lasergun	Number of Bullets : 5 Life Taken Per Shot : 2
 Plasma Gun	Number of Bullets : 1 Life Taken Per Shot : 3

OK

Suitable for indoor or outdoor games, supports multiplayer melee, the laser gun will make a sound and vibrate every time it hits



Image: A visual representation of the four blaster modes: Single Shot, Machine Gun, Lasergun, and Plasma Gun, detailing their bullet count and life taken per shot.

Gameplay

- The effective firing range of the laser gun is approximately 130 feet (40-60 meters).
- Digital LED displays on the vests show remaining lives.
- Guns will make a sound and vibrate every time an opponent is hit.
- To reload your gun, push the wide button located on the bottom of the handle.

THE EFFECTIVE FIRING RANGE OF THE LASER GUN IS 40-60 METERS



Image: Children playing laser tag in an outdoor setting, demonstrating the effective firing range of the laser guns.

Official Product Video

Your browser does not support the video tag.

Video: A seller-provided overview of the Laser Tag Guns Set, showcasing its features and gameplay.

MAINTENANCE

Keep the laser tag guns and vests clean and dry. Store them in a cool, dry place when not in use.

Battery Care

- Remove batteries if the product will not be used for an extended period to prevent leakage.
- Replace all batteries simultaneously with new ones.
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Guns or Vests Not Powering On

- Ensure batteries are correctly inserted with the correct polarity.
- Replace with fresh batteries.
- Check if the power switch is fully engaged.

Inaccurate Hits or Poor Range

- Ensure there are no physical obstructions between the gun's infrared launcher and the vest's target sensor.
- Avoid playing in extremely bright sunlight, as intense light can interfere with the infrared signal's range and accuracy.
- Check battery levels in both the gun and vest; low batteries can reduce performance.

SPECIFICATIONS

- Product Dimensions: 1 x 1 x 1 inches
- Item Weight: 2.92 pounds
- Manufacturer Recommended Age: 8 - 12 years
- Batteries: 24 AAA batteries required (not included)
- Manufacturer: IVOXEX

WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty information, please refer to the contact details provided with your purchase or visit the official IVOXEX website for assistance.