CYKOV CY59H

CYKOV Office Chair User Manual

Model: CY59H | Brand: CYKOV

Introduction

Thank you for choosing the CYKOV Office Chair. This high-back desk chair is designed to provide ultimate comfort and ergonomic support for long hours of sitting, whether in a home office or executive setting. Featuring adjustable height, lumbar support, padded flip-up armrests, and a 360-degree swivel, this chair is built for versatility and durability. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new chair.



Figure 1: CYKOV Office Chair, Hunter Green.

Safety Guidelines

Please read and follow these safety guidelines carefully to prevent injury and ensure proper use of your chair.

- **Maximum Weight Capacity:** Do not exceed the maximum weight recommendation of 300 pounds (136 kg).
- **Assembly:** Ensure all parts are securely fastened before use. Do not use the chair if any components are damaged or missing.
- **Stability:** Always sit properly in the chair. Avoid standing on the chair or using it as a step stool.
- **Movement:** Be cautious when moving the chair, especially on uneven surfaces. Ensure the area around the chair is clear to prevent tripping hazards.
- **Children:** Keep children away from the chair during assembly. Do not allow children to play on or around the chair unsupervised.
- **Maintenance:** Regularly inspect the chair for loose screws or damaged parts. Tighten fasteners as needed.



Figure 2: Key components ensuring safety and stability.

Package Contents

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Backrest Assembly (1)
- Seat Cushion Assembly with Armrests (1)
- Gas Lift Cylinder (1)
- Star Base (1)
- Casters (5)
- Mechanism Plate (1)
- Hardware Pack (Screws, Washers, Allen Wrench)
- Instruction Manual (1)



Figure 3: Chair dimensions and weight capacity.

Assembly Guide

Assembly is straightforward and typically takes about 30 minutes. Follow these steps carefully:

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the star base.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with the provided screws and Allen wrench.
4. **Attach Backrest to Seat:** Align the backrest with the mounting points on the seat cushion assembly. Secure with screws.
5. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift

cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.

Tip: It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

Operating Instructions

Your CYKOV Office Chair offers several adjustable features to customize your seating experience for optimal comfort and support.

Height Adjustment

To adjust the chair's height (4-inch range):

- **To raise:** While seated, lift the lever located on the right side of the chair. The chair will rise. Release the lever at the desired height.
- **To lower:** While seated, lift the lever located on the right side of the chair and apply slight pressure downwards. The chair will lower. Release the lever at the desired height.



Figure 4: Recline, swivel, and height adjustment controls.

Recline and Tilt Lock

The chair features a 90-135 degree tilt lock mechanism:

- **To recline:** Pull out the lever on the left side of the chair to allow the backrest to recline.
- **To lock recline:** Push the lever back in at your desired recline angle to lock the position.
- **Adjusting Tilt Tension:** Rotate the round knob located underneath the seat (usually at the front) clockwise to increase tilt tension (harder to recline) or counter-clockwise to decrease tension (easier to recline).

Adjustable Lumbar Support

The chair includes a 2-inch adjustable lumbar support for personalized back comfort:

- Locate the lumbar support mechanism on the back of the chair.
- Gently push or pull the lumbar support pad up or down to find the position that best supports your lower back.



Figure 5: Ergonomic features including lumbar support and armrests.

Flip-Up Armrests

The convenient flip-up armrests offer flexibility and space-saving options:

- To raise the armrests: Simply lift them upwards until they lock into a vertical position. This allows the chair to be pushed closer under a desk or save space.
- To lower the armrests: Gently pull them downwards until they return to the horizontal position.



Figure 6: Flip-up armrests for versatility.

360-Degree Swivel Function

The chair's 360-degree swivel allows for effortless rotation and movement, enhancing your mobility and reach within your workspace.

Care and Maintenance

Proper care will extend the life and appearance of your CYKOV Office Chair.

- **Cleaning:** For general cleaning, wipe surfaces with a soft, damp cloth. For spills, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Leather Seat Care:** The premium leather seat is durable and easy to wipe. For best results, use a leather-specific cleaner and conditioner periodically.
- **Mesh Backrest:** The mesh backrest can be gently vacuumed to remove dust. For stains, dab with a damp

cloth and mild soap.

- **Casters:** Periodically check casters for hair or debris that may hinder smooth movement. Clean as needed.
- **Fasteners:** Regularly check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can fade upholstery.

Troubleshooting Common Issues

If you encounter any issues with your chair, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact support.
Chair wobbles or feels unstable.	Loose screws or improper assembly.	Check and tighten all screws, especially those connecting the seat to the mechanism and the backrest. Ensure casters are fully inserted into the base.
Casters do not roll smoothly.	Debris (hair, lint) caught in casters or damaged casters.	Turn the chair over and remove any debris from the caster wheels. If casters are damaged, they may need replacement.
Backrest does not recline or lock.	Tilt lock lever not engaged or tilt tension too tight.	Ensure the tilt lock lever is pulled out to allow recline. Adjust the tilt tension knob counter-clockwise to loosen.

Product Specifications

Feature	Detail
Brand	CYKOV
Model Name	HOME OFFICE DESK CHAIR (CY59H)
Color	Hunter Green
Product Dimensions	22"D x 20"W x 40"H
Maximum Weight Recommendation	300 Pounds

Feature	Detail
Seat Height Adjustment	4 inches (19.68" - 23.62")
Reclining Position Count	90-135 degrees (5 positions)
Lumbar Support	Adjustable (2 inches)
Arm Style	Flip-up Armrests
Base Movement	360-degree Swivel
Fill Material	Foam (3.15" thick, high resilience)
Furniture Finish	Leather (seat) / Mesh (back)
Item Weight	28.6 pounds

Warranty Information and Customer Support

CYKOV stands behind the quality and durability of its products. Your CYKOV Office Chair comes with a comprehensive **5-Year Warranty**.
This warranty covers manufacturing defects and significant malfunctions under normal use. Please retain your proof of purchase for warranty claims.
For any questions, concerns, or warranty claims, please contact CYKOV customer support. Our team is dedicated to ensuring your satisfaction.
Contact Information: Please refer to the contact details provided on your purchase receipt or the official CYKOV website for the most up-to-date support channels.




Figure 7: Dedicated customer support team.

© 2024 CYKOV. All rights reserved.