

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Outsunny](#) /

› [Outsunny 3-Piece Outdoor Rattan Lounge Set \(Model IT84G-359V00CW0631\) Instruction Manual](#)

Outsunny IT84G-359V00CW0631

Outsunny 3-Piece Outdoor Rattan Lounge Set Instruction Manual

Model: IT84G-359V00CW0631

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Outsunny 3-Piece Outdoor Rattan Lounge Set. This set includes a chaise longue, a 2-seater sofa, and a coffee table, designed for outdoor use. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.



Image 1: The Outsunny 3-Piece Outdoor Rattan Lounge Set, featuring a chaise longue, a 2-seater sofa, and a coffee table, arranged on a wooden patio.

2. SAFETY WARNINGS

- To ensure the stability of the furniture, secure it to a wall if necessary.
- Do not exceed the maximum load capacity: 240 kg for the chaise longue/sofa, and 50 kg for the coffee table.
- Follow the provided assembly instructions carefully.
- Keep the furniture away from heat sources and do not cover it with flammable materials.
- Regularly check the integrity of the furniture and tighten any loose screws.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The package should contain:

- 1 x Chaise Longue frame
- 1 x 2-Seater Sofa frame
- 1 x Coffee Table frame
- Seat cushions for chaise longue and sofa
- Back cushions for chaise longue and sofa
- Assembly hardware (screws, wrench, etc.)

4. SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the steps below. It is recommended to assemble the furniture on a soft, clean surface to prevent scratches.

4.1 Unpacking and Component Identification

Carefully remove all parts from the packaging. Identify each component and compare it with the parts list in your separate assembly guide (not included in this manual but typically provided with the product). Ensure all hardware is present.

4.2 Frame Assembly

Assemble the frames of the chaise longue, 2-seater sofa, and coffee table according to the specific instructions provided in your product's assembly manual. Typically, this involves attaching legs and connecting frame sections using the provided hardware. Ensure all connections are secure but do not overtighten until all parts are aligned.

DETTAGLI



PE Rattan Vimini



Piedini



Top in metallo



Scaffale di stoccaggio

Image 2: Detailed view of the PE rattan weave, sturdy furniture feet, the durable metal tabletop, and the convenient lower storage shelf of the coffee table.

4.3 Cushion Placement

Once the frames are fully assembled and stable, place the seat and back cushions onto the chaise longue and sofa. The cushions are designed for a snug fit to provide optimal comfort.

Your browser does not support the video tag.

Video 1: A short demonstration showing the placement of cushions on the Outsunny lounge set, highlighting the comfortable and supportive design.

CUSCINO CONFORTEVOLE

Fornisce un'esperienza
di comfort



schienale




per lo

Image 3: A close-up demonstrating the comfort of the cushions, with additional views of the back and seat cushions.

5. OPERATING INSTRUCTIONS

The Outsunny 3-Piece Outdoor Rattan Lounge Set is designed for comfortable outdoor seating and relaxation. Use the chaise longue for extended lounging, the 2-seater sofa for general seating, and the coffee table for placing drinks, books, or decorative items. The lower shelf of the coffee table provides additional storage.



VIMINI PE RATTAN



Image 4: A detailed view of the PE rattan weave, emphasizing its hand-woven texture, UV resistance, and weather-resistant properties.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your lounge set.

- **Cleaning the Frames:** Wipe the PE rattan and metal frames with a damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the material.
- **Cushion Care:** The cushion covers are removable and washable. Unzip the covers and follow the washing instructions on the label, typically a gentle cycle with cold water. Allow to air dry completely before reattaching.
- **Weather Protection:** Although the set is UV and water-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) can affect its longevity. Consider using a protective cover or storing cushions indoors during harsh weather.
- **Regular Inspection:** Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary to maintain structural integrity.




Image 5: A close-up of a cushion showing its zipper, illustrating the removable and washable nature of the cushion covers for easy maintenance.

7. TROUBLESHOOTING

If you encounter any issues with your lounge set, refer to the following common solutions:

- **Instability:** Ensure all bolts and screws are securely tightened. Check that the furniture is placed on a flat, even surface. If necessary, use shims under the feet to level.
- **Missing Parts:** If any parts were missing upon delivery, contact customer support immediately with your purchase details.
- **Cushion Discomfort:** Ensure cushions are placed correctly. Over time, cushions may compress; regular fluffing can help maintain their shape and comfort.

8. SPECIFICATIONS

Feature	Detail
Model	IT84G-359V00CW0631

Feature	Detail
Material	PE Rattan, Polyester, Steel (frame)
Color	Crema (Cream)
Chaise Longue Dimensions	130L x 70P x 80A cm (Length x Depth x Height)
2-Seater Sofa Dimensions	120L x 70P x 80A cm (Length x Depth x Height)
Coffee Table Dimensions	46L x 46P cm (Length x Depth)
Overall Product Dimensions	70 x 80 x 130 cm (as listed in product data, likely referring to the largest component or packaged size)
Weight	31 kg
Max Load Capacity (Chaise/Sofa)	240 kg
Max Load Capacity (Coffee Table)	50 kg
Special Features	UV Resistant, Water Resistant, Removable and Washable Cushions
Assembly Required	Yes



Image 6: Dimensional diagram illustrating the length, depth, and height of the chaise longue, 2-seater sofa, and coffee table components.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Outsunny customer service. Keep your proof of purchase for any warranty claims.

Manufacturer: Aosom Italy

Return Policy: This product is returnable within 30 days of receipt.

