

[Manuals.plus](#) /

› [smartoo](#) /

› smartoo Wireless Cat Water Fountain Instruction Manual

smartoo PSWFS001S

Wireless Cat Water Fountain Instruction Manual

Model: PSWFS001S | Brand: smartoo

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your smartoo Wireless Cat Water Fountain. Designed with your pet's hydration and your convenience in mind, this stainless steel fountain offers a large capacity, multiple working modes, and advanced filtration for clean, fresh water.



Figure 1: The smarttoo Wireless Cat Water Fountain, showcasing its sleek stainless steel design and flowing water.

PRODUCT COMPONENTS

Before assembly, ensure all components listed below are present in your package:

- Wireless Cat Water Fountain (Stainless Steel Water Tank)
- Stainless Steel Water Tray
- Master Control Module
- Pump Set
- Filter Tray
- Filter (1 included)
- Type-C Cable and Adapter
- Cleaning Brush
- User Manual

Packing Accessories



Figure 2: All included accessories and parts of the smartoo Wireless Cat Water Fountain.

SETUP INSTRUCTIONS

The smartoo Wireless Cat Water Fountain is designed for easy assembly and disassembly. Follow these steps for initial setup:

1. **Clean Components:** Before first use, thoroughly clean all parts of the fountain, especially the stainless steel water tank and tray, with mild soap and water. Rinse thoroughly.
2. **Install Filter:** Place the filter into the filter tray. Ensure it is seated correctly.
3. **Assemble Pump Set:** Connect the pump set to the master control module.
4. **Place Master Control Module:** Insert the assembled master control module and pump set into the designated slot within the stainless steel water tank.
5. **Add Water:** Fill the stainless steel water tank with clean water up to the MAX line indicated on the side. The fountain has a large 4.5L (152oz) capacity, providing ample water for up to two weeks for cats.

6. **Place Water Tray:** Position the stainless steel water tray on top of the unit, ensuring it aligns properly with the water outlet from the master control module.
7. **Charge Battery:** For optimal performance, fully charge the built-in 4000mAh rechargeable battery using the provided Type-C cable and adapter before first use. A full charge can last up to 60 days.

3 Water Modes Available for Your Cats



Figure 3: Simplified assembly diagram illustrating the main parts for easy setup.

OPERATING INSTRUCTIONS

The smarttoo Wireless Cat Water Fountain offers flexible operation modes to suit your pet's needs and conserve battery life.

Water Modes:

The fountain features three distinct working modes, selectable via the control panel on the master module:

- **Sensing Mode:** When a pet approaches within 31.5 inches (80cm) of the fountain, water will flow for 15 seconds. This is the most recommended mode for battery efficiency and encouraging pet hydration.
- **Intermittent Mode:** Water dispenses for 15 seconds at intervals of 10 minutes.
- **Constant Mode:** Water flows continuously. This mode will consume battery power more rapidly.

3 Water Modes

Switch between sensing mode, intermittent mode or constant mode



Figure 4: Visual representation of the three available water dispensing modes.

Battery Life and Placement:

The integrated 4000mAh battery provides up to 60 days of operation on a single charge, depending on the selected mode and usage frequency. Its wireless design allows flexible placement anywhere in your home, eliminating concerns about wires being chewed or tripping hazards.

Long-lasting Power

Up to **60 days** of power on a single charge
4000 mAh Li-Polymer Battery



Drinking abundant water benefits your cat's
kidney and urinary health.

Figure 5: The fountain's long-lasting battery ensures continuous hydration for your pet.

Hydration without Boundaries

Battery-operated so your pets can drink wherever they like



Figure 6: The wireless design allows for flexible placement in various locations, such as a desk, lounge, reading room, or living room.

Filtration System:

The fountain utilizes a multi-stage vertical filtration system to ensure water purity and taste:

- **Activated Carbon:** Removes bad taste and odors.
- **Ion Exchange Resin:** Softens tap water.
- **Medical Stone:** Removes heavy metals and releases trace elements.
- **Non-woven Fabric:** Filters hair and impurities.
- **High-density Sponge (in pump):** Helps remove fine particles.

Purity in Every Drop

4-layer filtration system removes heavy metals, dirt, and other harmful substances



Figure 7: The multi-layer filtration system ensures clean and healthy water for your pets.

MAINTENANCE

Regular cleaning and filter replacement are crucial for maintaining water quality and extending the life of your fountain.

Cleaning the Fountain:

The SUS 304 stainless steel construction makes the fountain easy to clean and dishwasher-safe. Disassemble the fountain into its main components (water tank, water tray, master control module, pump set, filter tray) for thorough cleaning. Use the provided cleaning brush for the pump and other intricate parts.

Wireless, More Secure




Figure 8: The fountain's design allows for easy disassembly and cleaning of all parts.

How to Clean the Pump:

For detailed instructions on cleaning the pump, please refer to the official video below. Regular pump cleaning prevents mineral buildup and ensures optimal water flow.

Your browser does not support the video tag.

Video 1: This video demonstrates the proper procedure for cleaning the pump of your smartoo Wireless Cat Water Fountain, ensuring its longevity and efficient operation.

Filter Replacement:

It is recommended to replace the filter regularly to maintain optimal water quality. The frequency depends on usage and water hardness, but generally, replacement every 2-4 weeks is advised. Additional filters can be purchased separately.

TROUBLESHOOTING

If you encounter issues with your smartoo Wireless Cat Water Fountain, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Water not flowing or weak flow	Low water level, clogged pump, low battery.	Refill water to MAX line. Clean the pump thoroughly (refer to cleaning video). Recharge the fountain battery.
Fountain is noisy	Low water level, pump not properly seated, debris in pump.	Ensure water is at adequate level. Re-seat the pump. Clean the pump.
Water tastes or smells bad	Filter needs replacement, fountain needs cleaning.	Replace the filter. Disassemble and clean all fountain components.
Motion sensor not activating	Sensor obstructed, low battery, incorrect mode.	Ensure sensor is clear. Recharge battery. Verify fountain is in Sensing Mode.

SPECIFICATIONS

Model Name: Wireless Cat Water Fountain

Model Number: PSWFS001S

Brand: smartoo

Material: SUS 304 Stainless Steel

Color: Silver

Capacity: 4.5 Liters (152 oz)

Battery: Built-in 4000mAh Li-Polymer Rechargeable Battery

Noise Level: Approximately 20dB

Dimensions (L x W x H): 11.14" x 8.5" x 5.49"

Item Weight: 2.2 Pounds

Target Audience: Cats, Small Animals, Dogs

Usage: Indoor Only

WARRANTY AND SUPPORT

Your smartoo Wireless Cat Water Fountain comes with a comprehensive warranty:

- **Master Control Module:** 12-month warranty
- **Pump:** 18-month warranty

For further assistance, technical support, or warranty claims, please refer to the contact information provided in the original product packaging or visit the official smartoo website.

A digital version of this user manual is also available for download:[User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question