

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FITUEYES](#) /

› [FITUEYES Hand Crank Lift TV Stand with Wheels for 32-75 Inch TVs, Model B0CXT1BBSM Instruction Manual](#)

FITUEYES B0CXT1BBSM

FITUEYES Hand Crank Lift TV Stand with Wheels

MODEL: B0CXT1BBSM

Instruction Manual

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your FITUEYES Hand Crank Lift TV Stand with Wheels. Please read this manual thoroughly before installation and use to ensure safe and correct operation. Keep this manual for future reference.



Image: The FITUEYES Hand Crank Lift TV Stand with Wheels, shown with a television mounted, in a modern room setting.

Safety Information

Please observe the following safety precautions to prevent injury or damage to your product and property:

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or defective.
- Do not exceed the maximum load capacity of 88 lbs (40 kg).
- This TV stand is designed for TVs between 32 and 75 inches. Verify your TV's VESA pattern is compatible (200x200mm to 600x400mm).
- Always have at least two people for assembly and when mounting or dismounting the TV.
- Ensure the wheels are locked when the stand is in a stationary position to prevent accidental movement.
- Keep children and pets away from the TV stand during assembly and operation.
- Avoid placing heavy objects on the TV stand's base that could obstruct movement or cause instability.

Package Contents

Before beginning assembly, verify that all parts listed below are included in your package. If any parts are missing or damaged, please contact customer support.

Please Check the Size and Compability for Your TV




Image: An exploded diagram illustrating all components of the TV stand, including the base, central column, TV mounting plate, VESA adapter arms, hand crank, and various fasteners and tools. Key dimensions and VESA compatibility are also shown.

The package typically includes:

- Base with pre-installed wheels
- Central column (height adjustable)
- TV mounting plate
- VESA extension brackets (if needed for larger VESA patterns)
- Hand crank for height adjustment
- Various screws, washers, and spacers for TV mounting
- Assembly tools (e.g., Allen wrench, spanner)

Setup and Assembly Instructions

Follow these steps carefully for proper assembly. It is recommended to have a second person assist with the assembly process, especially when handling the TV.

Video: A detailed installation support video demonstrating the step-by-step assembly of the FITUEYES TV stand.

1. **Attach Wheels to Base:** If not pre-installed, screw the four lockable wheels into the designated holes on the bottom of the base. Ensure they are tightened securely.
2. **Connect Column to Base:** Align the central column with the mounting holes on the base. Ensure the correct orientation (refer to the video for hexagonal vs. round holes). Secure the column to the base using the provided screws and Allen wrench.
3. **Insert Hand Crank:** Carefully insert the hand crank into the designated opening on the central column. Ensure it is not pushed through the column entirely, but seated correctly to engage the lifting mechanism.
4. **Attach TV Mounting Plate:** Secure the TV mounting plate to the top of the central column using the provided screws. Before fully tightening, adjust the tilt angle if desired, then secure the screws.
5. **Install VESA Brackets:** Attach the VESA brackets to the back of your television using the appropriate screws, washers, and spacers for your TV model. Ensure the brackets are securely fastened and evenly spaced.
6. **Mount TV to Stand:** With assistance, carefully lift your TV and hook the VESA brackets onto the TV mounting plate on the stand. Ensure the TV is centered and level. Secure the TV to the stand using the safety screws or locking mechanisms at the bottom of the VESA brackets.

Operating Instructions

This section details how to adjust and use your FITUEYES TV stand.

Video: A demonstration of the hand crank lift mechanism and overall mobility of the FITUEYES TV stand with wheels.

Height Adjustment

The TV stand features a hand crank mechanism for smooth and effortless height adjustment without needing to remove your TV.

- To raise the TV, turn the hand crank clockwise.
- To lower the TV, turn the hand crank counter-clockwise.
- The height can be adjusted from 38 inches to 59.6 inches (from the floor to the center of the TV mounting plate).

STEPLESS HEIGHT ADJUSTMENT WITHOUT UNSCREWING TV



Image: The TV stand illustrating the stepless height adjustment feature, showing the TV at its maximum and minimum height settings.

Video: A short demonstration of the TV stand's height adjustment feature using the hand crank, highlighting ease of use.

Tilt Adjustment

The TV mounting plate allows for a tilt adjustment of 0° to 10°.

- To adjust the tilt, loosen the tilt adjustment screws on the sides of the mounting plate.
- Adjust the TV to your desired angle.
- Tighten the tilt adjustment screws firmly to secure the TV in place.

Tilt for Optimal Viewing



Image: The TV stand demonstrating the tilt function, showing the TV angled upwards by 10 degrees.

Swivel Adjustment

The TV stand allows for a swivel adjustment of $\pm 30^\circ$.

- Gently rotate the TV to the left or right to achieve your desired viewing angle.
- No locking mechanism is typically required for swivel, as it is designed for fluid movement.

Ultra-Wide Viewing Angle



Image: The TV stand demonstrating the swivel function, showing the TV rotated to the side for an ultra-wide viewing angle.

Lockable Wheels

The four high-quality PU wheels are lockable to ensure stability when the stand is stationary.

- To move the TV stand, unlock all four wheels by pressing the lever on each wheel upwards.
- To secure the TV stand in place, push the lever on each wheel downwards to lock them.

Maintenance

Regular maintenance helps prolong the life and appearance of your TV stand.

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid abrasive cleaners or solvents that may damage the finish.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Moving Parts:** The hand crank mechanism and wheels are designed for durability. If you notice any stiffness, ensure no debris is obstructing their movement.
- **Cable Management:** Utilize the integrated cable management features to keep cables tidy and prevent tripping hazards.

Cable Management



Image: The TV stand demonstrating effective cable management, with cables neatly organized along the central column.

Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

- **TV is not level:** Check that the VESA brackets are installed evenly on the back of the TV and that the TV mounting plate is securely fastened to the column. Adjust as needed.
- **Hand crank is stiff or not adjusting height:** Ensure the hand crank is fully inserted and engaged with the lifting mechanism. Check for any obstructions in the column. Do not force the crank.
- **Wheels are not locking/unlocking:** Verify that the locking levers on each wheel are fully engaged or disengaged. Clean any debris from the wheel mechanisms.
- **Stand feels unstable:** Ensure all assembly screws are tightened securely. Do not exceed the maximum weight capacity of the stand. Distribute the TV's weight evenly.
- **Missing parts:** If any parts were missing upon delivery, contact FITUEYES customer support immediately for replacements.

Specifications

Feature	Specification
---------	---------------

Compatible TV Sizes	32-75 inches
Maximum Load Capacity	88 lbs (40 kg)
VESA Compatibility	200x200mm to 600x400mm
Height Adjustment Range	38 inches to 59.6 inches (from floor)
Tilt Angle	0° to 10°
Swivel Angle	±30°
Base Material	Iron
Overall Product Dimensions	23.62 x 15.74 x 59.64 inches
Item Weight	30 pounds

Warranty and Support


FITUEYES products are designed for quality and durability. For specific warranty information regarding your product, please refer to the warranty card included in your package or visit the official FITUEYES website. If you require technical assistance, have questions about assembly, or need to report a missing/damaged part, please contact FITUEYES customer support.

You can typically find contact information on the product packaging, the official brand website, or through your retailer.

© 2025 FITUEYES. All rights reserved.

Related Documents - B0CXT1BBSM

	<p>FITUEYES TT106002GB TV Stand with Mount - Installation Guide</p> <p>Comprehensive installation guide for the FITUEYES TT106002GB TV Stand with Mount. Includes parts list, step-by-step assembly instructions, and hardware details for easy setup.</p>
	<p>FITUEYES TC65 TV Cart Installation Guide</p> <p>A comprehensive guide for assembling and installing the FITUEYES TC65 mobile TV cart, detailing parts, hardware, and step-by-step instructions for mounting televisions.</p>
	<p>FITUEYES FT-S1601MB TV Stand with Mount Installation Guide</p> <p>Comprehensive installation manual for the FITUEYES FT-S1601MB TV Stand with Mount. Includes parts list, step-by-step instructions, and safety information for assembly.</p>




[FITUEYES TT107501MB TV Stand with Mount Installation Guide](#)

Comprehensive installation guide for the FITUEYES TT107501MB TV Stand with Mount. Includes parts list, safety warnings, and step-by-step assembly instructions for flat-backed and irregular-backed TVs.



[FITUEYES TC78 TV Cart Installation Guide | Portable TV Stand](#)

Comprehensive installation guide for the FITUEYES TC78 TV Cart. Learn how to assemble and mount your TV safely with clear steps and part descriptions.



[FITUEYES TT104001GB Universal TV Stand Assembly Instructions & Parts List](#)

Assemble your FITUEYES TT104001GB Universal TV Stand with this comprehensive guide. Includes parts list, step-by-step instructions, and safety warnings for safe and secure TV mounting.