PACOVY FLL-018-F5

PACOVY 18W Bright LED Floor Lamp User Manual

Model: FLL-018-F5
Brand: PACOVY

1. Introduction

Thank you for choosing the PACOVY 18W Bright LED Floor Lamp. This manual provides essential information for the safe and efficient operation of your new floor lamp. Please read these instructions thoroughly before use and retain them for future reference.



Image: The PACOVY 18W Bright LED Floor Lamp, showcasing its sleek design, diamond-surface lamp head, flexible gooseneck, and both remote and touch controls.

2. Safety Instructions

- Ensure the power supply voltage matches the lamp's requirements before plugging in.
- Do not disassemble or modify the lamp. Refer all servicing to qualified personnel.
- Keep the lamp away from water or other liquids to prevent electric shock.
- Place the lamp on a stable, level surface to prevent tipping. The weighted base is designed for stability.
- Avoid direct eye exposure to the LED light for prolonged periods.
- Unplug the lamp from the power outlet before cleaning or when not in use for an extended period.
- This lamp is designed for indoor use only.

3. Package Contents

- LED Floor Lamp (unassembled sections)

- Weighted Base
- Power Adapter
- Remote Control
- User Manual

4. Assembly Instructions

Assembly of your PACOVY floor lamp is quick and requires no additional tools.

1. Carefully unpackage all components.
2. Connect the lamp pole sections by screwing them clockwise until secure.
3. Screw the assembled lamp pole into the weighted base clockwise until firmly attached.
4. Connect the power cord to the lamp and then plug it into a standard electrical outlet.



Image: Visual guide for assembling the floor lamp, illustrating the connection of pole sections, attachment to the base, and power cord connection.

5. Operating Instructions

5.1. Touch Control

The lamp features intuitive touch controls located on the pole:

- **Short Touch:** Power On/Off.
- **Long Touch (Color Temperature Adjustment):** Continuously adjust color temperature from warm to cool (2700K to 6500K).
- **Short Touch (Color Temperature Modes):** Cycle through four preset color temperatures: Warm White, Natural White, Daylight, and Cool White.
- **Long Touch (Brightness Adjustment):** Continuously adjust brightness from 5% to 100%.
- **Short Touch (Brightness Levels):** Cycle through four preset brightness levels: 10%, 40%, 70%, 100%.



Image: Close-up of the lamp's touch control panel, detailing the functions of each button for power, color temperature, and brightness.

5.2. Remote Control

The magnetic remote control offers convenient operation from up to 49.2ft (15m) away. It can be securely attached to the lamp pole.




Image: The floor lamp with its magnetic remote control, demonstrating both touch and remote operation capabilities.

Remote Control Functions:



Image: Detailed layout of the remote control buttons and their corresponding functions.

- **Power Button:** Turns the lamp On/Off.
- **Brightness +/-:** Adjusts brightness levels.
- **Color Temperature +/-:** Adjusts color temperature.
- **1H Timer:** Activates a 1-hour timer.
- **Preset Modes:** Dedicated buttons for Reading Mode, Working Mode, Night Mode, and Breastfeeding Mode.

Pairing/Canceling the Remote:

- **Pairing:** When using for the first time, press and hold the power button on the remote for 5-10 seconds to pair it with the floor lamp.
- **Canceling:** To cancel pairing, toggle the power cord off and on 5 times. The light will flicker to confirm cancellation.

5.3. Brightness and Color Temperature Adjustment

The lamp offers stepless adjustment for both brightness and color temperature, allowing for precise customization of your lighting environment.



Image: The floor lamp demonstrating various color temperatures from 2700K (warm white) to 6500K (cool white) and brightness levels from 5% to 100%.

5.4. Lighting Modes

Utilize the preset lighting modes for optimized illumination in different scenarios:

- **Reading Mode:** Bright, neutral light for comfortable reading.
- **Working Mode:** Cool, bright light for focus and productivity.
- **Night Mode:** Soft, warm light for relaxation.
- **Breastfeeding Mode:** Gentle, warm light suitable for nighttime care.



Image: Examples of the floor lamp's various lighting modes in use, such as for reading, working, and nighttime.

5.5. Timer Function

Activate the 1-hour timer via the remote control. The lamp will automatically turn off after one hour. Pressing any button on the remote or touch panel will interrupt the timer and require a new timer activation.



Image: Visual demonstration of the 1-hour timer function, showing the lamp active and then automatically turning off.

5.6. Memory Function

The lamp features a memory function that automatically restores your last-used brightness and color temperature settings when turned back on.

6. Features Overview

- **18W Super Bright & Eye-Caring LED:** Diffuse, non-flickering light protects eyes and provides ample illumination.
- **Flexible Gooseneck:** 360° adjustable up to 13.8 inches for directing light precisely.
- **Unique Diamond Lamp Head:** Modern design that blends with various decors.
- **Safe Stable Base:** Weighted base minimizes tipping risk, ensuring safety around pets and children.



Image: An infographic detailing the lamp's physical features, including its adjustable gooseneck, diamond-shaped head, and stable base.

7. Maintenance

- Clean the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the lamp is unplugged before cleaning.
- The LED light source is integrated and not user-replaceable.

8. Troubleshooting

8.1. Remote Control Not Responding

- Check if the remote control batteries need replacement.
- Ensure there are no obstructions between the remote and the lamp.
- Re-pair the remote control with the lamp by pressing and holding the power button on the remote for 5-10 seconds.
- If issues persist, try canceling the pairing by toggling the power cord off and on 5 times, then re-pair.

8.2. Lamp Not Turning On

- Verify that the power cord is securely plugged into both the lamp and the electrical outlet.
- Check if the electrical outlet is functioning correctly by plugging in another device.

9. Specifications

Feature	Detail
Model Name	FLL-018-F5
Brand	PACOVY
Wattage	18 watts
Brightness	1800 Lumen
Light Source Type	LED
Color Temperature	2700K to 6500K (Warm White, Natural White, Daylight, Cool White)
Control Method	Remote, Touch
Product Dimensions	6"D x 9"W x 65.4"H
Item Weight	5.86 Pounds
Material	Stainless Steel
Power Source	Corded Electric
Special Feature	Corded, Dimmable, Color Adjustable, Timer, Memory Function, Flexible Gooseneck
Certifications	UL, FCC, CE, RoHS

10. Warranty and Support

This PACOVY floor lamp is covered by a**2-year manufacturer's warranty**.
For any issues or questions not covered in this manual, please contact PACOVY customer service for assistance. Please have your model number (FLL-018-F5) and purchase information ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question