



Manuals.plus /

› LINSY HOME /

› LINSY HOME Farmhouse 9-Drawer Dresser (Model LH618E4) Instruction Manual

LINSY HOME LH618E4

LINSY HOME Farmhouse 9-Drawer Dresser

Model: LH618E4

1. INTRODUCTION

This manual provides essential instructions for the assembly, safe use, and maintenance of your LINSY HOME Farmhouse 9-Drawer Dresser, Model LH618E4. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The LINSY HOME Farmhouse 9-Drawer Dresser is designed to offer ample storage and complement various decorative styles. It features a sturdy wooden frame, thickened panels, and nine spacious drawers.

2. SAFETY INFORMATION

- **Tip-Over Prevention:** Always use the provided wall anchor kit to secure the dresser to a wall. Failure to do so can result in serious injury or death from tip-over.
- **Weight Capacity:** The maximum load capacity for the dresser tabletop is 66 lbs (30 kg). Do not exceed this weight.
- **Drawer Safety:** Smooth metal runners on each drawer include safety stops to prevent drawers from being pulled out completely, reducing the risk of items falling or drawers detaching.
- **Assembly:** Assembly requires two people. An electric screwdriver is recommended for efficiency.
- **Placement:** Place the dresser on a level, stable surface.

Ample Storage Space

 **50+**
Tissue

 **90+**
Socks

 **70+**
Underwear

 **60+**
Snacks

 **40+**
Toys

 **60+**
Shirt



Image: The LINSY HOME 9-Drawer Dresser is suitable for various rooms, offering ample storage.

3. PACKAGE CONTENTS

Before assembly, ensure all parts and hardware are present and undamaged. Refer to the included assembly instructions for a detailed list of components. If any parts are missing or damaged, contact customer support.

- Dresser panels and components
- Hardware pack (screws, dowels, cam locks, etc.)
- Wall anchor kit
- Assembly instructions

4. ASSEMBLY INSTRUCTIONS

Detailed step-by-step assembly instructions are included in your package. Please follow them carefully. The following are general recommendations:

1. **Preparation:** Clear a spacious area for assembly. Lay out all components on a soft, clean surface to

prevent scratches.

2. **Tools:** An electric screwdriver is recommended to expedite the assembly process.
3. **Teamwork:** Two people are recommended for assembly to ensure stability and ease of handling larger components.
4. **Hardware:** Ensure all screws and fasteners are tightened securely, but do not overtighten to avoid damaging the wood.
5. **Wall Anchoring:** After assembly, securely attach the dresser to a wall using the provided wall anchor kit. This is a critical safety step.

| Premium Edge Sealing Process



Exquisite sealing edge,
longer service life



No edge sealing,
easy to crack and mold



Image: Product dimensions and individual drawer capacities.

5. USAGE AND OPERATION

The LINSY HOME Farmhouse 9-Drawer Dresser is designed for versatile storage in various rooms.

- **Storage:** Utilize the nine drawers for organizing clothing, accessories, or other household items.
- **Multi-purpose:** The dresser can also function as a TV stand, provided the television's weight does not exceed the tabletop's maximum load capacity of 66 lbs (30 kg).
- **Drawer Operation:** Drawers are equipped with smooth metal runners for easy opening and closing. Do

not force drawers if they feel stuck.

Your browser does not support the video tag.

Video: This video demonstrates the features and ample storage capacity of the LINSY HOME Farmhouse 9-Drawer Dresser. It shows the drawer operation, the inclusion of a drawer organizer, and the overall design.

6. MAINTENANCE AND CARE

To maintain the appearance and longevity of your dresser, follow these care instructions:

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent moisture damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.

P2 Grade Material
Not only more cost-effective
but also environmentally sustainable

Formaldehyde Emission

Grade	Color
P2	Green
E0	Yellow
E1	Orange
E2	Red

SGS

CARB PHASE 2 COMPLIANT

TSCA EP. TITLE VI COMPLIANT

Image: The dresser features a premium edge sealing process for enhanced durability and moisture resistance.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, consider the following:

- **Wobbly Dresser:** Ensure all screws and fasteners are securely tightened. Check that the dresser is placed on a level surface. Adjust furniture levelers if present.
- **Stuck Drawer:** Check for any obstructions inside or behind the drawer. Ensure the drawer runners are properly aligned.
- **Missing Parts:** If any parts were missing upon delivery, refer to the assembly instructions and contact customer support for replacements.

8. SPECIFICATIONS

Feature	Detail
Brand	LINSY HOME
Model Name	LH618E4
Product Dimensions	16"D x 36"W x 53"H
Color	Grey
Material	Wood
Finish Type	Wood
Number of Drawers	9
Item Weight	110 Pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

Ample Storage, Multi Occasion

Spacious drawers help you keep your house tidy



Image: The dresser is constructed with P2 Grade Material, emphasizing environmental sustainability.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact LINSY HOME directly through their official channels. Ensure you have your model number (LH618E4) and purchase details available when contacting support.