

[Manuals.plus](#) /

› [Lighting EVER](#) /

› Lepro Bundle - 1000LM Battery Powered LED Camping Lantern & PR320019 Super Bright Headlamp User Manual

Lighting EVER 1000LM Camping Lantern & PR320019 Headlamp Bundle

Lepro Bundle User Manual

1000LM Battery Powered LED Camping Lantern & PR320019 Super Bright Headlamp

Model: 1000LM Camping Lantern & PR320019 Headlamp Bundle | Brand: Lighting EVER

1. INTRODUCTION

Thank you for purchasing the Lepro Bundle, which includes a 1000LM Battery Powered LED Camping Lantern and a PR320019 Super Bright Headlamp. This comprehensive user manual provides detailed instructions for the safe and efficient use, setup, operation, maintenance, and troubleshooting of both products. Please read this manual thoroughly before use and retain it for future reference.



Image: The Lepro Bundle, featuring the 1000LM Camping Lantern and the PR320019 Headlamp, along with accessories.

2. PRODUCT OVERVIEW

2.1 Lepro 1000LM Battery Powered LED Camping Lantern

This powerful and versatile camping lantern is designed to provide bright, reliable illumination for various outdoor activities. Its robust construction ensures durability, while multiple lighting modes offer flexibility for different needs.

- **High Brightness & Dimmable:** Delivers up to 1000 lumens, adjustable by long-pressing the power button.
- **4 Lighting Modes:** Easily switch between Daylight White, Warm White, Full Brightness (combined), and Flashing modes with a short press.
- **Long Battery Life:** Powered by 3 D alkaline batteries (not included), providing up to 12 hours of light at 1000

lumens.

- **Waterproof Design:** Suitable for use in various weather conditions.
- **Versatile Mounting:** Features a top handle for hanging and a bottom hook for inverted hanging.



Image: The 1000LM Camping Lantern highlighting its brightness, long runtime on low setting, and 360-degree illumination.

2.2 Lepro PR320019 Super Bright Headlamp

The PR320019 headlamp offers superior hands-free illumination with its wide beam and adjustable spotlight, perfect for hiking, cycling, and other activities requiring focused or broad lighting.

- **Superior Brightness & Wide Beam:** Delivers 350 lumens with a 230° wide-angle COB light.
- **Adjustable Spotlight:** A unique spotlight feature allows for focused illumination, adjustable to specific needs.
- **Versatile Lighting Modes:** Includes 6 modes: COB light (high/low), Spotlight (high/low), and motion sensor activation.
- **Motion Sensor:** Enables hands-free operation; wave your hand to activate or deactivate the COB light.
- **USB Rechargeable:** Equipped with a 1200mAh battery, rechargeable via USB-C.

Wide Beam Floodlight & Spotlight

30°
Adjustable



230°
Area
Illumination



Notes: Spotlight & flood light can not be on at the same time

Image: The PR320019 Headlamp showcasing its wide beam floodlight and adjustable spotlight capabilities.

3. SETUP

3.1 Lepro 1000LM Battery Powered LED Camping Lantern

1. **Battery Installation:** Unscrew the bottom cap of the lantern. Insert 3 D-size alkaline batteries (not included) according to the polarity markings (+/-) inside the battery compartment. Replace the bottom cap and twist to secure.
2. **Initial Check:** Press the power button to ensure the lantern turns on.



3 x D Size Battery Powered
(NOT Included)

Image: Dimensions of the 1000LM Camping Lantern and illustration of the required D-size batteries.

3.2 Lepre PR320019 Super Bright Headlamp

1. **Initial Charge:** Before first use, fully charge the headlamp. Connect the included USB-C cable to the headlamp's charging port and the other end to a USB power source (e.g., wall adapter, computer USB port). The charging indicator light will show charging status. A full charge takes approximately 4 hours.
2. **Adjust Headband:** Adjust the elastic headband to fit comfortably and securely around your head.

1200mAh USB Rechargeable

Type-C cable included



4 Hours

Fully Charged



Hrs Usage



Image: The PR320019 Headlamp connected for USB-C charging, showing charging time and usage duration.

4. OPERATING INSTRUCTIONS

4.1 Lepro 1000LM Battery Powered LED Camping Lantern

1. **Power On/Off:** Press the power button once to turn the lantern on or off.
2. **Adjust Brightness (Stepless Dimming):** When the lantern is on, long-press the power button to smoothly adjust the brightness level from dim to bright, and vice-versa. Release the button at your desired brightness.
3. **Switch Lighting Modes:** Short-press the power button repeatedly to cycle through the 4 lighting modes: Daylight White → Warm White → Full Brightness (Daylight + Warm) → Flashing → Off.
4. **Mounting Options:** Use the integrated top handle to hang the lantern from a tent ceiling or branch. For inverted hanging, utilize the bottom hook.





Image: The 1000LM Camping Lantern illustrating its stepless dimming function and the four distinct lighting modes.



Bottom Hook



Top Handle

Image: Examples of the 1000LM Camping Lantern being used with its bottom hook and top handle for versatile placement.

4.2 Lepro PR320019 Super Bright Headlamp

1. **Power On/Off:** Press the power button once to turn the headlamp on or off.
2. **Switch Lighting Modes:** Short-press the power button repeatedly to cycle through the 6 lighting modes: COB High → COB Low → Spotlight High → Spotlight Low → Motion Sensor Mode → Off.
3. **Motion Sensor Activation:** When in Motion Sensor Mode, wave your hand approximately 2-4 inches in front of the sensor to turn the COB light on or off without pressing the button. This feature is ideal for hands-free operation.
4. **Adjust Spotlight Angle:** The spotlight can be physically adjusted to direct the beam as needed.

5 Lighting Modes

230°

Flood Light

High--350lm



Low--110lm



Motion sensor



High--150lm



Low--60lm



30°

Spot Light

Image: The PR320019 Headlamp illustrating its various floodlight and spotlight modes, including motion sensor activation.

Wide Angle Illumination




Image: The PR320019 Headlamp providing wide-angle illumination during a cycling activity.

5. MAINTENANCE

- **Cleaning:** Wipe both the lantern and headlamp with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Care (Lantern):** If the lantern will not be used for an extended period, remove the D-size batteries to prevent leakage and corrosion.
- **Battery Care (Headlamp):** Recharge the headlamp regularly, even if not in frequent use, to maintain battery health. Avoid fully depleting the battery for prolonged periods.
- **Storage:** Store both products in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lantern does not turn on.	Batteries are dead or incorrectly installed.	Replace D-size batteries with new ones, ensuring correct polarity.
Lantern light is dim.	Batteries are low.	Replace D-size batteries.
Headlamp does not turn on.	Battery is depleted.	Charge the headlamp using the USB-C cable.
Headlamp light is dim.	Battery is low.	Recharge the headlamp.
Headlamp motion sensor not responding.	Not in motion sensor mode; Obstruction in front of sensor; Sensor dirty.	Ensure headlamp is in motion sensor mode. Clear any obstructions. Clean the sensor area.

7. SPECIFICATIONS

7.1 Lepro 1000LM Battery Powered LED Camping Lantern

Feature	Specification
Brightness	Up to 1000 Lumens
Light Source Type	LED
Power Source	Battery Powered (3 x D-size Alkaline, not included)
Battery Life (at 1000LM)	12 Hours
Water Resistance Level	Waterproof
Mounting Type	Tabletop Mount, Hanging (Top Handle, Bottom Hook)
Material	Plastic
Color	Green
Dimensions (approx.)	88 mm (W) x 184 mm (H) / 3.46 in (W) x 7.24 in (H)

7.2 Lepro PR320019 Super Bright Headlamp

Feature	Specification
COB Light Brightness	High: 350 Lumens, Low: 110 Lumens

Feature	Specification
Spotlight Brightness	High: 150 Lumens, Low: 60 Lumens
Beam Angle	230° Wide Beam (COB), 30° Spotlight
Battery Capacity	1200mAh
Charging Type	USB-C Rechargeable
Charging Time	Approx. 4 Hours (fully charged)
Usage Time	4-10 Hours (depending on mode)
Special Features	Motion Sensor

8. WARRANTY AND SUPPORT

Lighting EVER products are manufactured with high-quality materials and craftsmanship. For specific warranty information and customer support, please refer to the warranty card included with your product or visit the official Lighting EVER website. You can also contact the seller directly for assistance.

Lighting EVER Store: [Visit the Lighting EVER Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question