Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Signature Design by Ashley 6070315

Signature Design by Ashley Wolfridge Power Reclining Sofa

Model: 6070315

Introduction

This manual provides essential information for the safe and efficient use of your Signature Design by Ashley Wolfridge Power Reclining Sofa. Please read these instructions thoroughly before setup and operation, and retain this manual for future reference.

The Wolfridge Power Reclining Sofa is designed for comfort and functionality, featuring dual electric recline, adjustable headrests, a drop-down table with integrated charging options, and convenient armrest storage.



Image: Front view of the Wolfridge Power Reclining Sofa in Brindle Brown.

Safety Information

- Ensure all power cords are properly connected and routed to prevent tripping hazards.
- Keep children and pets away from moving parts during reclining operation.
- Do not place heavy objects on the footrest when extended.
- Avoid spilling liquids on electrical components, especially the charging ports and power controls.
- Always unplug the sofa from the power outlet before cleaning or performing any maintenance.

Setup

Unpacking and Placement

The Wolfridge Power Reclining Sofa requires minimal assembly. It is recommended that two people handle the sofa during unpacking and placement due to its weight (322 pounds). Ensure your doorway is at least 32 inches wide for easy entry.



Image: Diagram showing the dimensions of the sofa (Width: 86", Depth: 42", Height: 42").

Assembly

Component connector assembly is not required. The main task involves attaching the backrests to the base. A screwdriver may be useful for any minor adjustments or securing connections.

For detailed assembly instructions, please refer to the manufacturer's guide available at:Ashley Furniture Assembly Instructions.

Power Connection

Locate all power cords. There are typically three cords: one for each reclining seat and one for the center console features. Connect them securely to the sofa's power inputs and then plug into a standard electrical outlet. Ensure cords are not pinched or damaged.

Operating Instructions

Power Recline and Adjustable Headrests

The two outer seats feature independent power recline and Easy View adjustable headrests. Use the control panel located on the side of each armrest to operate these functions. The buttons allow for infinite reclining positions and headrest adjustments.



USB CHARGING

Built-In Power

CHARGING MADE SIMPLE - JUST PLUG YOUR USB CABLE DIRECTLY INTO YOUR FURNITURE AND KEEP YOUR DEVICES POWERED ALL DAY LONG

USB CHARGING STATION

Image: The sofa with the footrest extended, demonstrating the power recline feature.



Image: Close-up of the adjustable headrest, showing its range of motion.

Drop-Down Table and Charging Station

The middle seat's backrest can be folded down to reveal a convenient table. This table includes LED reading lights, dual cup holders, an electrical outlet, a wireless charging docking station, and two USB charging ports.



Image: The middle seat's backrest folded down, revealing the integrated table with lights and charging options.



Image: Detailed view of the drop-down table's electrical outlet, wireless charging pad, and USB ports.

Armrest Storage and Cup Holders

Each outer armrest features a flip-open storage compartment and a built-in cup holder. Lift the top of the armrest to access the storage space.



Image: An armrest with the storage compartment open, showing space for items like remotes or books.



Image: A close-up of the built-in cup holder, designed to securely hold beverages.

Maintenance

Cleaning the Upholstery

The sofa is upholstered in durable faux leather (98% Polyester, 2% PU). For cleaning, spot clean with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the fabric. The upholstery cleaning code is 'S', indicating solvent-based cleaning products may be used for tougher stains, but always test in an inconspicuous area first.



Image: A close-up view of the brindle faux leather upholstery, highlighting its texture.

General Care

- Regularly dust the sofa with a soft, dry cloth.
- Avoid direct sunlight to prevent fading.
- Keep sharp objects away from the upholstery to prevent tears or punctures.
- Check power cords periodically for any signs of wear or damage.

Troubleshooting

Power Issues

- **Sofa not reclining/headrest not adjusting:** Ensure all power cords are securely plugged into the sofa and the wall outlet. Check if the wall outlet is functional by plugging in another device.
- **Charging ports not working:** Verify the main power connection to the sofa. Ensure devices are properly connected to the USB ports or placed correctly on the wireless charging pad.

Recline Mechanism Issues

- **Footrest stuck:** Check for any obstructions under or around the footrest. Do not force the mechanism.
- **Unusual noises during operation:** This may indicate a need for lubrication or a loose component. Contact customer support if noises persist.

General Issues

- If the sofa is not functioning as expected after checking these points, please refer to the product's online support resources or contact Signature Design by Ashley customer service.

Specifications

Feature	Detail
Brand	Signature Design by Ashley
Model Number	6070315
Product Dimensions (D x W x H)	42"D x 86"W x 42"H
Item Weight	322 pounds
Seating Capacity	3
Upholstery Fabric Type	Faux Leather (98% Polyester, 2% PU)
Color	Brindle Brown
Reclining Seat Count	2 (outer seats)
Reclining Position Count	Infinite Position
Additional Features	Adjustable Headrest, Cup Holder, Recliner, Storage, USB Charging Ports, Wireless Charging
Frame Material Type	Engineered Wood
Suspension Type	Sinuous Spring
Minimum Required Door Width	32 inches

Warranty Information

The Signature Design by Ashley Wolfridge Power Reclining Sofa comes with a Limited Warranty. For specific details regarding coverage, duration, and terms, please refer to the product page on the retailer's website or contact Signature Design by Ashley customer service directly.

Customer Support

If you have any questions, require assistance with setup, operation, or encounter any issues not covered in this manual, please contact Signature Design by Ashley customer support. You can typically find contact information on the manufacturer's official website or through your retailer.

For more information about Signature Design by Ashley products, visit their official website:www.ashleyfurniture.com

© 2023 Signature Design by Ashley. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CXTQJHL7

More documents and user manuals: **https://manuals.plus/**