



Manuals.plus /

› Farenheit /

› Farenheit Glass Aromatherapy Diffuser User Manual

Farenheit FAR-OZONE

Farenheit Glass Aromatherapy Diffuser User Manual

Model: FAR-OZONE

1. INTRODUCTION

Thank you for choosing the Farenheit Glass Aromatherapy Diffuser. This ultrasonic essential oil diffuser is designed to provide a soothing mist and pleasant aroma, enhancing the ambiance of your home, office, or vehicle. With its elegant glass design and multiple light settings, it offers both functionality and aesthetic appeal. Please read this manual carefully before use to ensure proper operation and maintenance.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Always place the diffuser on a flat, stable, and water-resistant surface.
- Do not place the diffuser near heat sources, direct sunlight, or on electronic equipment.
- Use only the original power adapter provided with the unit.
- Do not immerse the diffuser base in water or any other liquid.
- Unplug the diffuser from the power outlet before cleaning, refilling, or when not in use.
- Do not block the mist outlet.
- Keep out of reach of children and pets.
- Do not add water above the MAX fill line.
- Only use 100% pure essential oils. Do not use corrosive chemicals or synthetic fragrances.
- If the diffuser emits an unusual smell or sound, or if smoke appears, unplug it immediately and contact customer support.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Farenheit Glass Aromatherapy Diffuser Unit
- Power Adapter
- Remote Control
- User Manual



Image: Power adapter, remote control, and user manual included in the package.

4. PRODUCT OVERVIEW

The Farenheit Glass Aromatherapy Diffuser features an elegant spherical glass design that illuminates with various colors, a compact base with control buttons, and a remote control for convenient operation.



Image: The Farenheit Glass Aromatherapy Diffuser and its remote control.





Image: Internal components of the diffuser, including the water tank and mist outlet.

Key Features:

- **Ultrasonic Technology:** Produces a fine, cool mist without heat.
- **120ml Water Capacity:** Provides mist for up to 3.5 - 4 hours.
- **7 Mood Lights & 15 Modes:** Customizable lighting options for ambiance.
- **Timer Settings:** 1H, 2H, 3H, 4H options for automatic shut-off.
- **Compact Design:** Ideal for small to medium spaces (approx. 6" W x 5" H).
- **Remote Control:** For convenient operation of mist, light, and timer functions.

Ultrasonic Essential Oil Glass Humidifier

Perfect for Any Space:
Car, Office, Home, or
Nursery

Elegant Glass Design
for a Premium Look

120ml
Water Capacity



Image: Diffuser highlighting 120ml water capacity and suitability for various spaces.

Soothing Mist



Mist Lasts for up to
3.5 - 4 hours



Image: Diffuser demonstrating soothing mist output and duration.

7 Mood Lights & 15 Modes



Image: Diffuser showcasing its 7 mood lights and 15 modes, controllable by remote.

Compact Design



Image: Diffuser illustrating its compact design and dimensions.

5. SETUP

Follow these steps to set up your diffuser for first use:

1. Place the diffuser on a flat, stable surface away from direct sunlight or heat sources.
2. Carefully remove the glass cover from the base.
3. Fill the water tank with clean tap water up to the MAX fill line (120ml). Do not overfill.
4. Add 2-3 drops of your preferred 100% pure essential oil directly into the water tank. Adjust the amount based on desired aroma intensity.
5. Replace the glass cover securely onto the base.
6. Connect the power adapter to the DC jack on the back of the diffuser base, then plug the adapter into a standard wall outlet.

6. OPERATING INSTRUCTIONS

You can operate the diffuser using the buttons on the base or the included remote control.

Base Buttons:

- **Power Button (leftmost):** Press once to turn on continuous mist and cycling lights. Press again to turn off.
- **Timer Buttons (1H, 2H, 3H, 4H):** Press to set the mist duration. The diffuser will automatically shut off after the selected time.
- **Light Button (rightmost):** Press to cycle through light modes (fixed color, off, cycling colors).

Remote Control Functions:

Button	Function
ON/OFF	Turns the diffuser on or off.
Intermittent	Sets mist to intermittent mode (e.g., 30 seconds on, 30 seconds off).
Continuous	Sets mist to continuous mode.
Timing (1H, 2H, 3H, 4H)	Sets the automatic shut-off timer.
Big/Small Mist	Adjusts mist output intensity (if applicable).
Light	Cycles through light colors and modes (fixed color, color cycling, off).

Perfect For Relaxation



Image: Diffuser demonstrating features for relaxation, including light and mist settings.

7. MAINTENANCE AND CLEANING

Regular cleaning helps maintain optimal performance and extends the lifespan of your diffuser.

Cleaning Steps:

1. Unplug the diffuser from the power outlet and remove the glass cover.
2. Pour out any remaining water from the water tank, ensuring water does not enter the air outlet.
3. Wipe the inside of the water tank with a soft cloth. For stubborn residue, use a cotton swab dipped in white vinegar to gently clean the ultrasonic plate.
4. Rinse the tank with clean water.
5. Wipe the exterior of the diffuser with a soft, damp cloth.
6. Allow all parts to air dry completely before reassembling or storing.

Important Notes:

- Do not use corrosive detergents or solvents.
- Do not scratch the ultrasonic plate.
- Clean the diffuser regularly, especially if you change essential oils frequently or use it daily.

8. TROUBLESHOOTING

If you encounter issues with your diffuser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No mist or low mist output.	Insufficient water; water level too high; ultrasonic plate dirty; mist outlet blocked.	Add water to MAX line; ensure water is not above MAX line; clean ultrasonic plate; clear mist outlet.
Diffuser does not turn on.	No power connection; power adapter faulty.	Check power connection; try a different outlet; contact support if adapter is faulty.
Lights not working.	Light function turned off; internal issue.	Press the Light button on the base or remote to cycle through modes; contact support if issue persists.
Remote control not working.	Battery depleted; remote not aimed correctly.	Replace battery; ensure clear line of sight to the diffuser's sensor.

9. SPECIFICATIONS

Feature	Detail
Model Number	FAR-OZONE
Dimensions (L x W x H)	12.7 x 15.24 x 12.7 cm (approx. 6" W x 5" H)
Weight	550 g
Material	Glass
Color	Black Base, Multi-color Glass
Water Capacity	120 ml
Mist Duration	Up to 3.5 - 4 hours (continuous mode)
Special Features	Timer settings, Long-lasting aroma, Cool mist, Compact, Multiple light configurations

10. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For warranty claims, technical support, or any questions not covered in this manual, please contact Fahrenheit customer service through the retailer where you purchased the product or visit the official Fahrenheit website for contact information. Please retain your proof of purchase for warranty purposes.