

[Manuals.plus](#) /

› [YOUDENOVA](#) /

› YOUDENOVA Bamboo Bread Box with Cutting Board, Black, 25 x 20 x 39 cm - Instruction Manual

YOUDENOVA B0CXX58BMT

YOUDENOVA Bamboo Bread Box with Cutting Board

Model: B0CXX58BMT

INTRODUCTION

Thank you for choosing the YOUDENOVA Bamboo Bread Box. This product is designed to provide a stylish and functional storage solution for your bread and other kitchen essentials, featuring a convenient integrated cutting board. Please read this manual carefully to ensure proper assembly, use, and maintenance of your bread box.



Image: The YOUDENOVA Bamboo Bread Box in black, showcasing its sleek design and integrated cutting board.

PRODUCT FEATURES

- **High-Quality Bamboo Construction:** Crafted from durable and robust bamboo, ensuring longevity and a natural aesthetic.
- **Integrated Cutting Board:** Features a high-quality bamboo cutting board (approximately 1.2 cm thick) that slides out for convenient bread slicing.
- **Magnetic Door Closure:** Equipped with strong magnets to ensure the door remains securely closed, keeping contents fresh and protected.
- **Acrylic Wavy Transparent Panel:** The door panel features a wavy design that protects contents from insects while offering a degree of privacy.
- **Elevated Design:** The bread box base is elevated by 2.5 cm from the countertop, promoting cleanliness and helping to prevent mold formation.
- **Multi-functional Top Surface:** The flat top surface provides additional space for storing spices, condiments, or other small kitchen items.




Image: Detail showing the waterproof and elevated design features of the bread box.




Image: Close-up of the magnetic closure mechanism and the wooden knob handle.

PACKAGE CONTENTS

Upon unpacking, please ensure all the following components are present:

- 1 x YOUDENOVA Bamboo Bread Box Unit
- 1 x Integrated Bamboo Cutting Board
- Assembly Hardware (screws, small knob)

SETUP AND ASSEMBLY

The YOUDENOVA Bamboo Bread Box requires minor assembly. Please follow these general steps:

1. Unpack all components and verify against the package contents list.
2. Identify the main panels of the bread box (sides, top, bottom, back, door).
3. Assemble the main structure of the bread box using the provided hardware. Ensure all screws are tightened securely but do not overtighten.
4. Attach the wooden knob to the door panel.
5. Carefully insert the acrylic wavy panel into the door frame.
6. Slide the integrated bamboo cutting board into its designated slot at the bottom front of the bread box.

If you encounter any difficulties during assembly, please refer to the visual instructions that may be included in your packaging or contact customer support.

OPERATING INSTRUCTIONS

Using your YOUDENOVA Bamboo Bread Box is straightforward:

- **Storing Bread:** Gently pull the wooden knob to open the door. Place your bread, pastries, or other baked goods inside. Push the door back until the magnets engage, ensuring a secure closure.
- **Using the Cutting Board:** Pull the bamboo cutting board out from its slot at the base of the bread box. Place your bread on the board for slicing. After use, clean the board and slide it back into its storage position.
- **Top Storage:** Utilize the flat top surface of the bread box to store small items like spice jars, salt and pepper shakers, or other kitchen accessories.



Image: The bread box in use, demonstrating storage of bread inside and spices on its top surface.



Image: The cutting board stored beneath the bread box, with additional items placed on top.

MAINTENANCE AND CARE

To ensure the longevity and hygiene of your bamboo bread box, please follow these care instructions:

- **Cleaning the Bread Box:** Wipe the exterior and interior of the bread box with a soft, damp cloth. For stubborn stains, a mild soap solution can be used, followed by wiping with a clean, damp cloth.
- **Cleaning the Cutting Board:** Hand wash the bamboo cutting board with warm water and mild soap. Rinse thoroughly and dry immediately.
- **Drying:** Ensure all parts, especially the cutting board, are completely dry before storing to prevent mold and mildew growth.
- **Avoid Immersion:** Do not immerse the bread box or cutting board in water.
- **No Dishwasher or Microwave:** This product is not dishwasher safe and should not be used in a microwave.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, steel wool, or harsh chemical detergents, as these can damage the bamboo finish.



Image: Detail of the cutting board, emphasizing its easy-to-clean and mold-resistant surface.

TROUBLESHOOTING

- **Door not closing securely:** Check if any items inside are obstructing the door. Ensure the bread box is on a flat,

stable surface. Verify that the magnets are clean and free from debris.

- **Cutting board difficult to slide:** Ensure the slot is clean and free of crumbs. The board should be dry before sliding it back in.
- **Damage upon arrival:** If any components are damaged or missing upon opening the package, please contact customer support immediately for assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	25 x 39 x 19 cm (Bread Box)
Cutting Board Dimensions	Approx. 36 x 25 x 1.2 cm
Weight	3 Kilograms
Material	Bamboo, Acrylic
Color	Black
Capacity	20 Liters
Special Features	Durable, Lightweight, Food Grade Material, Magnetic Closure, Elevated Base
Care Instructions	Hand wash only, Not dishwasher safe, Not microwave safe




Image: Detailed diagram illustrating the dimensions of the bread box and its cutting board.

WARRANTY AND SUPPORT

YOUDENOVA products are manufactured to high-quality standards. For any questions, concerns, or warranty claims regarding your bread box, please contact YOUDENOVA customer support through your retailer or the official brand website. Please retain your proof of purchase for warranty purposes.