

[Manuals.plus](#) /

› [COOL KNIGHT](#) /

› COOL KNIGHT Electric Tobacco and Herb Rolling Machine User Manual

COOL KNIGHT Electric Tobacco and Herb Rolling Machine

COOL KNIGHT Electric Tobacco and Herb Rolling Machine User Manual

Model: Electric Tobacco and Herb Rolling Machine

INTRODUCTION

Thank you for choosing the COOL KNIGHT Electric Tobacco and Herb Rolling Machine. This device is designed for grinding and injecting tobacco or herbs into cigarette tubes or rolling papers efficiently. Constructed from environmentally friendly materials and high-quality stainless steel, it offers durability and ease of operation for both new and experienced users. Please read this manual thoroughly before use to ensure safe and optimal performance.

SAFETY INSTRUCTIONS

- Always ensure the device is unplugged before cleaning or performing any maintenance.
- Keep the device out of reach of children and pets.
- Do not immerse the device in water or any other liquid.
- Use only the provided power adapter.
- Avoid operating the machine with wet hands.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Ensure the grinding hopper is securely closed during operation.
- Use in a well-ventilated area.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the various parts of your COOL KNIGHT Electric Tobacco and Herb Rolling Machine and its accessories.

Electric Cigarette Rolling Machine



Image: This diagram illustrates the main components of the machine, including the grinding hopper, injection tubes, filter screen, adjustment button, and the overall dimensions (8.5 inches length, 3.9 inches width, 4.8 inches height).

Grindable Electric Cigarette Rollers Set




Image: This image displays all items included in the package: the main electric rolling machine unit, a power adapter, a cone loader, a cleaning brush, a scraper, tube probes, and a screwdriver for maintenance.

Main Components:

- **Grinding Hopper:** Where tobacco or herbs are placed for grinding.
- **Injection Tubes:** Two different sizes (8mm & 6.5mm diameter nozzles) for various cigarette tube sizes.
- **Filter Screen:** Collects fine powders.
- **Adjustment Button:** Rotary knob to adjust injection density (Loose/Tight).
- **Power Switch:** To turn the device on/off and initiate/pause injection.

Included Accessories:

- Power Adapter
- Cleaning Brush
- Cleaning Probe
- Screwdriver

- Scraper
- Cone Loader (for pre-rolled papers)

SETUP

1. Unpack all components from the box and ensure all accessories are present.
2. Place the machine on a stable, flat surface. The non-slip pads on the base will help ensure stability.
3. Connect the power adapter to the machine's power input and then plug it into a suitable electrical outlet.
4. Ensure the grinding hopper is clean and free of any debris before first use.

OPERATING INSTRUCTIONS

Follow these steps to operate your electric rolling machine:

Electric Cigarette Rolling Machine Steps for Usage



1 Connect to power and put the tobacco or vanilla into the hopper

2 Insert the empty paper tube into the nozzle (0.8mm or 0.65mm injection tube can be freely chosen)

3 Press the start switch to begin production

4 It will fall off automatically after the injection is completed and can be paused by pressing the switch again

Image: A visual guide demonstrating the four main steps for operating the machine, from loading material to producing a finished cigarette.

1. **Prepare Material:** Open the grinding hopper and place your desired amount of tobacco or herb inside. Close the hopper securely.
2. **Insert Tube:** Select the appropriate injection tube size (8mm or 6.5mm) and insert an empty cigarette tube onto the nozzle.
3. **Adjust Density:** Use the rotary adjustment button on the side to set your preferred injection density (Loose or Tight).
4. **Start Operation:** Press the power switch to begin the grinding and injection process. The machine will automatically fill the tube.
5. **Completion:** Once the injection is complete, the filled cigarette will fall off automatically. You can press the switch again to pause or stop the operation.
6. **Using the Cone Loader:** For pre-rolled papers, use the cone loader accessory to guide the material into the paper after grinding.



Image: This image demonstrates the use of the cone loader, which helps in perfectly injecting ground material into pre-rolled papers.

MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your machine.

- **After Each Use:** Unplug the device. Use the provided cleaning brush and scraper to remove any residual tobacco or herb from the grinding chamber, injection tubes, and filter screen.
- **Cleaning the Filter Screen:** The filter screen is designed to filter out fine powders. Regularly clean it to prevent clogging and maintain efficiency.
- **Cleaning Probes:** Use the cleaning probes to clear any blockages within the injection tubes.
- **Exterior Cleaning:** Wipe the exterior of the machine with a dry or slightly damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the machine in a cool, dry place when not in use.



Image: This image highlights the filter screen and scraper, essential tools for cleaning and maintaining the machine by removing fine powders.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power adapter faulty; power switch off.	Ensure power adapter is securely plugged into both the machine and the outlet. Check if the power switch is in the 'ON' position. Try a different outlet.
Material not grinding or injecting properly.	Hopper clogged; material too moist/dry; filter screen blocked; injection tube blocked.	Clean the grinding hopper and filter screen. Ensure material has appropriate moisture content. Use cleaning probes to clear injection tubes.
Cigarette tube not filling completely or too loosely/tightly.	Density adjustment incorrect; insufficient material; material consistency.	Adjust the rotary density button. Ensure enough material is in the hopper. Check material consistency (should be finely shredded).
Machine stops unexpectedly during operation.	Overload; internal blockage; power interruption.	Turn off and unplug the machine. Clear any blockages. Reduce the amount of material in the hopper. Plug back in and restart.

SPECIFICATIONS

- **Model:** Electric Tobacco and Herb Rolling Machine
- **Brand:** COOL KNIGHT
- **ASIN:** B0CXXQTYMS
- **Package Dimensions:** 8.9 x 4.88 x 4.17 inches
- **Item Weight:** 1.41 Pounds
- **Material:** Environmentally friendly materials, high-quality stainless steel
- **Nozzle Sizes:** 8mm & 6.5mm diameter

WARRANTY AND SUPPORT

COOL KNIGHT is committed to providing high-quality products and excellent customer service. If you encounter any issues or are dissatisfied with your purchase for any reason, please do not hesitate to contact us. We are dedicated to providing the best possible solution and support.

For assistance, please refer to your purchase platform or contact COOL KNIGHT customer service directly through the official brand store or contact information provided at the time of purchase.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is intended for tobacco or legal herb use only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CXXQTYMS>

More documents and user manuals: <https://manuals.plus/>